Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 713-042V80DB

HOMCOM Power Lift Recliner Chair User Manual

Model: 713-042V80DB

1. Introduction

Thank you for choosing the HOMCOM Power Lift Recliner Chair. This chair is designed to provide comfort and assistance, particularly for the elderly or individuals recovering from injuries. It features a power lift mechanism for easy standing, a reclining function, and convenient side pockets. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.



Image: The HOMCOM Power Lift Recliner Chair in a living room setting.

2. Important Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Always follow the assembly instructions carefully to avoid injury.
- Do not exceed the maximum weight limit of**265 lbs (120 kg)**.
- Be cautious when using the electric lift mechanism. Keep fingers and other body parts away from moving parts to prevent pinching or injury.
- Keep the chair on a stable, level surface to prevent tipping.
- Always turn off and unplug the chair when not in use, when cleaning, or when leaving the room for an extended period.
- Keep children and pets away from the chair's moving parts.
- Do not allow children to play on or around the chair.

- Ensure the power cord is not pinched or damaged.
- Do not attempt to repair or modify the chair yourself. Contact qualified service personnel for assistance.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.



Image: The chair is delivered in one package.

- Recliner Chair Base
- Backrest
- Remote Control
- Power Adapter
- Assembly Hardware (bolts, etc.)
- User Manual (this document)

4. Assembly Instructions

Assembly of the HOMCOM Power Lift Recliner Chair is designed to be straightforward. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Backrest:** Align the backrest with the slots on the chair base. Gently slide the backrest down until it clicks securely into place. Ensure both sides are fully engaged.
3. **Secure Backrest:** Insert the provided bolts into the designated holes to firmly attach the backrest to the base. Tighten all bolts using the included tool (if applicable).
4. **Connect Power:** Locate the power cord and connect it to the chair's power input. Plug the power adapter into a standard wall outlet.
5. **Test Functionality:** Use the remote control to test the lift and recline functions to ensure proper operation.

Note: Easy assembly required, just insert the bolts to assemble the backrest.

5. Operating Instructions

The HOMCOM Power Lift Recliner Chair is operated using the included remote control. The remote has two primary buttons for controlling the chair's movement.

5.1 Power Lift Function



Image: The chair's lift function helps users stand up easily.

To use the power lift function:

1. Ensure the chair is plugged into a power outlet.
2. Sit fully back in the chair.
3. Press and hold the **"UP"** button on the remote control. The chair will slowly tilt forward and lift, assisting you to an almost standing position (up to 45 degrees).
4. Release the button when you reach your desired height or are ready to stand.
5. To return to a seated position, press and hold the**"DOWN"** button.



Image: Detailed view of the lift function and remote control.

5.2 Power Recline Function



Image: The chair reclines up to 135 degrees for various activities.

To recline the chair:

1. Ensure the chair is plugged into a power outlet.
2. Sit fully back in the chair.
3. Press and hold the **"DOWN"** button on the remote control. The backrest will recline, and the footrest will simultaneously raise.
4. Release the button at any desired angle between upright and 135 degrees.
5. To return to an upright position, press and hold the **"UP"** button.



Image: The chair fully reclined, showing the retractable footrest and side pockets.

5.3 Remote Control and Side Pockets



Image: The remote control conveniently stored in the chair's side pocket.

The remote control is designed for simple operation with two buttons. When not in use, it can be stored in the convenient side pockets located on the chair, along with other small items.

Your browser does not support the video tag.

Video: Demonstration of the HOMCOM Electric Power Lift Recliner Chair's lift and recline functions.

6. Maintenance and Care

Proper care will extend the life and appearance of your recliner chair.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these may damage the fabric.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Dusting:** Regularly dust the chair with a soft brush or vacuum with an upholstery attachment.

- **Inspection:** Periodically check all bolts and connections to ensure they are tight. Retighten if necessary.
- **Power Cord:** Inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

7. Troubleshooting

If you encounter any issues with your HOMCOM Power Lift Recliner Chair, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not move.	Not plugged in. Power outlet not working. Loose connection. Remote control issue.	Ensure power cord is securely plugged into the chair and wall outlet. Test the outlet with another appliance. Check all cable connections under the chair. Ensure the remote control cable is firmly connected to the chair.
Chair moves slowly or intermittently.	Low power. Obstruction in mechanism. Overload.	Ensure the power adapter is correctly connected and receiving full power. Check under the chair for any objects obstructing the mechanism. Ensure the user's weight does not exceed 265 lbs.
Unusual noises during operation.	Loose hardware. Mechanism friction.	Check and tighten all assembly bolts. If noises persist, contact customer support. Do not attempt to lubricate or disassemble the mechanism.

If the problem persists after trying these solutions, please contact HOMCOM customer support for further assistance.

8. Product Specifications

Feature	Detail
Brand	HOMCOM
Model Name	Power Lift Chair
Model Number	713-042V80DB
Color	Dark Blue
Material	Polyester fabric, Foam fill, Steel frame
Overall Dimensions (Upright)	26" W x 35.5" D x 37.75" H
Overall Dimensions (Reclined)	61.75" L x 26" W x 32" H
Seat Size	18.5" W x 21.5" D x 17.75" H
Weight Capacity	265 lbs (120 kg)

Feature	Detail
Special Features	Foot Rest, Power Lift, Power Reclining, Side Pocket, Spring Pack Seat
Product Care	Wipe Clean
Item Weight	75.2 lbs
UPC	196393334607



Image: Detailed dimensions of the recliner chair.



Image: Features contributing to the chair's padded comfort.

9. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact HOMCOM customer service directly. Keep your purchase receipt and model number handy for faster service.
Manufacturer: Aosom LLC

© 2024 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CR3Y329F

More documents and user manuals: **https://manuals.plus/**