Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ODK SNG-6D

ODK 6-Drawer Dresser (Model SNG-6D) Instruction Manual

Model: SNG-6D

Product Overview

The ODK 6-Drawer Dresser, model SNG-6D, is a versatile storage unit designed for bedrooms and living rooms. It features a sturdy steel frame, a durable wooden top surface, and six spacious fabric drawers. This manual provides essential information for assembly, operation, and maintenance to ensure safe and effective use of your dresser.



Image: The ODK 6-Drawer Dresser integrated into a modern bedroom, showcasing its use as a TV stand and storage unit.

Safety Information

Please read all safety warnings and instructions carefully before assembly and use. Keep this manual for future reference.

- **Anti-Tip Anchors:** Always install the included anti-tip anchors to prevent the dresser from tipping over, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the top surface or drawers. Distribute weight evenly.
- **Stable Surface:** Place the dresser on a flat, stable, and level surface. Use the adjustable feet to ensure stability.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use.

Setup and Assembly

Assembly of the ODK 6-Drawer Dresser is designed to be straightforward. Follow the detailed instructions provided in the packaging. It is recommended to have a second person assist with assembly for ease and safety.

Required Tools (Not Included):

- Screwdriver (Phillips head)
- Hammer (for anti-tip anchors, if applicable)

Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Assemble the steel frame according to the diagrams, ensuring all connections are secure.
3. Attach the wooden top surface to the assembled frame.
4. Insert the X-crossbar at the back for added stability.
5. Install the adjustable feet at the bottom of the frame. Adjust them to level the dresser on uneven floors.
6. Assemble the fabric drawers by inserting the bottom panel and stiffeners.
7. Place the assembled fabric drawers into the designated compartments.
8. Secure the dresser to the wall using the provided anti-tip anchors.



Image: Dimensional diagram of the ODK 6-Drawer Dresser, illustrating overall measurements (100cm width, 30cm depth, 83.7cm height) and individual drawer dimensions (29.5cm width, 30cm depth, 22.5cm height).



Image: Detailed view of the dresser's fabric drawers, highlighting their large size and organizational capacity for various items.

Operating Instructions

The ODK 6-Drawer Dresser is designed for convenient storage and display.

Drawer Usage:

- The six extra-large fabric drawers are suitable for storing clothing, linens, accessories, and other household items.
- Pull drawers gently using the handles. Avoid forcing them open or closed.
- Distribute weight evenly within each drawer to prevent sagging or damage to the fabric.

Top Surface Usage:

- The wooden top surface can be used to display decorative items, lamps, or a television up to 50 inches.
- Ensure that any items placed on the top surface do not exceed its weight capacity.



Image: The dresser supporting a television, demonstrating its capacity to hold TVs up to 50 inches, with various TV sizes indicated for reference.



Image: A robot vacuum cleaner operating beneath the dresser, illustrating the 11.7cm clearance provided by the adjustable feet for easy cleaning.

Maintenance and Care

Proper care will extend the life and appearance of your ODK dresser.

- **Cleaning the Frame and Wooden Top:** Wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. Dry immediately.
- **Cleaning Fabric Drawers:** Spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to the materials.

Troubleshooting

If you encounter any issues with your ODK 6-Drawer Dresser, please refer to the following common solutions or contact customer support.

Dresser is Unstable/Wobbly:

- Ensure the dresser is on a flat, level surface.
- Adjust the leveling feet at the bottom of the frame to compensate for uneven floors.

- Check all assembly screws and bolts; tighten any that are loose.
- Verify that the X-crossbar at the back is correctly installed and secured.

Drawers Do Not Slide Smoothly:

- Ensure the fabric drawers are correctly assembled and their bottom panels are fully inserted.
- Check for any obstructions within the drawer compartments.
- Ensure the dresser frame is not warped or uneven (refer to stability checks above).

Missing Parts or Damaged Components:

- Contact ODK customer service immediately with your purchase details.

Specifications

Brand:	ODK
Model Number:	SNG-6D
Color:	Black
Material:	Wood (top surface), Steel (frame), Cationic Fabric (drawers)
Product Dimensions (D x W x H):	30 cm x 100 cm x 84.5 cm
Number of Drawers:	6
Style:	Modern
Assembly Required:	Yes
Mounting Type:	Floor Mount
Finish Type:	Lacquered (wooden top)
Country of Origin:	China

Warranty and Support

ODK is committed to providing quality products and excellent customer service.

- **Return Policy:** This product is subject to a 30-day refund/replacement return policy. Please refer to your retailer's specific return guidelines for full details.
- **Customer Service:** For any questions, concerns, or assistance with assembly or product issues, please contact the professional ODK customer service team. They are dedicated to resolving your problems efficiently.
- **Transparency Verified:** Each product includes a unique code for verification before shipment, ensuring authenticity.

© 2026 ODK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CR467PPC

More documents and user manuals: **https://manuals.plus/**