Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ARCADE1UP Ms. Pacman Deluxe Black Variant Arcade Machine

ARCADE1UP Ms. Pacman Deluxe Black Variant Arcade Machine User Manual

Model: Ms. Pacman Deluxe Black Variant Arcade Machine

1. Introduction

Welcome to the world of classic arcade gaming with your new ARCADE1UP Ms. Pacman Deluxe Black Variant Arcade Machine. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your arcade cabinet, ensuring years of nostalgic entertainment. Featuring 14 iconic games and a sleek design, this machine is built to deliver an authentic arcade experience in your home.

2. Safety Information

ARCADE1UP assumes no liability for improper installation or excessive loads placed on screws or brackets.
Always ensure the machine is placed on a stable, level surface. Keep away from water and excessive heat. Do not attempt to modify the internal components. For adult use, or supervised use by individuals 14 years and up.

3. Product Features

- 14 Classic Games
- Over 5 feet tall
- 17” BOE Color Monitor
- Dual Speakers for Crisp Arcade Sound
- Light Up Marquee
- Light-up Molded Faux Coin Door for Authentic Arcade Look
- WiFi Leaderboards to challenge the world!
- Upgraded Joystick and Light, Sleek Cabinet Design
- Metal Certificate of Authenticity Plaque

4. Setup & Assembly

Your ARCADE1UP machine requires assembly. It is recommended to have two people for assembly to ensure

proper and safe construction. Follow the detailed instructions provided in the packaging for step-by-step guidance. Ensure all parts are present before beginning assembly.





Figure 4.1: Fully assembled Ms. Pacman Deluxe Arcade Machine.



Figure 4.2: Machine dimensions (19 x 23 x 61 inches).

Once assembled, connect the power cable to the machine and then to a standard electrical outlet. The machine is designed for easy plug-and-play operation.

5. Operating Instructions

5.1 Power On/Off & Volume Control

Locate the power switch and volume controls on the control panel. Use these to turn the machine on or off and adjust the audio level to your preference.

5.2 Game Selection

Your arcade machine comes pre-loaded with 14 classic games. To select a game:

1. Press any button to start Ms. PAC-MAN.
2. Move the joystick up or down to navigate through the game list.
3. Press the 'Start Game' button to begin playing your selected game.



Figure 5.1: The 14 classic games included with your arcade machine.

5.3 Controls

The machine features an upgraded joystick and responsive buttons for an authentic arcade feel. The control panel is designed for intuitive gameplay.



Figure 5.2: Detailed view of the control panel with joystick and buttons.

5.4 WiFi Leaderboards

Connect your machine to Wi-Fi to access online leaderboards and compete with other players. Refer to the on-screen instructions for setting up your internet connection.

5.5 Light-Up Buttons & Marquee

The machine features light-up buttons and a lit marquee. These can be toggled on or off to customize your gaming experience and enhance the arcade aesthetic.

5.6 Returning to Main Menu / Resetting Game

To return to the main game selection menu from an active game, hold down the Player 1 button for 5 seconds. This action will also reset the current game.

6. Maintenance

To ensure the longevity and optimal performance of your arcade machine, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the cabinet and screen. Avoid abrasive cleaners or solvents that could damage the finish.
- **Dusting:** Regularly dust the machine, especially around vents and control areas, to prevent dust buildup.
- **Storage:** If storing the machine for an extended period, ensure it is in a dry, temperature-controlled environment.

7. Troubleshooting

If you encounter any issues with your ARCADE1UP machine, refer to the following common troubleshooting tips:

- **No Power:** Ensure the power cable is securely plugged into both the machine and a working electrical outlet. Check if the outlet is receiving power.
- **No Display:** Verify the machine is powered on. If the screen remains black, try restarting the machine.
- **Controls Unresponsive:** Ensure all connections are secure. If a joystick or button is sticking, gentle cleaning around the base may help. Avoid excessive force.
- **Sound Issues:** Check the volume controls on the machine. Ensure speakers are not obstructed.
- **Game Freezes:** Try holding the Player 1 button for 5 seconds to reset the game. If the issue persists, power cycle the machine.

For persistent issues not covered here, please contact customer support.

8. Specifications

Specification	Detail
Platform	Electronic Game
Controller Type	Joystick, Button Control
Item Weight	2 Pounds
Screen Size	17 Inches
Item Dimensions (L x W x H)	19 x 23 x 61 inches
Age Range (Description)	Adult (Manufacturer recommended: 14 years and up)
Display Type	LCD
Material	MDF
Form Factor	Stand Alone
UPC	195570020067
Manufacturer	ARCADE1UP

9. Warranty and Support

For any product inquiries, technical assistance, or warranty claims, please refer to the customer support information provided at the point of purchase or visit the official ARCADE1UP website. Keep your purchase receipt as proof of purchase for warranty purposes.

You can visit the ARCADE1UP Store on Amazon for more information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CR5QKX8K

More documents and user manuals: **https://manuals.plus/**