CIVYPRO BK-506

CIVYPRO Electric Foot Callus Remover (Model BK-506) Instruction Manual

Model: BK-506

1. Product Overview

The CIVYPRO Electric Foot Callus Remover is designed for effective and gentle removal of dead skin and calluses from your feet. This rechargeable device offers two speed settings and comes with a comprehensive pedicure kit for complete foot care.

What's Included:

- Electric Foot Callus Remover Unit
- 3 Replacement Roller Heads (1 pre-installed, 2 additional)
- USB Charging Cable
- Cleansing Brush
- 7-Piece Exfoliating Foot Care Kit (Callus Shaver, Callus Remover, Nail Brush, Nail File, Cuticle Remover, V-shaped Push Stick, Foot File)



Image 1.1: The CIVYPRO Electric Foot Callus Remover and its complete 13-in-1 pedicure kit.

2. Important Safety Information

- Read all instructions before use.
- Keep out of reach of children.
- Do not use on broken, irritated, or infected skin.
- Consult a physician if you have diabetes or poor circulation before using this device.
- Do not apply excessive pressure, as this may cause injury.
- This device is for personal use only.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

3. Setup

3.1 Charging the Device

1. Ensure the device is turned off before charging.
2. Connect the USB charging cable to the charging port on the device.
3. Plug the USB end into a compatible USB power source (e.g., wall adapter, computer, power bank).
4. The battery indicator on the device will show charging progress. A full charge takes approximately 3.5 hours and provides up to 300 minutes of use.



Image 3.1: The electric foot callus remover connected to a USB charging cable, showing various charging options.

3.2 Attaching/Replacing Roller Heads

1. Ensure the device is turned off.

2. To remove a roller head, press the release button on the side of the device and gently pull the roller head off.
3. To attach a new roller head, align it with the device and push until it clicks securely into place.
4. Choose from the three provided roller heads: Gentle Coarse (for daily maintenance), Regular Coarse (for dead skin), or Extra Coarse (for tough & hard calluses).



Image 3.2: The device with its three interchangeable quartz sand refill rollers, each designed for different levels of exfoliation.

4. Operating Instructions

1. **Prepare your feet:** For best results, ensure your feet are clean. The device can be used on both wet and dry feet.
2. **Turn on the device:** Press the power button once for low speed (1900 rpm). Press again for high speed (2200 rpm). The LED light will illuminate the area.
3. **Exfoliate:** Gently move the roller head over callused or dead skin areas. Do not apply excessive pressure. The device is designed to slow down or stop if too much pressure is applied, preventing injury.

4. **Check progress:** Periodically check your skin. Stop when desired smoothness is achieved.
5. **Turn off:** Press the power button a third time to turn off the device.



Image 4.1: The electric foot callus remover in action, highlighting the integrated LED light for improved visibility during use.

4.1 Speed Settings

The device features two scientific speed settings:

- **Low Speed:** 1900 rpm (Press power button once)
- **High Speed:** 2200 rpm (Press power button twice)



Image 4.2: Illustration of the two variable speed settings (1900 rpm and 2200 rpm) available on the device.

4.2 Using the Additional Pedicure Tools

The 7-piece foot care kit provides additional tools for comprehensive foot treatment. Use these tools as needed to further refine and care for your feet after using the electric callus remover.



Image 4.3: The complete pedicure set, including various manual tools for detailed foot care.

5. Maintenance

5.1 Cleaning the Device

The CIVYPRO Electric Foot Callus Remover is IPX7 waterproof, allowing for easy cleaning.

1. Ensure the device is turned off.
2. Remove the roller head.
3. Rinse the roller head and the device under running water.
4. Use the provided cleansing brush to remove any remaining skin particles from the roller head and device.
5. Allow all parts to air dry completely before reassembling or storing.

Your browser does not support the video tag.

Video 5.1: Official product video demonstrating the waterproof cleaning process of the CIVYPRO Electric Foot Callus Remover.

5.2 Roller Head Replacement

Replace roller heads when they show signs of wear or become less effective. Refer to section 3.2 for instructions on attaching/replacing roller heads.

6. Troubleshooting

Problem	Possible Cause	Solution
Device not turning on	Low battery or device is off.	Charge the device fully. Ensure the power button is pressed correctly.
Roller head stops during use	Excessive pressure applied.	Reduce pressure on the skin. The device has a safety mechanism to prevent injury.
Reduced effectiveness	Worn out roller head or clogged roller.	Clean the roller head or replace it with a new one.

7. Specifications

- **Model Number:** BK-506
- **Brand:** CIVYPRO
- **Material:** Plastic
- **Color:** Black
- **Item Weight:** 0.5 Kilograms
- **Power:** Electric, Rechargeable (1 AAA battery included)
- **Charging Time:** Approximately 3.5 hours
- **Service Time:** Up to 300 minutes
- **Waterproof Rating:** IPX7 (Whole Body Waterproof)
- **Speed Settings:** 1900 rpm (Low), 2200 rpm (High)

8. Warranty and Support

The CIVYPRO Electric Foot Callus Remover comes with a lifetime warranty and lifetime support. For any issues or inquiries regarding your product, please contact CIVYPRO customer service for satisfactory after-sales care.