DYNASONIC ALTAVOZ D30 2MIC

DYNASONIC D30 Wireless Outdoor Speaker User Manual

Model: ALTAVOZ D30 2MIC

Product Overview

The DYNASONIC D30 is a versatile wireless outdoor speaker designed for powerful sound and entertainment. It features Bluetooth connectivity, built-in LED lights, and support for Micro-SD and USB playback. This model includes two wireless microphones, making it ideal for karaoke and events. Its robust design and long-lasting battery ensure hours of enjoyment.

What's Included

- DYNASONIC D30 Wireless Outdoor Speaker
- 2 Wireless Microphones
- 1 Remote Control
- Charging Cable (not explicitly listed but implied for battery operation)

Key Features

- **Stereo Sound:** Powerful audio output with clear treble and defined bass, featuring stereo surround sound.
- **TWS Technology:** Allows connection of two speakers for simultaneous music playback and enhanced stereo experience.
- **Coloured LED Lights:** Integrated LED lights with various modes and colours that synchronize with music, creating an engaging atmosphere.
- **Large Capacity Battery:** Internal battery designed for extended music playback, with duration varying based on volume and LED light usage.
- **Multiple Connection Options:** Supports Bluetooth for fast, secure, and stable wireless connection, as well as wired connections via cable and USB.
- **Wireless Microphones:** Includes two wireless microphones with integrated fixed ECO effect for karaoke and vocal performances.
- **Remote Control:** Provides convenient control over speaker functions, including microphone and music volume adjustments, and sound effects.

Product Visuals



Figure 1: The DYNASONIC D30 Wireless Outdoor Speaker, shown with its two accompanying wireless microphones and remote control.



Figure 2: The DYNASONIC D30 speaker positioned with a single wireless microphone, illustrating its primary function as a karaoke Bluetooth speaker.



Figure 3: The DYNASONIC D30 speaker showcasing its vibrant color atmosphere lights, which can be adjusted to various RGB, dynamic, and switch modes.

Setup Guide

Unpacking

Carefully remove all components from the packaging. Inspect the speaker, microphones, and remote control for any signs of damage. Retain the packaging for future storage or transport.

Charging the Speaker

Before first use, fully charge the speaker's internal battery. Connect the provided charging cable to the speaker's charging port and to a suitable power source. The charging indicator will show the charging status and turn off or change color when fully charged.

Microphone Setup

The wireless microphones are pre-paired with the speaker. Ensure the microphones have batteries inserted (if required, check microphone compartment). Turn on the microphones; they should automatically connect to the speaker. Adjust microphone volume using the controls on the speaker or remote control.

Operating Instructions

Power On/Off

To power on the speaker, press and hold the power button located on the control panel. Repeat the action to power off the speaker.

Bluetooth Connection

1. Power on the DYNASONIC D30 speaker.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing light or audible prompt.
3. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select 'DYNASONIC D30' from the list of devices. Once connected, the speaker will provide an audible confirmation.
5. You can now play audio from your device through the speaker.



Figure 4: The DYNASONIC D30 speaker demonstrating its wireless Bluetooth connection capability with a smartphone.

USB/Micro-SD Playback

Insert a USB drive or Micro-SD card containing audio files into the respective port on the speaker. The speaker will automatically detect the media and begin playback. Use the speaker's controls or the remote control to navigate tracks and adjust volume.

Using the Microphones

Ensure the wireless microphones are powered on and connected to the speaker. Adjust the microphone volume using the dedicated controls on the speaker or the remote. The microphones feature an integrated ECO effect for enhanced vocal performance.



Figure 5: A user engaging in karaoke, singing into a wireless microphone with the DYNASONIC D30 speaker providing audio playback.

LED Light Modes

The speaker features dynamic LED lights. Use the dedicated light mode button on the speaker or remote control to cycle through various lighting effects, including RGB, dynamic patterns, and static colors. The lights can synchronize with the music.

TWS Function (True Wireless Stereo)

To use the TWS function, you need two DYNASONIC D30 speakers. Power on both speakers. On one speaker, press and hold the TWS pairing button (refer to speaker's control panel for exact button). The speakers will attempt to connect to each other. Once paired, connect your device via Bluetooth to the primary speaker, and audio will play in stereo across both units.

Remote Control Usage

The included remote control allows for convenient operation from a distance. Functions include power on/off, volume

control for both music and microphones, track navigation, mode selection (Bluetooth, USB, Micro-SD), and LED light control. Ensure the remote has working batteries and is pointed towards the speaker's sensor.



Figure 6: A hand operating the remote control, demonstrating its use for managing the DYNASONIC D30 speaker's functions.

Maintenance

Cleaning

Wipe the speaker's exterior with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not use abrasive cleaners, solvents, or immerse the speaker in water.

Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery periodically (e.g., every 3 months) to maintain its lifespan.

Battery Care

To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker when the low battery indicator appears. Do not expose the battery to high temperatures or attempt to disassemble it.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source and try again.

Problem	Solution
No sound from speaker.	Check speaker volume and source device volume. Ensure the correct input mode (Bluetooth, USB, etc.) is selected.
Bluetooth connection fails.	Ensure the speaker is in pairing mode. Turn off and on Bluetooth on your device. Move closer to the speaker (within 10m). Forget the device on your phone and re-pair.
Microphones not working.	Ensure microphones are powered on and have fresh batteries. Check microphone volume on the speaker/remote.
LED lights not functioning.	Press the light mode button on the speaker or remote to activate/change modes. Ensure speaker is powered on.

Technical Specifications

Feature	Detail
Brand	DYNASONIC
Model Name	ALTAVOZ D30 2MIC
Speaker Type	Outdoor
Connectivity Technology	Bluetooth, USB
Audio Output Mode	Surround, Stereo
Speaker Maximum Output Power	5 Watts
Frequency Response	12 KHz
Input Voltage	12 Volts
Mounting Type	Tabletop
Material	Plastic
Product Dimensions	21.3 x 19.5 x 42.5 cm
Item Weight	2.9 kg
Batteries	1 Lithium Ion battery (included)

Warranty and Support

DYNASONIC products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official DYNASONIC website. For technical support, troubleshooting assistance, or service inquiries, please contact DYNASONIC customer support through the contact information provided on the product packaging or the official website. Please have your model number (ALTAVOZ D30 2MIC) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question