**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Gourmet Easy 1

# Gourmet Easy 2-in-1 Electric Salt and Pepper Grinder Set Instruction Manual

Brand: Gourmet Easy | Model: 1

## 1. Introduction

Thank you for choosing the Gourmet Easy 2-in-1 Electric Salt and Pepper Grinder Set. This device is designed for convenient, one-handed seasoning, offering adjustable coarseness for various culinary needs. This manual provides essential information for the safe and efficient use of your new grinder.

## 2. Safety Information

- Read all instructions before use and retain for future reference.
- Keep the device away from water and other liquids. Do not immerse the grinder in water.
- Ensure the device is fully charged before first use.
- Keep out of reach of children.
- Use only the provided USB-C cable for charging.
- Do not attempt to disassemble or repair the grinder yourself. Contact customer support if issues arise.
- Avoid contact with moving parts during operation.

## 3. Package Contents

- 1 x Gourmet Easy 2-in-1 Electric Salt and Pepper Grinder
- 1 x USB Type-C Charging Cable
- 1 x Cleaning Brush
- 1 x Spice Scoop

## 4. Product Overview

The Gourmet Easy 2-in-1 Electric Salt and Pepper Grinder features a sleek design with two separate chambers for salt and pepper. It is constructed from durable stainless steel and includes a ceramic grinding core for efficient operation.




Figure 1: Overall view of the Gourmet Easy 2-in-1 Electric Salt and Pepper Grinder in Rose Gold.




Figure 2: Key features including the 2-in-1 design, durable ceramic grinding core, and adjustable coarseness mechanism.

### Components:

- **Top Cap:** Covers the charging port and operating button.
- **Operating Button (O):** Activates the grinding mechanism.
- **Transparent Chambers:** Two separate compartments for salt and pepper, allowing visibility of spice levels.
- **Adjustable Coarseness Knob:** Located at the bottom of each grinding mechanism to select grind size.
- **USB Type-C Port:** For recharging the internal battery.
- **LED Indicator Lights:** Shows charging status and illuminates during grinding.

## 5. Setup

### 5.1. Filling with Spices

1. Gently twist and pull the top and bottom sections of the grinder to separate the transparent spice chambers from the main body.
2. Using the provided spice scoop, fill each chamber with your desired spices (e.g., salt in one, pepper in the other) up to 80% capacity.
3. Align the chambers with the main body and twist them back into place until securely fastened.




Figure 3: The grinder's two chambers are easily accessible for filling.

### 5.2. Adjusting Coarseness

The grinder allows for adjustable coarseness from fine to coarse. To adjust:

- Locate the coarseness adjustment knob at the bottom of each grinding mechanism.
- Turn the knob clockwise for a finer grind.
- Turn the knob counter-clockwise for a coarser grind.

## 6. Operating Instructions

The Gourmet Easy Electric Grinder is designed for seamless one-handed operation.

1. Ensure the grinder is charged and filled with your desired spices.
2. Remove the protective cap from the bottom of the grinder.
3. Invert the grinder over your food.
4. Press and hold the operating button (O) located on the top of the grinder. The LED light will illuminate, and the grinding mechanism will activate.

5. Release the button to stop grinding.




Figure 4: One-handed operation with the LED light illuminating the grinding area.

## 7. Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your grinder.

- **Cleaning the Mechanism:** Use the provided cleaning brush to remove any residual spice particles from the grinding mechanism.
- **Wiping the Body:** Wipe the exterior of the grinder with a damp cloth. Do not use abrasive cleaners.
- **Avoid Water:** Do not expose the grinder to running water or immerse it in water, as this can damage the electronic components and battery.
- **Storage:** Store the grinder in a dry place when not in use.

## 8. Charging Instructions

The grinder is equipped with an integrated 750mAh lithium battery and charges via USB Type-C.

1. Locate the USB Type-C charging port on the top cap of the grinder.
2. Connect the provided USB Type-C cable to the grinder and a suitable power source (e.g., USB wall adapter, computer USB port).
3. The LED indicator light will show **red** while charging.
4. The LED indicator light will turn **white** when fully charged.
5. A full charge ensures extended use without frequent recharging.

## 9. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Grinder does not operate. | Low battery or no charge. | Charge the grinder using the USB-C cable until the indicator light turns white. |
| No spices are dispensed. | Chamber is empty or grinding mechanism is blocked. | Refill the spice chamber. Use the cleaning brush to clear any blockages in the grinding mechanism. |
| Grind size is inconsistent. | Coarseness setting needs adjustment. | Adjust the coarseness knob at the bottom of the grinder to your desired setting. |

## 10. Specifications

| Feature | Detail |
|---|---|
| Brand | Gourmet Easy |
| Model Number | 1 |
| Color | Rosegold |
| Product Dimensions | 6.35 x 6.35 x 22.61 cm |
| Capacity | 414 g |
| Material | Stainless Steel |
| Item Weight | 413 g |
| Battery | Integrated 750mAh Lithium Battery |
| Charging Port | USB Type-C |

## 11. Warranty and Support

This Gourmet Easy 2-in-1 Electric Salt and Pepper Grinder Set comes with a**2-Year Full Replacement Warranty**. For any product inquiries, technical support, or warranty claims, please contact Gourmet Easy customer service through the retailer's platform or visit the official Gourmet Easy store online.
Visit the Gourmet Easy Store for more information.

© 2026 Gourmet Easy. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0CRH22HXT**

More documents and user manuals: **https://manuals.plus/**