PINDOWS PDS-8007A

PINDOWS Digital Sports Watch PDS-8007A Instruction Manual

Model: PDS-8007A

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your PINDOWS Digital Sports Watch, model PDS-8007A. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your watch.

2. Product Overview

The PINDOWS PDS-8007A is a multi-functional digital sports watch designed for daily use and various activities. It features a durable construction and several useful functions.

2.1 Key Features

- Japanese Movement for accurate timekeeping.
- LED Backlight for visibility in low-light conditions.
- Alarm function.
- 12/24-hour time display system.
- Automatic Calendar.
- Hourly Chime.
- Stopwatch function.
- 50m Water Resistance (suitable for splashes, rain, and brief immersion, but not for diving or showering).
- Durable silicone band, ABS case, and scratch-resistant mineral glass.

2.2 Watch Components and Buttons

Familiarize yourself with the watch's buttons and display areas as shown in the diagram below.



Image 2.2.1: Front view of the PINDOWS PDS-8007A watch, indicating the Light, Start/Pause, Adjustment, and Mode buttons, along with the time display area.

- **LIGHT Button:** Activates the LED backlight.
- **START/PAUSE Button:** Used to start/stop functions like the stopwatch, or to increase values during setting.
- **ADJUSTMENT Button:** Used to reset functions or decrease values during setting.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch, etc.).
- **Time Display:** Shows the current time, date, and day of the week.

3. Setup

3.1 Setting Time and Date

1. From the normal time display mode, press the**MODE** button repeatedly until the seconds begin to flash. This indicates you are in time setting mode.

2. Press the **ADJUSTMENT** button to cycle through the setting options: seconds, hours, minutes, month, date, day of the week.
3. While an option is flashing, use the **START/PAUSE** button to increase the value or the **ADJUSTMENT** button to decrease it (if applicable).
4. To switch between 12-hour and 24-hour format, press the **START/PAUSE** button when the hour is flashing.
5. Once all settings are correct, press the **MODE** button to exit the setting mode and return to the normal time display.

4. Operating Instructions

4.1 Using the LED Backlight

To illuminate the watch display in low-light conditions, press the **LIGHT** button. The backlight will remain active for a few seconds.



Image 4.1.1: The watch display illuminated by the LED backlight, showing clear visibility in darkness.

4.2 Setting and Using the Alarm

1. From the normal time display, press the **MODE** button until "ALM" (Alarm) appears on the display. The alarm time will be shown.
2. Press the **ADJUSTMENT** button to make the hour digits flash.
3. Use the **START/PAUSE** button to set the desired alarm hour.
4. Press the **ADJUSTMENT** button again to make the minute digits flash.
5. Use the **START/PAUSE** button to set the desired alarm minutes.
6. Press the **MODE** button to exit alarm setting.
7. To turn the alarm ON/OFF, press the **START/PAUSE** button while in alarm mode (without flashing digits). An alarm icon will appear/disappear.
8. When the alarm sounds, press any button to stop it.

4.3 Using the Stopwatch

1. From the normal time display, press the **MODE** button until "STP" or "CHR" (Stopwatch/Chronograph) appears on the display.
2. Press the **START/PAUSE** button to start the stopwatch.
3. Press the **START/PAUSE** button again to pause the stopwatch.
4. To resume, press the **START/PAUSE** button.
5. To reset the stopwatch to zero, press the **ADJUSTMENT** button while the stopwatch is paused.
6. Press the **MODE** button to exit stopwatch mode.

4.4 Hourly Chime

The hourly chime feature provides an audible signal at the top of every hour. To activate or deactivate this feature, navigate to the alarm mode. While in alarm mode (and not in setting mode), press the **ADJUSTMENT** button to toggle the hourly chime ON/OFF. A small icon (often a bell or speaker) will indicate its status.

5. Maintenance

5.1 Water Resistance

Your PINDOWS PDS-8007A watch is rated for 50 meters (5 ATM) water resistance. This means it is suitable for everyday use, such as splashes, rain, and brief immersion in water. However, it is **not** suitable for diving, snorkeling, hot showers, or prolonged submersion. Avoid pressing buttons while the watch is wet or submerged to prevent water entry.



Image 5.1.1: The watch shown with water droplets, illustrating its 50m water resistance for everyday activities.

5.2 Cleaning Your Watch

To clean your watch, wipe it gently with a soft, damp cloth. Do not use chemical cleaners, solvents, or abrasive materials, as these can damage the watch case, band, or display. Ensure the watch is completely dry before storing or wearing.

5.3 Battery Replacement

The watch uses a Lithium Metal battery with an estimated lifespan of up to 3 years. When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery.
Time is incorrect.	Time not set correctly or accidental button press.	Refer to Section 3.1 "Setting Time and Date" to reset the time.
Alarm does not sound.	Alarm is turned off or set incorrectly.	Ensure the alarm is activated and the time is set correctly (refer to Section 4.2).
Water inside the watch.	Exceeded water resistance limits or buttons pressed underwater.	Immediately take the watch to a qualified technician for inspection and repair. Do not attempt to open it yourself.

7. Specifications

Feature	Detail
Model Number	PDS-8007A
Brand	PINDOWS
Movement	Japanese Quartz
Battery Type	1 Lithium Metal battery (included)
Water Resistance	50m (5 ATM)
Case Material	ABS
Band Material	Silicone (TPU)
Display Type	Digital with LED Backlight
Product Dimensions	4.3 x 4.3 x 1.3 cm
Weight	120 g
Band Width	18mm
Band Length (Wearing Size)	175mm to 226mm (6.9 to 8.9 inches)



Image 7.1.1: Diagram showing the dimensions and materials of the PINDOWS PDS-8007A watch.

8. Warranty and Support

PINDOWS offers a **12-month warranty** from the date of purchase against manufacturing defects. This warranty does not cover damage caused by improper use, accidents, unauthorized repairs, or normal wear and tear.

For warranty claims, technical support, or any inquiries regarding your PINDOWS watch, please contact our customer service. Details can typically be found on the retailer's website or the product packaging.

© 2024 PINDOWS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question