**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## ChooChoo ST2201-1TWL-LO

# ChooChoo 47" Farmhouse Console Table User Manual

Model: ST2201-1TWL-LO

## Product Overview

The ChooChoo 47" Farmhouse Console Table is designed to add a rustic vintage aesthetic to your living room or entryway. This versatile piece of furniture features a spacious top surface, a large drawer for concealed storage, and a decorative slatted bottom shelf for additional display or storage solutions. Its sturdy construction ensures durability for years of use.

- **Farmhouse Design:** White and wood grain finish for a charming farmhouse style.
- **Ample Storage:** Features one large drawer for discreet storage and a slatted bottom shelf for open storage.
- **Sturdy Construction:** Made with strong MDF board and X-Frame supports for enhanced stability.
- **Easy Assembly:** Designed for straightforward assembly with numbered parts and clear instructions.

## Important Safety Information

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always assemble the product according to the provided instructions.
- Do not overload the table, especially the drawer, to maintain its stability and longevity.
- Keep the table away from heat sources and moisture to prevent damage.
- Always supervise children when they are near the table to prevent accidents.
- For added stability, consider anchoring the table to the wall, especially in homes with children or pets.

## Parts List

Before beginning assembly, ensure all parts are present and undamaged. Refer to the assembly guide for detailed part identification.

- Console Table Components (e.g., Top Panel, Side Panels with X-supports, Bottom Shelf, Drawer components)
- Assembly Hardware (screws, dowels, cam locks, drawer glides, handles)
- Assembly Guide

*Note: An assembly tool is included, but additional tools like a Phillips head screwdriver may be required.*

## Setup and Assembly

Assembly of the ChooChoo Console Table is designed to be straightforward and can typically be completed within 30 minutes with the provided instructions and numbered parts. It is recommended to assemble the table on a soft, clean surface to prevent scratches.

### Step-by-Step Instructions:

1. **Unpack and Identify Parts:** Carefully unpack all components and hardware. Match each piece to the corresponding number or letter in the assembly guide.
2. **Assemble Side Frames:** Attach the X-supports to the side panels as indicated in the manual. Ensure all connections are secure.
3. **Attach Bottom Shelf:** Secure the slatted bottom shelf to the assembled side frames.
4. **Assemble Drawer:** Construct the drawer box. Pay close attention to the orientation of the drawer glides and ensure the lock nuts are inserted with the slot facing outwards for potential adjustment. The drawer is a single, long unit, not two separate drawers.
5. **Install Drawer Glides:** Carefully attach the drawer glides to both the drawer and the table frame. Verify that the correct screw holes are used to ensure the drawer slides in flush with the table front.
6. **Attach Top Panel:** Secure the top panel to the assembled frame.
7. **Install Handles:** Attach the retro-style handles to the drawer front. Ensure they are oriented correctly.
8. **Final Check:** Once assembled, gently lift and move the table to its desired location. Verify all connections are tight and the table is stable.




**Image Description:** This image displays close-up details of the ChooChoo console table. It highlights the retro-style handle on the drawer, the classic X-shaped support design on the side panels, and demonstrates the large, single drawer opened to reveal its storage capacity. These features are crucial for understanding the table's design and assembly.




**Image Description:** This image provides a detailed diagram of the ChooChoo console table with its key dimensions labeled. The table measures 47.24 inches in width, 11.81 inches in depth, and 31.50 inches in height. The drawer front is 3.8 inches high. This visual aid is essential for planning placement and understanding the table's physical size.

## Operating Instructions

The ChooChoo Console Table is designed for versatile use in various living spaces.

- **Display Surface:** Use the spacious top surface to display decorative items, lamps, photo frames, or other personal belongings.
- **Drawer Storage:** Utilize the large, single drawer for out-of-sight storage of small items such as keys, remote controls, stationery, or personal accessories.
- **Bottom Shelf:** The slatted bottom shelf provides additional space for baskets, books, plants, or other decorative elements.
- **Placement:** Ideal for entryways, hallways, living rooms, or behind a sofa.

## Maintenance and Care

Proper care will help maintain the appearance and longevity of your console table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood grain finish.
- **Heat and Moisture:** Do not place hot items directly on the surface. Use coasters or protective pads. Keep away from

excessive moisture.

- **Hardware Check:** Periodically check and tighten all screws and fasteners to ensure the table remains stable.

## Troubleshooting

If you encounter any issues with your ChooChoo Console Table, refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Table is wobbly or unstable. | Loose fasteners or uneven assembly. | Ensure all screws, cam locks, and other fasteners are fully tightened. Check that the table is on a level surface. If not, use furniture pads to level. |
| Drawer does not slide smoothly or is not flush. | Incorrect installation of drawer glides or lock nuts. | Re-check the assembly instructions for drawer glide placement and screw holes. Ensure lock nuts are inserted with the slot facing out for proper engagement. Adjust as needed. |
| Missing parts or damaged components. | Manufacturing error or shipping damage. | Contact ChooChoo customer service immediately for assistance. Provide your model number and details of the missing/damaged parts. |

## Specifications

| | |
|---|---|
| **Brand** | ChooChoo |
| **Model Name** | ST2201 |
| **Model Number** | ST2201-1TWL-LO |
| **Product Dimensions (D x W x H)** | 11.8"D x 47.19"W x 31.5"H |
| **Item Weight** | 37.37 Pounds |
| **Color** | White |
| **Style** | Farmhouse |
| **Material Type** | Engineered Wood |
| **Number of Drawers** | 1 |
| **Number of Shelves** | 1 |
| **Recommended People for Assembly** | 1 |
| **Indoor/Outdoor Usage** | Indoor |

## Customer Support

ChooChoo is committed to providing excellent customer service. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact us. We aim to respond to all inquiries within 24 hours.
For support, please visit the ChooChoo Store on Amazon or refer to your purchase documentation for direct contact information.

© 2024 ChooChoo. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0CRKC2ZDV**

More documents and user manuals: **https://manuals.plus/**