Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sherilyn SDEG

Sherilyn Twin Bed Tent Instruction Manual

Model: SDEG | Brand: Sherilyn

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sherilyn Twin Bed Tent. Please read this manual thoroughly before use to ensure proper setup and safe operation. Keep this manual for future reference.

2. Safety Information

- Adult supervision is recommended during assembly and initial use.
- Keep the tent away from open flames, heaters, and other heat sources.
- Ensure all poles are securely connected and inserted into the fabric sleeves to prevent collapse.
- Regularly inspect the tent for any signs of wear or damage. Discontinue use if damaged.
- Do not hang heavy objects from the tent structure.
- Keep small parts, such as pole connectors, away from young children to prevent choking hazards.

3. Package Contents

Please verify that all the following components are included in your package:

- 1 x Bed Tent Cover (Polyester Cotton)
- 2 x Sets of Fiberglass Poles
- 1 x Pennant Banners
- 1 x String Lights (Battery/USB operated)



Figure 1: All components included in the Sherilyn Twin Bed Tent package.

4. Setup and Assembly

The Sherilyn Twin Bed Tent is designed for easy assembly. Follow these steps for a quick setup:

1. **Prepare the Poles:** Connect the fiberglass pole segments to form two long, flexible poles. Ensure all segments are firmly joined.
2. **Insert Poles into Tent Sleeves:** Lay the tent fabric flat. Carefully slide each assembled pole through the designated fabric sleeves on the tent cover. Ensure the poles are inserted correctly into both the lower and upper sleeves as indicated in the diagram below.
3. **Form the Arch:** Gently bend the poles to create the arched shape of the tent. Secure the ends of the poles into the corner pockets or loops on the tent base.
4. **Secure the Tent:** Place the assembled tent over your twin mattress or on the floor. Use the integrated straps or ties to secure the tent to the mattress or bed frame, ensuring stability.

5. **Attach Decorations:** Tie the pennant banners to the loops inside the tent. Drape the string lights along the interior poles or fabric, securing them with the provided ties or clips. Insert batteries into the string light battery pack or connect via USB.



Figure 2: Detailed view of pole insertion during assembly.

Assembly Videos

Your browser does not support the video tag.

Video 1: Easy to build, easy to store. This video demonstrates the simple assembly process for the bed tent.

Your browser does not support the video tag.

Video 2: Twin bed tent assembly. A quick guide to setting up your twin bed tent.

Your browser does not support the video tag.

Video 3: Blackout bed tent installation. This video provides step-

by-step instructions for installing the blackout bed tent.

Your browser does not support the video tag.

Video 4: Bed Tent Installation Guide for Twin and Full Size Mattress. A comprehensive guide for installing the bed tent on various mattress sizes.

Your browser does not support the video tag.

Video 5: Toddlers Twin Bed Tent Canopy: with Lights & Flag for Girls. This video showcases the tent's features and assembly, including lights and flags.

5. Operating Instructions

Your Sherilyn Twin Bed Tent offers several features for comfort and privacy:

- **Doors:** The tent features two doors for easy entry and exit. These can be rolled up and secured with the attached ties to keep them open, or left down for privacy.
- **Windows:** Two mesh windows are located on the sides for ventilation. Each window has a roll-up cover that can be secured with ties to allow airflow or kept down for blackout and privacy.
- **String Lights:** The included string lights can be powered by batteries (not included) or via a USB connection. Use the ties inside the tent to position the lights as desired.



Figure 3: Interior view of the tent, showing a mesh window with its cover rolled up.



Figure 4: Children enjoying the tent, illustrating the interior space and lighting.

6. Care and Maintenance

To ensure the longevity of your Sherilyn Twin Bed Tent, please follow these care instructions:

- **Cleaning:** The tent fabric is machine washable. Use cold water on a gentle cycle. Do not bleach. Tumble dry low or hang to dry.
- **Storage:** When not in use, disassemble the tent and store all components in the provided carry bag in a cool, dry place.
- **Poles:** Avoid bending the fiberglass poles excessively to prevent breakage.

7. Troubleshooting

If you encounter any issues with your Sherilyn Twin Bed Tent, please refer to the following common solutions:

- **Tent not standing upright:** Ensure all pole segments are fully connected and correctly inserted into the fabric sleeves and base pockets.
- **Lack of stability:** Verify that the tent is properly secured to the mattress or floor using all available straps/ties.
- **String lights not working:** Check if batteries are correctly inserted and charged, or if the USB connection is secure. Ensure the power switch is in the 'ON' position.

If the problem persists, please contact Sherilyn customer support for assistance.

8. Specifications

Feature	Specification
Product Dimensions	77.16"L x 37.8"W x 51.18"H
Item Weight	4.65 pounds (2.11 Kilograms)
Material	Polyester Cotton
Color	Twin Grey
Assembly Required	Yes
Estimated Assembly Time	3 Minutes
Included Components	Bed Tent Cover, Pennant Banners, Poles
Manufacturer	Sherilyn
Model Number	SDEG

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Sherilyn customer service directly. Contact details can typically be found on the manufacturer's website or through your point of purchase.

© 2023 Sherilyn. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRNPY3NV

More documents and user manuals: **https://manuals.plus/**