Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anchilly JIABEN Switch

Anchilly JIABEN Switch Instruction Manual

For WORX WG309 Electric Pole Saw/Chainsaw

Model: JIABEN Switch | **Brand:** Anchilly

1. Safety Information

Read and understand all safety instructions before installing or operating the switch. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always disconnect the power source from the tool before attempting any installation, maintenance, or repair.
- Ensure the replacement switch matches the specifications of the original switch and the tool.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, during installation.
- If you are unsure about any part of the installation process, consult a qualified electrician or service technician.
- Keep children and bystanders away from the work area.

2. Product Overview

The Anchilly JIABEN Switch is a replacement power switch designed for compatibility with the WORX WG309 2-in-1 Electric Pole Saw and Chainsaw. This switch controls the power supply to the motor, enabling the tool's operation.



Image showing the Anchilly JIABEN Switch, a replacement component for the WORX WG309 2-in-1 Electric Pole Saw and Chainsaw. The switch features a black housing with electrical ratings and certifications visible on its side.

3. Setup and Installation

This section outlines the general steps for replacing a power switch. Specific disassembly and reassembly procedures for the WORX WG309 may vary. Always refer to the original WORX WG309 manual for detailed instructions on accessing and replacing internal components.

1. **Disconnect Power:** Unplug the WORX WG309 electric pole saw/chainsaw from the power outlet. This is a critical safety step.
2. **Access Old Switch:** Carefully disassemble the tool's housing to gain access to the existing power switch. This may involve removing screws and separating plastic casings.
3. **Note Wiring:** Before disconnecting, take a clear photograph or make a diagram of the wiring connections to the old switch. Note which wires connect to which terminals.
4. **Remove Old Switch:** Disconnect the wires from the old switch and remove it from its mounting.
5. **Install New Switch:** Position the new Anchilly JIABEN Switch in the same location as the old one. Connect the wires to the new switch's terminals according to your diagram or photograph. Ensure all connections are secure.
6. **Reassemble Tool:** Carefully reassemble the tool's housing, ensuring all screws are tightened and no wires

are pinched.

7. **Test Functionality:** Plug the tool back into a power outlet and perform a brief functional test to ensure the switch operates correctly (on/off).

4. Operating Instructions

The Anchilly JIABEN Switch functions as a standard power switch for your WORX WG309 tool. Press the switch to the 'ON' position to supply power to the motor and operate the tool. Press it to the 'OFF' position to cut power and stop the tool. Always ensure the switch is fully engaged in either the 'ON' or 'OFF' position.

5. Maintenance

The JIABEN Switch is designed for durability and requires minimal maintenance. However, regular inspection can help ensure its longevity and safe operation.

- **Visual Inspection:** Periodically inspect the switch for any signs of physical damage, cracks, or loose connections.
- **Cleanliness:** Keep the switch area free from dust, debris, and moisture. Use a dry, soft cloth for cleaning. Do not use liquids or solvents.
- **Functionality Check:** Ensure the switch operates smoothly and provides a clear 'click' or tactile feedback when pressed. If the switch feels sticky or unresponsive, it may need replacement.

6. Troubleshooting

If you experience issues with your tool after replacing the switch, consider the following troubleshooting steps:

Problem	Possible Cause	Solution
Tool does not turn on.	No power to the tool. Incorrect wiring. Faulty switch.	Check power outlet and cord. Re-check wiring connections against diagram. Test switch continuity with a multimeter (if experienced).
Tool turns on intermittently.	Loose wiring connection. Internal switch fault.	Ensure all wires are securely connected. Replace the switch.
Switch feels stiff or stuck.	Debris in switch mechanism. Internal mechanical failure.	Clean switch area. Replace the switch.

If problems persist after troubleshooting, discontinue use and consult a qualified service technician.

7. Specifications

Feature	Specification
Model	JIABEN Switch

Feature	Specification
Compatibility	WORX WG309 2-in-1 Electric Pole Saw & Chainsaw
Rated Voltage (AC)	125VAC / 250VAC
Rated Current (AC)	8A (at 125VAC) / 12A (at 250VAC)
Certifications	TUV, CE, CQC, cURus (as per image OCR)
UPC	635393231023
Item Weight	0.634 ounces (approx.)
Package Dimensions	2.95 x 2.05 x 1.69 inches (approx.)

8. Warranty and Support

For warranty information and customer support regarding your Anchilly JIABEN Switch, please refer to the purchase documentation or contact the retailer from whom the product was purchased. Keep your proof of purchase for any warranty claims.

For technical assistance or further inquiries, please contact Anchilly customer service through their official channels, if available, or the seller directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRPF6DWH

More documents and user manuals: **https://manuals.plus/**