Move2Play N_KSK.101

Move2Play Kids Karaoke Microphone

Model: N_KSK.101 | Brand: Move2Play

Introduction

This manual provides essential information for the safe and effective operation of your Move2Play Kids Karaoke Microphone. Please read these instructions thoroughly before use and retain them for future reference.

Safety Information

- Do not expose the device to water or excessive moisture.
- Avoid dropping or subjecting the device to strong impacts.
- Keep out of reach of very young children without adult supervision.
- Use only the provided Micro-USB charging cable.
- Do not attempt to disassemble or repair the device yourself.
- Ensure proper ventilation during charging.

Package Contents

- 1x Move2Play Kids Karaoke Microphone
- 1x Micro-USB Charging Cable
- 1x Rechargeable Battery (pre-installed)
- Pre-loaded Songs

Product Features

- **Pre-Loaded Songs:** Includes 15 popular nursery rhymes and children's songs.
- **Bluetooth Connectivity:** Connects wirelessly to smartphones or tablets for playing custom music.

- **Voice Effects:** Features 4 distinct voice-altering effects.
- **Echo Effect:** Adjustable echo for enhanced vocal performance.
- **High-Quality Sound:** Integrated acoustic speakers provide clear audio.
- **Rechargeable Battery:** Offers over 6 hours of continuous playtime on a single charge.
- **Durable Design:** Constructed from plastic for child-friendly use.

Product Overview

Familiarize yourself with the microphone's components and controls:



Image: Front view of the Move2Play Kids Karaoke Microphone, highlighting the control panel.

Control Panel Description:

- **Power Button (Center Top):** Press and hold to power on/off. Quick press to switch modes (Bluetooth/Pre-loaded songs).
- **Play/Pause Button (Center):** Controls playback of music.
- **Previous/Next Track Buttons (Left/Right of Play/Pause):** Skips between songs.
- **Volume Up/Down Buttons (Right Side):** Adjusts the overall music volume.
- **Mic Volume Slider (Bottom Left):** Adjusts the microphone's vocal output volume.
- **Voice FX Button (Center Below Play/Pause):** Cycles through 4 different voice effects.
- **Echo Slider (Bottom Right):** Adjusts the intensity of the echo effect.
- **USB Port (Bottom):** For charging and connecting external devices.
- **AUX Port (Bottom):** For wired audio input.

Setup

1. Charging the Microphone

Before first use, fully charge the microphone. Connect the Micro-USB charging cable to the USB port at the bottom of the microphone and the other end to a compatible USB power adapter (not included).

- A charging indicator light will illuminate during charging.
- The light will turn off or change color when fully charged.
- A full charge provides approximately 6 hours of playtime.

2. Powering On/Off

Press and hold the Power Button (center top) for a few seconds until you hear an audible prompt indicating the device is powering on or off.

3. Bluetooth Pairing

1. Ensure the microphone is powered on and in Bluetooth mode (indicated by a voice prompt).
2. On your smartphone or tablet, navigate to the Bluetooth settings.
3. Search for available devices and select "Kids Star" (or similar name) from the list.
4. Once connected, you will hear a confirmation tone.

Operating Instructions

1. Playing Pre-Loaded Songs

The microphone comes with 15 pre-loaded children's songs. To access these:

- Ensure the microphone is powered on.
- If in Bluetooth mode, quick press the Power Button to switch to pre-loaded song mode.
- Use the Previous/Next Track buttons to select a song.
- Press the Play/Pause button to start or stop playback.



Image: A visual list of some of the 15 pre-loaded songs available on the microphone.

2. Playing Songs via Bluetooth

Once paired with your device:

- Open your preferred music streaming app (e.g., Spotify, YouTube, Apple Music) on your connected device.
- Select and play any song. The audio will stream through the microphone's speakers.
- Use the Play/Pause and Previous/Next Track buttons on the microphone to control playback.



Image: The microphone demonstrating Bluetooth connectivity with a smartphone and popular music apps.

3. Adjusting Volume

- **Music Volume:** Use the Volume Up/Down buttons on the right side of the control panel.
- **Microphone Volume:** Use the Mic Volume slider on the bottom left to adjust your vocal output.

4. Using Voice Effects and Echo

Enhance your singing with special effects:

- **Voice Effects:** Press the Voice FX button (center below Play/Pause) to cycle through 4 different voice-altering effects (e.g., high-pitched, low-pitched).
- **Echo Effect:** Use the Echo slider on the bottom right to increase or decrease the echo intensity.



Image: Illustration of the microphone's voice effects, including high-pitched, low-pitched, monster voice, and echo.

5. Official Product Video

Video: An official product video from Move2Play demonstrating the Kids Karaoke Microphone in use.

Maintenance

1. Cleaning

Wipe the microphone with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.

2. Storage

Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.

3. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

Troubleshooting

- **No Power:** Ensure the microphone is fully charged. Press and hold the Power Button for several seconds.
- **No Sound:** Check both the microphone volume and the main music volume. Ensure the device is properly connected via Bluetooth or in pre-loaded song mode.
- **Bluetooth Disconnection:** Ensure the microphone is within range of the paired device. Try unpairing and re-pairing the device.
- **Distorted Sound:** Reduce the volume of both the microphone and music. Ensure the microphone is not too close to the mouth or other sound sources.

Specifications

Feature	Detail
Microphone Form Factor	Handheld
Item Dimensions (L x W x H)	6 x 6 x 6 inches
Power Source	Battery Powered
Number of Batteries	1 Lithium Ion (included)
Material	Plastic
Signal-to-Noise Ratio	50 dB
Hardware Platform	Karaoke Machine, Tablet
Item Weight	11.3 ounces
Model Name	N_KSK.101
Connectivity Technology	Bluetooth
Special Feature	Rechargeable
Included Components	Karaoke Microphone, Micro-USB Charging Cable, Rechargeable Battery, Songs

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Move2Play customer service directly. Keep your purchase receipt as proof of purchase.