Move2Play N_KSK.104

Move2Play Kids Karaoke Microphone Instruction Manual

Model: N_KSK.104

Brand: Move2Play

Introduction

This manual provides essential information for the safe and effective use of your Move2Play Kids Karaoke Microphone. Please read it thoroughly before operating the device and retain it for future reference.



Figure 1: Move2Play Kids Karaoke Microphone. This image displays the microphone in a pink and purple color scheme, highlighting its design and the 'Pre-Loaded with 15 Kid Songs' feature.

The Move2Play Kids Karaoke Microphone is designed for interactive entertainment, featuring pre-loaded songs, Bluetooth connectivity, and various voice effects. It is equipped with quality acoustic speakers for clear sound output and a rechargeable battery for extended playtime.

Setup

Charging the Microphone

Before first use, fully charge the microphone. The device uses a Lithium Ion battery and can provide up to 6 hours of playtime on a full charge.

1. Locate the charging port on the microphone.
2. Connect the provided charging cable to the microphone and a compatible USB power source.
3. The indicator light will show charging status (refer to specific light behavior in the user manual for details).
4. Once fully charged, disconnect the cable.

Bluetooth Pairing

The microphone can connect wirelessly to your smartphone or tablet via Bluetooth to play music from various streaming services.

1. Press and hold the power button on the microphone until you hear an audible prompt indicating Bluetooth mode.
2. On your mobile device, navigate to the Bluetooth settings.
3. Search for available devices and select 'Motown Magic' or a similar identifier (e.g., 'WS-868').
4. Confirm pairing on your device if prompted. The microphone will indicate successful connection.



Figure 2: Bluetooth Connectivity. This image illustrates the microphone's ability to connect wirelessly to a smartphone, enabling music playback from various apps.

Operating Instructions

Basic Controls

- **Power Button:** Press and hold to turn the microphone ON/OFF. Short press to switch between modes (Bluetooth, pre-loaded songs).
- **Volume Control (Music):** Use the 'Vol+' and 'Vol-' buttons to adjust the volume of the background music.
- **Microphone Volume:** Use the 'Mic Vol' slider to adjust the microphone's output volume.
- **Previous/Next:** Use the 'Prev' and 'Next' buttons to skip between pre-loaded songs or tracks played via Bluetooth.
- **Play/Pause:** Use the 'Play/Pause' button to start or stop music playback.

Voice Effects

The microphone includes 4 voice effects to enhance the karaoke experience.

- **Voice FX Button:** Press to cycle through different voice effects (e.g., high-pitched, low-pitched, monster voice).
- **Echo Control:** Use the 'Echo' slider to adjust the echo intensity of your voice.



Figure 3: Voice Effects. This image highlights the microphone's voice-altering capabilities, including high-pitched, low-pitched, monster voice, and echo effects.

Pre-Loaded Songs

The microphone comes pre-loaded with 15 popular nursery rhymes and children's songs.

- Wheels On The Bus
- Row Your Boat
- Old MacDonald
- ABCs
- Comin' Round The Mountain
- Twinkle Twinkle Little Star
- Take Me Out To The Ball Game
- Wish You A Merry Christmas
- Jingle Bells
- Happy Birthday Song
- And More!



Figure 4: Pre-Loaded Songs. This image displays a list of the 15 pre-loaded children's songs available on the microphone.

Maintenance

Cleaning

Wipe the microphone with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

Storage

Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **No Sound:** Ensure the microphone is powered on and the volume levels for both the microphone and music are adjusted. Check Bluetooth connection.
- **Bluetooth Not Connecting:** Ensure Bluetooth is enabled on your device and the microphone is in pairing mode. Try restarting both devices.
- **Short Battery Life:** Ensure the microphone is fully charged using the provided cable and a compatible power source.

Specifications

Feature	Detail
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)
Material	Plastic
Signal-to-Noise Ratio	55 dB
Hardware Platform	Karaoke Machine, Tablet
Number of Channels	1
Product Dimensions	7 x 3 x 3 inches
Item Weight	10.8 ounces
Item Model Number	N_KSK.104
Recommended Uses	Karaoke
Connectivity Technology	Bluetooth
Connector Type	3.5 mm Jack
Special Feature	Volume Control
Compatible Devices	Voice Recorder
Color	Pink/Purple
Polar Pattern	Unidirectional
Microphone Form Factor	Handheld

Official Product Videos

Kids Karaoke Demo Video

This video provides a demonstration of the Kids Karaoke Microphone in action, showcasing its features and sound quality. It offers a visual guide to the product's functionality.

Move2Play Karaoke Microphone Overview

This video offers an overview of the Move2Play Karaoke Microphone, detailing its design, controls, and how it can be used for entertainment.

Warranty and Support

This product is from a small business brand. For support or warranty information, please refer to the contact details provided with your purchase or visit the official Move2Play store on Amazon.

Visit the Move2Play Store for more information.

© 2025 Move2Play. All rights reserved.