Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

amseatec LY-5067-H

amseatec Executive Leather Office Chair Model LY-5067-H Instruction Manual

Model: LY-5067-H | Brand: amseatec

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your amseatec Executive Leather Office Chair, Model LY-5067-H. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your chair.
Key features of your chair include:

- High-quality PU leather upholstery for durability and easy cleaning.
- Adjustable flip-up armrests for versatile use and space-saving.
- Ergonomic design with lumbar support to enhance comfort during extended use.
- Adjustable seat height and backrest recline (90° to 115°) with rocking function.

2. Safety Information

Important Safety Warnings:

- The maximum weight recommendation for this chair is **300 pounds (136 kg)**. Do not exceed this limit to prevent injury or product damage.
- Ensure the chair is stable and does not tip over during use. Avoid sudden movements or leaning excessively.
- Keep hands and fingers clear of moving parts during adjustment.
- Do not stand on the chair.
- Regularly check all bolts and screws to ensure they are tightened. Retighten if necessary.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Backrest
- Seat Cushion

- Armrests (2)
- Mechanism Plate
- Gas Lift Cylinder
- Gas Lift Cover
- Star Base
- Casters (5)
- Hardware Pack (screws, washers, Allen wrench)

4. Assembly Instructions

Assembly typically takes approximately 20 minutes. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

Step 1: Attach Casters to Star Base

Insert each of the five casters into the holes at the end of the star base until they click securely into place.



Image: Fully assembled amseatec Executive Leather Office Chair in black, showcasing its design and flip-up armrests. This image represents the final product after assembly.

Step 2: Install Gas Lift

Place the gas lift cylinder into the center hole of the assembled star base. Cover the gas lift with the telescopic plastic cover.

Step 3: Attach Mechanism Plate to Seat Cushion

Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism plate faces the front of the seat. Secure with screws using the provided Allen wrench.

Step 4: Attach Armrests to Seat Cushion and Backrest

Attach the armrests to the sides of the seat cushion and then to the backrest. It may be helpful to partially tighten all screws before fully tightening them to allow for minor adjustments and alignment.



Image: Close-up of a chair armrest, illustrating the soft padding and stitching. This detail is relevant for attaching the armrests.

Step 5: Connect Seat Assembly to Gas Lift

Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the tapered end of the gas lift fits securely into the mechanism plate.

5. Operating Instructions

5.1. Seat Height Adjustment

To adjust the seat height, lift the lever located on the right side of the chair (when seated). To raise the seat, lift the lever while taking your weight off the seat. To lower the seat, lift the lever while remaining seated.

5.2. Backrest Recline and Rocking Function

The chair's backrest can recline from 90° (upright for work) to 115° (relaxed for rest). Pull out the lever on the left side of the chair to activate the rocking function. Push the lever in to lock the backrest in an upright position. The resistance knob underneath the seat can be turned to adjust the tension of the rocking motion.



Image: Diagram illustrating the backrest recline from 90° to 115° and the location of the resistance knob and rocking function lever for adjustment.



Image: A person relaxing in the reclined office chair with feet up, demonstrating the chair's comfort in a relaxed position.

5.3. Flip-Up Armrests

The armrests can be flipped up by rotating them 90 degrees upwards. This feature allows for easy storage under desks or provides more space when not needing arm support.



Image: Illustration showing the 90-degree flip-up motion of the armrest, highlighting its space-saving benefit.

6. Maintenance

To ensure the longevity and appearance of your amseatec office chair, follow these maintenance guidelines:

- **Cleaning:** The PU leather upholstery is designed for easy cleaning. Wipe surfaces with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts for tightness. Retighten as needed to maintain stability and prevent squeaks.
- **Casters:** Keep casters free of hair and debris to ensure smooth rolling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack.

7. Troubleshooting

If you encounter any issues with your chair, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Chair Squeaks	Loose bolts or components.	Tighten all assembly bolts, especially those connecting the seat, backrest, and mechanism plate.
Chair Does Not Adjust Height	Gas lift malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement. Contact customer support.
Casters Not Rolling Smoothly	Debris caught in casters.	Turn the chair over and remove any hair, dust, or debris from the caster wheels.
Backrest Does Not Recline/Lock	Recline lever not engaged or mechanism issue.	Ensure the recline/rocking lever is correctly positioned (pulled out for rocking, pushed in for locked upright). Check the resistance knob for proper tension adjustment.

8. Specifications

Brand	amseatec
Model Name	LY-5067-H
Color	Black
Product Dimensions (D x W x H)	23.62"D x 25.59"W x 42.52"H
Item Weight	33.3 pounds (15.1 kg)
Maximum Weight Recommendation	300 Pounds (136 kg)
Material	PU Leather, High-Density Foam, Sturdy Planks, Stainless Steel Base
Special Features	Adjustable Height, Flip-Up Armrests, Lumbar Support, Rocking Function
Seat Height Range	16 - 19 inches (approximate, based on typical adjustable range)
Backrest Recline Angle	90° to 115°

UPC	761729110882



Image: Detailed diagram showing the product dimensions including height, width, and depth of the chair.

9. Warranty and Support

Your amseatec Executive Leather Office Chair is backed by a comprehensive warranty and dedicated customer support.

- **Warranty:** The chair comes with a **1-year warranty** covering manufacturing defects. Additionally, amseatec offers a **5-year warranty** on mechanical parts, reflecting our commitment to quality and durability.
- **Customer Service:** For any questions, concerns, or assistance with assembly or operation, please contact our customer service team via email. We also offer 24/7 text support for your convenience.
- **Contact Information:** Please refer to the contact details provided with your purchase or visit the official amseatec website for support.

© 2025 amseatec. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRPY9T2T

More documents and user manuals: **https://manuals.plus/**