Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pelican TX80

Pelican Adventure Overland Case TX80 User Manual

Model: TX80 | Brand: Pelican

1. Introduction

This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your Pelican Adventure Overland Case TX80. Designed for durability and versatility, this weather-resistant case is ideal for protecting your gear during various activities, from overland adventures to general storage and transport.

The Pelican Adventure Overland Case TX80 features a heavy-duty rubber seal for water and dust resistance, steel latches with built-in lock hasps for security, and tie-down plates for vehicle attachment. It includes a removable inner tray for organized storage and molded-in handles for easy transport.



Image 1.1: The Pelican Adventure Overland Case TX80 in OD Green, shown closed from an angled front view. This image highlights the robust construction and secure latches of the case.

2. Setup

Upon receiving your Pelican Adventure Overland Case TX80, follow these steps to prepare it for use:

1. **Unpacking:** Carefully remove the case and all components from its packaging. Inspect for any signs of damage during transit.
2. **Lid Hinge Installation (if applicable):** In some instances, lid hinges may be packaged separately. If your case requires hinge installation, locate the included hardware and securely attach the hinges to the designated points on the lid and base. Ensure all screws are tightened appropriately.
3. **Inner Tray Placement:** The case includes a removable inner tray for organizing smaller items. Place this tray inside the main compartment as desired. It can be easily removed for access to the space below or for cleaning.
4. **Initial Inspection:** Verify that the heavy-duty rubber seal around the lid is properly seated and free from obstructions to ensure optimal weather resistance. Check that the steel latches operate smoothly.



Image 2.1: The Pelican Adventure Overland Case TX80 shown open, revealing the spacious interior and the removable inner tray. This demonstrates the case's organizational capabilities.

3. Operating Instructions

The Pelican Adventure Overland Case TX80 is designed for straightforward and secure operation:

- **Opening the Case:** To open, disengage the two steel latches located on the front of the case. Lift the lid upwards. The lid-stay hinges will hold the lid open for easy access.
- **Closing the Case:** Lower the lid until it rests firmly on the base. Engage both steel latches by pressing them down until they click into place. Ensure the rubber seal is not pinched.
- **Securing Contents:** The steel latches include built-in lock hasps. For added security, you can attach padlocks (not included) through these hasps.
- **Using the Inner Tray:** The removable inner tray can be used to separate smaller items from the main compartment. It can be lifted out for full access to the case's depth.

- **Transporting the Case:** Utilize the molded-in handles on the sides of the case for comfortable and secure carrying.
- **Vehicle Attachment:** The case features tie-down plates designed for securing it to a vehicle. Use appropriate straps or cords (not included) through these plates to prevent movement during transit.



Image 3.1: A person kneeling beside an open Pelican Adventure Overland Case TX80, reaching inside to access items. This illustrates the practical use and accessibility of the case's interior.

4. Maintenance

Regular maintenance ensures the longevity and performance of your Pelican Adventure Overland Case TX80:

- **Cleaning:** Clean the exterior and interior of the case with mild soap and water. Avoid abrasive cleaners or solvents that could damage the plastic material. Rinse thoroughly and allow to air dry.
- **Seal Inspection:** Periodically inspect the heavy-duty rubber seal around the lid for any cracks, tears, or debris. A clean, intact seal is crucial for maintaining weather resistance. Clean the seal with a damp cloth if necessary.
- **Latch Functionality:** Ensure the steel latches operate smoothly. If they become stiff, a small amount of silicone-

based lubricant can be applied to the moving parts. Avoid oil-based lubricants as they can attract dirt.

- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent material degradation over time.

5. Troubleshooting

If you encounter issues with your Pelican Adventure Overland Case TX80, consider the following:

- **Lid Not Closing Properly:**
  - Check for any items obstructing the lid or the rubber seal.
  - Ensure the rubber seal is correctly seated in its groove and free of debris.
  - Verify that the lid hinges are properly aligned and secured.
- **Latches Are Stiff or Difficult to Engage:**
  - Clean the latches and surrounding areas to remove any dirt or grit.
  - Apply a small amount of silicone lubricant to the latch mechanisms.
- **Water or Dust Ingress:**
  - Inspect the rubber seal for damage, cracks, or improper seating. Replace if necessary.
  - Ensure the latches are fully engaged and the lid is securely closed.
- **Missing Components:** If any components, such as lid hinges or the inner tray, were missing upon delivery, please contact Pelican customer support immediately.

6. Specifications

Detailed specifications for the Pelican Adventure Overland Case TX80:

Feature	Detail
Model	TX80
Exterior Dimensions (L x W x H)	25.00 x 17.25 x 16.00 inches
Interior Dimensions (L x W x H)	20.75 x 12.25 x 13.25 inches
Weight	15.50 lbs (7.03 kg)
Material	Plastic (Rotomolded Construction)
Color	OD Green
Weather Resistance	Heavy-duty rubber seal for water and dust resistance
Security Features	Steel latches with built-in lock hasps
Portability	Molded-in handles
Organization	Removable inner tray, optional MOLLE Panel attachment (not included)



Image 6.1: A person carrying the Pelican Adventure Overland Case TX80 using its molded-in handles, demonstrating its portability.

7. Warranty Information

The Pelican Adventure Overland Case TX80 is backed by a **Lifetime Warranty**. This warranty covers defects in materials and workmanship for the lifetime of the product. For specific terms and conditions, or to initiate a warranty claim, please refer to the official Pelican website or contact Pelican customer support.

8. Support

For further assistance, product inquiries, or to report issues not covered in this manual, please contact Pelican customer support:

- **Online Support:** Visit the official Pelican website for FAQs, product registration, and contact forms.
- **Pelican Store:** You can also find more information and products at thePelican Store on Amazon.

© 2025 Pelican Products, Inc. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRRZK3MW

More documents and user manuals: **https://manuals.plus/**