truke Buds F1 Ultra (S31)

truke Buds F1 Ultra True Wireless Earbuds User Manual

Model: Buds F1 Ultra (S31)
Brand: truke

Introduction

The truke Buds F1 Ultra are advanced true wireless earbuds designed to provide an immersive audio experience with features like Spatial Audio, Environmental Noise Cancellation (ENC), and a dedicated Gaming Mode. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your earbuds.

What's in the Box

- truke Buds F1 Ultra Earbuds (Left and Right)
- Charging Case
- Type-C USB Cable
- Eartips (various sizes)
- Warranty Card
- User Manual

Product Overview

Familiarize yourself with the components of your truke Buds F1 Ultra earbuds and charging case.



Image: truke Buds F1 Ultra earbuds shown inside their open charging case. The earbuds are black with silver accents and green indicator lights. The charging case is also black with a blue truke logo light on the front.

Earbud Components:

- **Touch Control Area:** For managing playback, calls, and modes.
- **Microphone:** Quad-mics for clear calls and Environmental Noise Cancellation (ENC).
- **LED Indicator:** Shows pairing status, charging, and battery level.
- **Eartip:** Provides a secure and comfortable fit.

Charging Case Components:

- **Charging Port:** Type-C port for charging the case.
- **Battery Indicator:** Shows the charging status and battery level of the case.
- **Earbud Charging Slots:** Securely holds and charges the earbuds.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.



Image: The truke Buds F1 Ultra charging case connected to a USB-C cable, illustrating fast charging capabilities. Text indicates 10 minutes of charging provides 10 hours of playtime, and total playtime is up to 60 hours.

- Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
- Connect the Type-C USB cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
- The indicator light on the case will show charging status. Once fully charged, the light may change color or turn off.
- A 10-minute charge of the case can provide up to 100 minutes of playtime for the earbuds. The total playtime with the charging case is approximately 60 hours.

2. Bluetooth Pairing

Pair your truke Buds F1 Ultra with your device for the first time.

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, and their LED indicators will flash.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. Select "truke Buds F1 Ultra" from the list.
5. Once connected, the earbud LED indicators will stop flashing or turn off, and you will hear a confirmation sound.
6. The earbuds feature Bluetooth 5.3 for stable and efficient wireless connections.

Note: The earbuds will automatically connect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case lid, or take the earbuds out of the case. They will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically and begin charging.

Touch Controls

The truke Buds F1 Ultra feature intuitive touch controls on each earbud.

Function	Action
Play/Pause Music	Single tap on either earbud.
Next Track	Double tap on the Right earbud.
Previous Track	Double tap on the Left earbud.
Answer/End Call	Single tap on either earbud.
Reject Call	Press and hold either earbud for 2 seconds.
Activate Voice Assistant (Siri/Google Assistant)	Triple tap on either earbud.

Audio Modes and Features



Image: A close-up of a truke Buds F1 Ultra earbud illustrating 360-degree Spatial Audio. Icons for Dynamic Mode, Movie Mode, and Bass Boost Mode are shown, along with a note about the 13mm Graphene Driver.

- **Spatial Audio Experience:** Enjoy an immersive 360° sound experience for music and gaming.
- **Preset Equalizer Modes:** Customize your listening experience.
  - **Dynamic Mode:** Balanced audio for general listening.
  - **Movie Mode:** Enhanced vocals and soundstage for cinematic content.
  - **Bass Boost Mode:** Amplified bass for a powerful audio experience.

  To switch modes: Refer to the product's specific touch control gestures, usually a long press or multiple taps on one earbud.
- **Environmental Noise Cancellation (ENC):** Quad-mics enhance call clarity by reducing ambient noise.



Image: Two truke Buds F1 Ultra earbuds highlighting the Quad-Mics Advanced Environmental Noise Cancellation (Adv. ENC) feature, emphasizing crystal clear calls.

- **Gaming Mode (Ultra-Low Latency):** Experience synchronized audio and visuals with latency as low as 40ms.



Image: Two truke Buds F1 Ultra earbuds with RGB LEDs, set against a gaming-themed background, highlighting the ultra-low 40ms latency for a pure gaming experience.

To activate Gaming Mode: Refer to the product's specific touch control gestures. This mode is ideal for gaming to minimize audio delay.

Maintenance

Cleaning

- Regularly clean the earbuds, especially the eartips and charging contacts, with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure no moisture enters the earbud openings or charging case.

Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

Troubleshooting

Problem	Possible Solution
Earbuds not pairing/connecting.	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "truke Buds F1 Ultra" from your device's Bluetooth list and re-pair. ◦ Place earbuds back in case, close lid, wait 5 seconds, then open again to re-enter pairing mode.
Only one earbud working.	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the case, close the lid, then open again. ◦ Perform a factory reset (refer to specific instructions in the full user manual if available, or contact support).
Low volume or poor sound quality.	◦ Adjust volume on both your device and the earbuds. ◦ Ensure eartips are clean and properly seated in your ears. ◦ Try different sized eartips for a better seal.
Charging case not charging.	◦ Check the Type-C cable and power adapter. Try a different cable or adapter. ◦ Ensure the charging port is clean and free of debris.

Specifications

Feature	Detail
Model Name	Buds F1 Ultra
Model Number	S31
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Size	13mm Graphene Drivers
Battery Life (Total with Case)	Up to 60 Hours
Fast Charging	10 mins charge = 100 mins playtime
Microphones	Quad-Mics with Advanced Environmental Noise Cancellation (ENC)
Audio Latency	Ultra-Low 40ms (Gaming Mode)
Control Method	Touch Controls
Water Resistance Level	Water Resistant
Item Weight	42 Grams
Dimensions	5.4 x 6 x 3 cm

Feature	Detail
Included Components	Charging Case, Type-C USB Cable, Eartips, Warranty Card, User Manual

Warranty and Support

truke provides comprehensive support for your product.



Image: Information regarding truke's 12-month warranty and a network of over 350 active service centers. Contact details for customer care, including a phone number and email ID, are also provided.

- **Warranty:** Your truke Buds F1 Ultra comes with a 12-month warranty from the brand, assuring quality and customer satisfaction.
- **Service Centers:** truke has a vast service network with over 350 active service centers for convenient and accessible support.
- **Customer Care Contact:**

- **Phone:** +91 9354170767
- **Email:** support@eccentricindia.com
- **Website:** www.truke.in

Please retain your proof of purchase for warranty claims.

© 2025 truke. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question