Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Labymos XDOBO Vibe Plus

Labymos XDOBO Vibe Plus 80W Portable Speaker User Manual

Model: XDOBO Vibe Plus

Introduction

Thank you for choosing the Labymos XDOBO Vibe Plus 80W Portable Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



Image: The Labymos XDOBO Vibe Plus 80W Portable Speaker, showcasing its robust design and dual speaker grilles with illuminated rings.

Key Features

- **Powerful Audio:** 80W RMS output with 2.1CH portable speaker system and super bass.
- **Wireless Connectivity:** Bluetooth 5.0 for seamless streaming from any A2DP-enabled device.
- **Durable Design:** IPX5 waterproof rating, resistant to splashes and rain, ideal for outdoor use.
- **Dynamic Lighting:** Three different modes of RGB lighting effects.
- **True Wireless Stereo (TWS):** Dedicated button for pairing two Vibe Plus speakers for enhanced stereo sound.
- **Versatile Playback:** Supports USB stick playback and 3.5mm AUX line-in for various audio sources.
- **Built-in Power Bank:** USB port for emergency device charging.
- **Equalizer Function:** For dynamic sound customization.
- **Portable:** Sturdy carrying handle for easy transport.



Image: The XDOBO Vibe Plus speaker highlighting its Bluetooth 5.0 connectivity, 80W power output, double diaphragm, and DSP 3 horn design.

Product Overview

Familiarize yourself with the various components and controls of your XDOBO Vibe Plus speaker.



Image: Top view of the speaker showing the control panel with buttons for power, volume, play/pause, mode, and RGB light effects.



Image: An exploded view illustrating the internal components of the speaker, including the drivers and passive radiators, demonstrating its acoustic design.

Setup

Charging the Speaker

Before first use, fully charge the speaker.

1. Locate the Type-C charging port on the speaker.

2. Connect the provided Type-C USB cable to the speaker's charging port.
3. Connect the other end of the cable to a compatible USB power adapter (5V/2A recommended).
4. The charging indicator light will illuminate. It will turn off or change color once fully charged.

The speaker has a 4000mAh battery capacity, providing extended playback time.

Powering On/Off

- To power on, press and hold the Power button (usually indicated by a power symbol) on the control panel until you hear an audible prompt or see indicator lights.
- To power off, press and hold the Power button again until the speaker shuts down.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (usually indicated by a blinking Bluetooth LED). If not, press the Mode button to switch to Bluetooth mode.
2. On your mobile device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "XDOBO Vibe Plus" from the list of found devices.
4. Once paired, the speaker will provide an audible confirmation, and the Bluetooth LED will become solid.
5. You can now play audio from your device through the speaker.

True Wireless Stereo (TWS) Function

Pair two XDOBO Vibe Plus speakers together for a true stereo sound experience.

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press the dedicated TWS button (refer to the control panel diagram if available).
3. The speaker will enter TWS pairing mode.
4. On the second speaker, press its TWS button.
5. The two speakers will automatically connect to each other. Once connected, the primary speaker's Bluetooth LED will blink, and the secondary speaker's LED will be solid.
6. Now, connect your mobile device to the primary speaker via Bluetooth as described above. Audio will play in stereo across both speakers.

Controlling Playback and Volume

- **Play/Pause:** Press the Play/Pause button.
- **Volume Up:** Press the Volume + button.
- **Volume Down:** Press the Volume - button.
- **Next Track:** Press and hold the Volume + button.
- **Previous Track:** Press and hold the Volume - button.

RGB Light Effects

The speaker features three different modes of RGB lighting.

- Press the Light Effect button (often indicated by a sun or lightbulb icon) to cycle through the available RGB lighting modes.
- Press and hold the Light Effect button to turn the lights off.



Image: A person holding the XDOBO Vibe Plus speaker, demonstrating its active RGB lighting effects on the speaker grilles.

USB Stick Playback

Insert a USB flash drive containing audio files into the USB port. The speaker will automatically switch to USB mode and begin playback.

AUX Line-in Mode

Connect an audio device (PC, MID, TV, MP3 player) to the speaker's 3.5mm AUX input using a 3.5mm audio cable. The speaker will automatically switch to AUX mode.

Equalizer Function

Press the EQ button (if available, or refer to the manual's specific button for EQ) to cycle through different equalizer presets for dynamic sound.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker is IPX5 rated, meaning it is resistant to splashes and rain. Do not submerge the speaker in water. Ensure all port covers are securely closed before exposure to water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker; Press and hold the Power button for a few seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker.	Ensure speaker is in Bluetooth pairing mode; Turn on Bluetooth on your device; Move device closer to speaker (within 10m).
No sound from speaker.	Volume too low; Incorrect input mode; Device not playing audio.	Increase speaker and device volume; Press Mode button to select correct input (BT, AUX, USB); Ensure audio is playing on your device.
TWS pairing fails.	Speakers already connected to other devices; Not in TWS pairing mode.	Disconnect speakers from any Bluetooth devices; Ensure both speakers are in TWS pairing mode.

Specifications

Brand	Labymos
Model	XDOBO Vibe Plus
Bluetooth Version	5.0
Output Power	80W RMS
Input Power	Type-C 5V/2A
Battery Capacity	4000mAh
Max Sound Pressure Level	75dB
Frequency Response	70Hz-20kHz
Audio Channels	Stereo (2.1CH)
Speakers	3 dual-diaphragm
Connectivity Options	Bluetooth, AUX (3.5mm), USB Disk
Waterproof Rating	IPX5
Material	Plastic + Metal
Product Dimensions	35.6 x 13.4 x 17.8 cm

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Labymos website. Keep your purchase receipt as proof of purchase.
For further assistance, you may contact customer support through the retailer where the product was purchased.

© 2024 Labymos. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRS24CS9

More documents and user manuals: **https://manuals.plus/**