PINDOWS PDS-642

PINDOWS Men's Digital Analog Watch Instruction Manual

Model: PDS-642

Introduction

Thank you for choosing the PINDOWS PDS-642 Digital Analog Watch. This multifunctional timepiece combines classic analog display with modern digital features, including LED backlight, alarm, stopwatch, and calendar. Designed for durability and versatility, it is suitable for various outdoor activities and daily wear. This manual provides detailed instructions to help you set up, operate, and maintain your watch for optimal performance.





Image: PINDOWS PDS-642 Digital Analog Watch with black dial and leather strap.

Product Features

- **Dual Time Display:** Combines traditional analog hands with a digital display for versatile timekeeping.
- **Multifunctional Digital Display:** Includes alarm clock, automatic date, stopwatch, and 12/24 hour format.
- **LED Backlight:** Provides clear visibility in low-light conditions.
- **50M Water Resistance:** Suitable for swimming, raining, and cold bathing. *Note: Do not press any buttons underwater.*
- **Durable Construction:** Features an alloy steel case, PMMA dial window, and genuine leather band.
- **Pedometer & Calories:** Tracks steps and estimated calorie burn.
- **Hourly Chime:** An optional audible alert on the hour.

Watch Components and Buttons



Image: Diagram showing the location and function of buttons on the PINDOWS PDS-642 watch.

1. **Light Button:** Activates the LED backlight.
2. **Start/Pause Button:** Used for starting and pausing the stopwatch, and for adjusting settings.
3. **Adjustment Button:** Used for setting time, alarm, and other digital functions.
4. **Mode Button:** Cycles through different digital modes (Time, Alarm, Stopwatch).
5. **Time Display:** Digital display area.
6. **Analog Hands:** Traditional hour, minute, and second hands.

Setup and Initial Configuration

1. Setting Analog Time

Pull out the crown (the central knob on the right side of the watch) to the first click position. Rotate the crown to adjust the analog hour and minute hands to the desired time. Once set, push the crown back in to secure the time.

2. Setting Digital Time and Date

1. Press the **Mode Button** repeatedly until the digital time display starts flashing.
2. Press the **Adjustment Button** to select the digit you wish to change (e.g., hours, minutes, year, month, day).
3. Press the **Start/Pause Button** to increase the selected value. Hold to rapidly advance.
4. Continue pressing the **Adjustment Button** and **Start/Pause Button** until all desired settings (time, date, day of week) are configured.
5. Press the **Mode Button** once more to exit the setting mode.

Tip: Ensure the analog and digital times are synchronized for consistent timekeeping.

Operating Instructions

1. Using the LED Backlight

Press the **Light Button** (top-left) to illuminate the digital display. The backlight will remain on for a few seconds. This feature is useful for viewing the time in dark environments.



Image: PINDOWS PDS-642 watch with its blue LED backlight activated, showing the digital time clearly in darkness.

2. Alarm Function

1. Press the **Mode Button** until "AL" (Alarm) appears on the digital display.
2. Press the **Adjustment Button** to make the alarm hour flash.
3. Use the **Start/Pause Button** to set the desired alarm hour.
4. Press the **Adjustment Button** again to select the alarm minutes, then use the **Start/Pause Button** to set them.
5. Press the **Mode Button** to confirm and exit.
6. To turn the alarm ON/OFF, while in "AL" mode, press the **Start/Pause Button**. An alarm icon will appear/disappear.

3. Stopwatch Function

1. Press the **Mode Button** until "ST" (Stopwatch) appears on the digital display.
2. Press the **Start/Pause Button** to start the stopwatch.
3. Press the **Start/Pause Button** again to pause the stopwatch.
4. Press the **Adjustment Button** to reset the stopwatch to zero.
5. Press the **Mode Button** to return to the time display.

4. Hourly Chime

To activate or deactivate the hourly chime, navigate to the time display mode. Press and hold the **Adjustment Button**. A chime icon will appear or disappear, indicating the status of the hourly chime.

Maintenance

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and dirt. For the leather strap, avoid excessive moisture and harsh chemicals.
- **Water Resistance:** The watch is 50M water-resistant. This means it can withstand splashes, rain, and brief immersion in water (e.g., swimming). **Do not press any buttons while the watch is submerged in water.** Avoid hot water, steam, and prolonged exposure to water to prevent damage to seals.
- **Battery Replacement:** The watch uses one CR2032 battery. When the digital display dims or functions become erratic, it's time to replace the battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure water resistance is maintained.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Digital display is blank or dim.	Low battery.	Replace the CR2032 battery.
Analog hands are not moving.	Crown is pulled out; battery issue.	Push the crown back in. If still not moving, replace battery.
Time is inaccurate.	Incorrect setting; low battery.	Re-set the time. Replace battery if issue persists.
Water inside the watch.	Buttons pressed underwater; seals compromised.	Immediately take to a professional for inspection and repair. Avoid further water exposure.
Buttons are unresponsive.	Low battery; internal malfunction.	Replace battery. If problem persists, contact customer support.

SPECIFICATIONS



Image: Diagram illustrating the dimensions and key parameters of the PINDOWS PDS-642 watch.

Feature	Detail
Brand Name	PINDOWS
Model Number	PDS-642
Item Type	Electronic Sports Watch
Movement	Digital
Dial Window Material	PMMA

Feature	Detail
Case Material	Alloy Steel
Band Material Type	Genuine Leather
Clasp Type	Pin Buckle / Buckle
Waterproof Level	50M (5ATM)
Dial Diameter	1.81 inch (approx. 46mm)
Case Thickness	0.55 inch (approx. 14mm)
Band Length	8.4 inch (approx. 213mm)
Battery Type	1 x CR2032 (included)
Product Dimensions	3.03 x 1.18 x 1.18 inches; 5.64 ounces

Warranty and Support

PINDOWS provides a **12-month warranty** for this watch, ensuring quality and reliability. If you encounter any issues or have questions regarding your PDS-642 watch, please refer to the troubleshooting section first. For further assistance, warranty claims, or technical support, please contact PINDOWS customer service through the retailer where you purchased the product or visit the official PINDOWS store page on Amazon.
For more information, you may visit the PINDOWS Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question