Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Taylor Swoden HHB8717D

Taylor Swoden HHB8717D Electric Kettle User Manual

Model: HHB8717D

Introduction

Thank you for choosing the Taylor Swoden HHB8717D Electric Kettle. This manual provides important information regarding the safe operation, maintenance, and troubleshooting of your appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.

- This appliance is for household use only.

Product Overview

Familiarize yourself with the components of your Taylor Swoden HHB8717D Electric Kettle.



Image: The Taylor Swoden HHB8717D Electric Kettle, showing its main body, handle, spout, lid, and detachable power base. This image illustrates the overall design and key external features of the appliance.

1. Spout with filter
2. Lid
3. Handle
4. Water level indicator
5. Power switch with indicator light
6. Kettle body
7. Power base with cord storage

Setup

1. **Unpack:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future transport or storage.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the MAX fill line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the kettle is not near the edge of a counter or table to prevent accidental tipping.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of your kettle (220-240V, 50/60Hz).

Operating Instructions

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below the MIN mark or above the MAX mark (1.7 Litres). Overfilling may cause boiling water to spill out.
2. **Close the Lid:** Ensure the lid is securely closed before operating the kettle.
3. **Place on Base:** Place the kettle firmly onto the power base.
4. **Start Boiling:** Press the power switch down. The indicator light will illuminate, indicating that the kettle is heating.
5. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off.
6. **Pouring:** Carefully lift the kettle from the power base and pour the hot water. Be cautious of steam escaping from the spout.
7. **Re-boiling:** If you need to re-boil, wait a few seconds for the internal thermostat to reset before pressing the power switch again.

Note: The kettle is equipped with boil-dry protection. If it accidentally switches on without water, it will automatically turn off. Allow it to cool down before refilling with cold water.

Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle.

1. **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals. Never immerse the kettle body or power base in water or any other liquid.
3. **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas.
    - Fill the kettle with a mixture of one part white vinegar and two parts water.
    - Boil the mixture and let it stand for at least 30 minutes, or longer if the scale is heavy.
    - Discard the mixture and rinse the interior thoroughly with fresh water several times.
    - For stubborn deposits, a commercial descaling agent designed for kettles can be used following the manufacturer's instructions.
4. **Filter Cleaning:** The spout filter can be removed for cleaning. Rinse it under running water and brush gently if necessary. Ensure it is properly re-inserted before use.
5. **Storage:** When not in use, store the kettle in a clean, dry place. You can wrap the power cord around the cord

storage area under the base.

Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in. Kettle not properly seated on base. Power switch not pressed. Boil-dry protection activated.	Ensure plug is securely in outlet. Place kettle firmly on the power base. Press the power switch down. Allow kettle to cool for 15-20 minutes, then refill with water and try again.
Water takes too long to boil.	Limescale buildup. Low voltage (unlikely for standard household).	Descale the kettle as per maintenance instructions. Ensure kettle is plugged into a suitable power outlet.
Kettle leaks.	Overfilled. Lid not closed properly.	Do not fill above the MAX line. Ensure the lid is securely closed.
Kettle switches off before boiling.	Limescale buildup affecting sensor. Boil-dry protection activated (if no water).	Descale the kettle. Ensure kettle has sufficient water.

If the problem persists after trying these solutions, please contact customer support.

Specifications

- **Model:** HHB8717D
- **Brand:** Taylor Swoden
- **Capacity:** 1.7 Litres
- **Power:** 2200 Watts
- **Voltage:** 220-240V~
- **Frequency:** 50/60Hz
- **Material:** (Assumed, typically Stainless Steel/Plastic)
- **ASIN:** B0CRYN8325
- **Country of Origin:** China

Warranty Information

Taylor Swoden products are manufactured to the highest quality standards. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims.
The warranty does not cover damage caused by misuse, neglect, accident, alteration, or unauthorized repair. For specific warranty terms and conditions, please refer to the warranty card included with your product or contact customer support.

Customer Support

If you have any questions about your Taylor Swoden HHB8717D Electric Kettle, or if you require assistance, please contact our customer support team.

- **Website:** Visit the Taylor Swoden Store on Amazon
- **Email:** (Please refer to your product packaging or warranty card for specific email address)
- **Phone:** (Please refer to your product packaging or warranty card for specific phone number)

When contacting support, please have your model number (HHB8717D) and proof of purchase ready.

© 2024 Taylor Swoden. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRYN8325

More documents and user manuals: **https://manuals.plus/**