Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FRESKO HB3302

FRESKO 4-in-1 Immersion Blender Instruction Manual

Model: HB3302 | Brand: FRESKO

Introduction

Thank you for choosing the FRESKO 4-in-1 Immersion Blender. This versatile kitchen appliance is designed to simplify your food preparation tasks with its powerful motor and multiple attachments. Please read this manual thoroughly before first use to ensure safe and optimal operation. Keep this manual for future reference.

Product Overview

The FRESKO Immersion Blender system includes a powerful motor body and several interchangeable attachments for various culinary tasks.



Figure 1: Key features of the FRESKO Immersion Blender, including the 12-speed control, ergonomic design, turbo switch, 500W motor, 4-blade system, and easy assembly mechanism.

Components Included:

- **Motor Body:** The main unit housing the 500W motor, speed control dial, and power/turbo buttons.
- **Immersion Blender Stick:** Stainless steel shaft with a 4-blade system for blending.
- **Chopper Attachment (500ml):** For chopping nuts, meat, and vegetables.
- **Whisk Attachment:** For whisking eggs, cream, and batters.
- **Measuring Cup (700ml):** With a lid for convenient blending, measuring, and storage.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash all detachable parts (blender stick, chopper bowl, whisk, measuring cup) in warm soapy water. Rinse thoroughly and dry. The motor body should only be wiped with a damp cloth.

3. **Assemble:** Attach the desired accessory to the motor body. Align the accessory with the motor unit and twist or push until it clicks securely into place. Ensure it is firmly attached before use.
4. **Power Connection:** Plug the power cord into a standard electrical outlet.

Operating Instructions

General Operation:

- Ensure the appliance is properly assembled and plugged in.
- Place the food items into the appropriate container (measuring cup, chopper bowl, or a suitable pot/bowl).
- Immerse the attachment into the food.
- Press and hold the Power button to start. For maximum speed, press the Turbo button.
- Release the button to stop operation.

Speed Control:



Figure 2: The 12-speed control dial and Turbo button on the FRESKO Immersion Blender motor body.

The FRESKO Immersion Blender features 12 variable speeds, adjustable via the dial on top of the motor body. Turn the dial to select your desired speed. For a quick burst of maximum power, press the **TURBO** button.

Using the Immersion Blender Stick:



Figure 3: Blending baby food with the immersion blender stick in the measuring cup.

- Ideal for pureeing soups, making smoothies, sauces, and baby food.
- Insert the blender stick into the liquid before turning it on to prevent splashing.
- Move the blender up and down gently to ensure even blending.
- The 4 ultra-hard stainless steel blades are designed to crush hard foods effectively.

Using the Chopper Attachment:



Figure 4: Chopping meat using the chopper attachment.

- Use for chopping nuts, herbs, onions, garlic, and small quantities of meat.
- Do not overfill the chopper bowl.
- Use short pulses for coarse chopping, and longer pulses for finer results.

Using the Whisk Attachment:



Figure 5: Whisking cream with the whisk attachment.

- Perfect for whipping cream, beating eggs, and mixing light batters.
- Attach the whisk to the motor body.
- Begin whisking at a low speed and gradually increase as needed.

Official Product Video:

Your browser does not support the video tag.

Video 1: FRESKO Hand Blender 12-Speed Powerful Handheld Stick Blender. This video demonstrates the assembly and various uses of the FRESKO Immersion Blender, showcasing its 12-speed functionality and powerful blending capabilities for different ingredients.

Maintenance and Cleaning



Figure 6: Cleaning the detachable components of the FRESKO Immersion Blender.

- **Motor Body:** Wipe the motor body with a damp cloth. Do not immerse the motor body in water or any other liquid.
- **Blender Stick:** The stainless steel blender stick is dishwasher safe. For manual cleaning, rinse under running water immediately after use.
- **Chopper Bowl & Whisk:** These attachments are generally dishwasher safe or can be washed by hand with warm soapy water.
- **Measuring Cup:** Wash with warm soapy water or place in the dishwasher.
- **Detaching Parts:** To detach accessories, press the release buttons on the sides of the motor body and pull the attachment off.
- Ensure all parts are completely dry before storing.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet not working; attachment not securely connected.	Check power cord connection; test outlet with another appliance; ensure attachment is clicked into place.
Motor stops during operation.	Overheating due to prolonged use or processing too hard ingredients.	Unplug and let cool down for 15-20 minutes. Reduce load or processing time.
Food is not blending evenly.	Insufficient liquid; ingredients too large; not moving the blender.	Add more liquid; cut ingredients into smaller pieces; move the blender up and down.
Splashing during blending.	Blender not fully immersed; container too full.	Ensure blender head is fully submerged before starting; do not overfill container.

Specifications



Figure 7: Dimensions of the FRESKO Immersion Blender and its accessories.

- **Brand:** FRESKO
- **Model Number:** HB3302
- **Power:** 500W
- **Number of Speeds:** 12 + Turbo Mode
- **Voltage:** 120 Volts
- **Material:** Food-Grade 304 Stainless Steel (Blades & Stick)
- **Color:** Stainless Steel
- **Product Dimensions:** 2.5"D x 2.5"W x 15.5"H (main unit)
- **Item Weight:** 2.73 pounds
- **Capacity (Measuring Cup):** 700 Milliliters
- **Capacity (Chopper):** 500 Milliliters
- **Special Features:** Adjustable Speed Control, Compact, Detachable Attachment, Ergonomic Handle, Multiple Speeds, Anti-splash design.
- **Material Type Free:** BPA Free

Warranty and Support

Warranty Information:

This FRESKO Immersion Blender comes with a **Full Warranty**. For specific terms and conditions, please refer to the warranty card included in your product packaging or contact FRESKO customer service.

Customer Support:

If you have any questions, concerns, or require assistance with your FRESKO Immersion Blender, please contact our customer support team:

- **Phone:** 1-866-211-9344
- **Email:** support@freskoshop.com
- **Website:** www.freskoshop.com

Our support team is available to help you with product registration, troubleshooting, and any other inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRYN8TW5

More documents and user manuals: **https://manuals.plus/**