**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Arktronic W320**

# Arktronic 32-inch FHD WiFi Digital Picture Frame (Model W320) User Manual

Comprehensive instructions for setup, operation, and maintenance.

## 1. Introduction

Thank you for choosing the Arktronic 32-inch FHD WiFi Digital Picture Frame, Model W320. This device allows you to display your cherished photos and videos with exceptional clarity on a large 1920x1080 Full HD IPS matte screen. With 64GB of internal storage, remote control functionality, and automatic rotation, it offers a versatile and user-friendly experience for sharing memories with family and friends.

## 2. Package Contents

Before proceeding with the setup, please ensure all items listed below are present in your package:

- Arktronic 32-inch FHD WiFi Digital Picture Frame (Model W320)
- Remote Control (requires AAA batteries, not included)
- Swivel Wall Mount (VESA Spec 100 x 100mm)
- Screwdriver
- Screws & Wall Anchors
- Power Cord (70.87 inches)
- User Manual / Quick Start Guide





Figure 2.1: Included accessories and frame dimensions.

The wall mount allows for both vertical and horizontal orientation, adapting to your display needs.

# 3. Product Overview

## 3.1 Front View




Figure 3.1: Front view of the digital picture frame with remote and app interface.

The front of the frame features a 32-inch FHD IPS matte screen display, offering a 1920x1080 resolution for high-quality image and video presentation from various viewing angles.

## 3.2 Rear View and Ports





Figure 3.2: Rear view with port locations and controls.

The rear of the frame includes a speaker, VESA mounting holes, USB 2.0 port, Type-C port, Micro SD card slot, DC-IN power input, and integrated power/volume buttons. These ports allow for expanded storage and connectivity options.

## 4. Setup Guide

### 4.1 Initial Power-On

1. **Unpack:** Carefully remove the digital picture frame and all accessories from the packaging.
2. **Connect Power:** Plug the power cord into the DC-IN port on the back of the frame, then connect it to a power outlet. The frame will automatically begin the startup process.
3. **Select Language:** Use the included remote control to navigate the on-screen menu and select your preferred language.

Your browser does not support the video tag.

Video 4.1: This video provides a brief overview of the Arktronic 32-inch WiFi Digital Picture Frame, showcasing its appearance and various uses.

### 4.2 WiFi Connection

4. **Access WiFi Settings:** From the home screen, navigate to the 'Settings' menu using the remote control. Select 'Wi-Fi'.
5. **Connect to Network:** Choose your desired WiFi network from the list and enter the password using the on-screen keyboard. Ensure the frame is successfully connected to the internet.

### 4.3 App Installation and Pairing

6. **Download VPhoto App:** Search for "VPhoto" in your mobile device's app store (Apple App Store or Google Play Store) and download the application.
7. **Create Account:** Open the VPhoto app and create a new user account.
8. **Pair Frame:** In the VPhoto app, follow the instructions to connect your frame. You may need to scan a QR code displayed on the frame's screen (found in 'Settings' > 'My Frame' > 'Device Info') or enter a connection code.




Figure 4.3: Steps for downloading the VPhoto app and connecting your frame.

Once paired, you can instantly share photos and videos from your smartphone to the digital picture frame.

## 4.4 Mounting Options

The frame supports both vertical and horizontal wall mounting using the included swivel mount. It also features an auto-rotate function that adjusts the display orientation automatically.




Figure 4.4: The special swivel mount allows for easy rotation between portrait and landscape modes.

## 5. Operation

### 5.1 Adding Photos and Videos

- **Via VPhoto App:** Open the VPhoto app on your smartphone, select the photos or videos you wish to share, and upload them to your connected frame. The frame has 64GB of internal memory, capable of storing up to 160,000 photos.
- **Via Email:** You can also send photos and videos directly to your frame's unique email address.
- **Via USB/Micro SD:** Insert a USB flash drive or Micro SD card (up to 64GB with an external converter) into the respective ports on the frame. You can play media directly from these devices or import/export content to the internal storage.




Figure 5.1: Sharing photos and videos via the VPhoto app.

## 5.2 Remote Control Functions

The remote control provides convenient access to various frame functions:

- **Navigation:** Use arrow keys to move through menus and select options.
- **Photo/Video Playback:** Switch between photos, play videos, and control playback.
- **Settings Access:** Adjust brightness, volume, slideshow mode, and other display settings.
- **Power On/Off:** Turn the frame on or off.




Figure 5.2: Remote control for easy operation.

## 5.3 Multi-functionality

Beyond displaying media, the frame offers additional features:

- **Weather Display:** Shows current weather conditions and forecasts for your location.
- **Clock & Alarm:** Functions as a clock and allows you to set alarms.
- **Background Music:** Play background music during photo slideshows.
- **Captions:** Add descriptive captions to your photos.
- **Sleep Mode:** Configure the frame to enter sleep mode during specified times.





Figure 5.3: Home screen displaying various functions including weather, clock, and media options.

## 6. Maintenance

- **Cleaning:** Use a soft, dry cloth to gently wipe the screen and frame. Avoid abrasive cleaners or solvents.
- **Software Updates:** Ensure your frame is connected to WiFi to receive automatic software updates for optimal performance and new features.
- **Factory Reset:** If you encounter persistent issues, a factory data reset option is available in the settings menu. This will erase all user data and settings.

## 7. Troubleshooting

| Issue | Possible Cause | Solution |
|---|---|---|

| Issue | Possible Cause | Solution |
|---|---|---|
| Frame does not power on | Power cord not properly connected; power outlet issue. | Check power cord connection; try a different outlet. |
| Cannot connect to WiFi | Incorrect password; out of range; network issue. | Verify password; move frame closer to router; restart router. |
| Photos/Videos not uploading via app | Frame not paired; app not updated; file size limit exceeded. | Ensure frame is paired; update VPhoto app; check video file size (VPhoto app limits video uploads to 200MB). |
| Auto-rotate not working | Feature disabled in settings; sensor obstruction. | Check 'Auto-Rotate Screen' setting; ensure no physical obstruction. |

## 8. Specifications

| | |
|---|---|
| **Brand** | Arktronic |
| **Model Number** | W320 |
| Screen Size | 32 Inches |
| **Resolution** | 1920x1080 (FHD) |
| **Display Type** | IPS Matte Screen |
| **Internal Storage** | 64GB (stores up to 160,000 photos) |
| **External Storage** | USB Flash Drive, Micro SD Card (up to 64GB via external converter) |
| **Connectivity** | WiFi (2.4GHz/5GHz), Bluetooth |
| **Compatible Devices** | IOS, Android |
| **Supported Image Formats** | JPG, GIF, BMP, PNG |
| **Supported Video Formats** | MPEG1, MPEG2, MPEG4, Xvid, AVI, M-JPEG, H.264.MOV, VOB, MKV, DIVX4, DIVX5 |
| **Product Dimensions** | 29.94 x 17.98 x 0.99 inches |
| **Item Weight** | 7.92 pounds |

## 9. Warranty and Support

This product is guaranteed against material and workmanship defects from the date of purchase. For warranty claims or technical support, please refer to the contact information provided in your product packaging or visit the official Arktronic website. Misuse, abuse, or unauthorized modifications are not covered under warranty.

**Customer Service:** For assistance, please contact Arktronic customer support.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0CSMDH3K1**

More documents and user manuals: **https://manuals.plus/**