Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Taylor Swoden B0CSYWX6FZ

Taylor Swoden Electric Kettle with Tea Infuser (1L) - Instruction Manual

Model: B0CSYWX6FZ

Introduction

Thank you for choosing the Taylor Swoden Electric Kettle with Tea Infuser. This appliance is designed for fast and efficient water boiling and tea brewing. Please read this manual thoroughly before use to ensure safe and optimal operation.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Do not immerse the power base, cord, or plug in water or other liquids.
- Ensure the kettle is placed on a firm, flat, heat-resistant surface.
- Do not operate the kettle if the cord or plug is damaged.
- Keep the appliance out of reach of children.
- Do not fill above the MAX line or below the MIN line to prevent boil-dry and overflow.
- Always close the lid securely before operating.
- Use only cold water for boiling.
- Unplug the kettle from the outlet when not in use and before cleaning.
- Avoid contact with hot surfaces. Use handles or knobs.

Components

The Taylor Swoden Electric Kettle includes the following parts:

- Glass Kettle Body (1L capacity)
- Power Base with Cord Wrap
- Removable Stainless Steel Tea Infuser
- Lid with integrated filter



Image: The Taylor Swoden Electric Kettle with its glass body, handle, lid, and power base.

Setup

1. **Unpack:** Carefully remove all packaging materials and check for any damage.
2. **Clean:** Before first use, fill the kettle with clean water to the MAX line, boil, and then discard the water. Repeat this process 2-3 times to remove any manufacturing residues. Wash the tea infuser and lid with warm, soapy water and rinse thoroughly.
3. **Placement:** Place the power base on a stable, flat, dry, and heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.

Operating Instructions

1. Boiling Water

1. **Fill:** Open the lid and fill the kettle with the desired amount of cold water. Do not exceed the MAX (1.0L) mark or go

below the MIN (0.3L) mark.

2. **Close Lid:** Close the lid securely.
3. **Place on Base:** Place the kettle onto the power base.
4. **Power On:** Plug the power cord into a suitable electrical outlet. Press the ON/OFF switch located on the handle. The blue LED indicator light will illuminate, indicating the kettle is heating.
5. **Automatic Shut-Off:** The kettle will automatically shut off once the water reaches a rolling boil, and the blue LED light will extinguish.
6. **Pour:** Carefully lift the kettle from the base and pour the hot water.

Your browser does not support the video tag.

Video: Demonstration of the Taylor Swoden Electric Kettle boiling water, showing the blue LED light and automatic shut-off feature.



Image: The electric kettle with water boiling, illuminated by a blue LED light at the base.

2. Using the Tea Infuser

1. **Prepare Infuser:** Remove the lid from the kettle. Detach the stainless steel tea infuser from the lid by gently pulling it down.
2. **Add Tea:** Fill the infuser with your desired loose-leaf tea or tea bags. Do not overfill.
3. **Reattach Infuser:** Reattach the filled infuser to the lid.
4. **Brew:** Place the lid with the infuser back onto the kettle. Follow the boiling instructions above. Once the water boils, allow the tea to steep for the recommended time.
5. **Remove Infuser:** After steeping, carefully remove the lid with the infuser. You may place the infuser on a small plate to catch drips.



Image: A hand demonstrating how to remove the stainless steel tea infuser from the kettle lid and fill it with tea leaves.

Your browser does not support the video tag.

Video: A demonstration of how to use the tea infuser with the electric kettle, including filling and placing it.

3. Keep Warm Function

The kettle features a "Keep Warm" function to maintain the water temperature between 176°F/80°C to 185°F/85°C after boiling.

1. **Activate:** After the water has boiled, press the "KEEP WARM" button located on the power base. The indicator light for this function will illuminate.
2. **Deactivate:** To turn off the "Keep Warm" function, press the "KEEP WARM" button again or lift the kettle from its base.



Image: Close-up of the kettle base showing the "KEEP WARM" button and the Taylor Swoden logo.

4. Auto Shut-Off and Boil-Dry Protection

For safety and peace of mind, the kettle is equipped with:

- **Automatic Shut-Off:** The kettle automatically turns off once the water has reached a full boil.
- **Boil-Dry Protection:** If the kettle is accidentally switched on without sufficient water, the boil-dry protection will automatically turn off the heating element to prevent damage to the appliance.

Maintenance

Regular cleaning ensures the longevity and optimal performance of your kettle.

1. **Unplug:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior of the kettle and the power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
3. **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale:
    - Fill the kettle with a mixture of 1 part white vinegar and 2 parts water.
    - Boil the mixture and let it stand for at least 30 minutes, or longer for heavy deposits.
    - Discard the mixture and rinse the interior thoroughly with fresh water several times.
    - For stubborn deposits, you may need to repeat the process or gently scrub with a non-abrasive brush.
4. **Tea Infuser Cleaning:** The stainless steel tea infuser can be easily removed and rinsed under running water. For thorough cleaning, use warm, soapy water and a soft brush.



Image: A hand pouring lemon juice into the kettle to demonstrate cleaning the interior from mineral deposits.

Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat.	Not plugged in; power switch off; kettle not properly seated on base.	Ensure kettle is plugged in, switch is ON, and kettle is correctly placed on the base.
Water does not boil.	Insufficient water (boil-dry protection activated); faulty power outlet.	Fill kettle above MIN line. Check power outlet with another appliance.
Kettle leaks.	Lid not closed properly; overfilled.	Ensure lid is securely closed. Do not fill above MAX line.
Excessive scale buildup.	Hard water usage.	Descale the kettle regularly as per maintenance instructions.

Specifications

- **Brand:** Taylor Swoden
- **Model:** B0CSYWX6FZ
- **Capacity:** 1.0 Liter (approximately 5 cups)
- **Material:** Borosilicate Glass, Stainless Steel (infuser, heating element), BPA-Free Plastic
- **Special Features:** Automatic Shut-Off, Boil Dry Protection, Built-In Infuser Filter, Keep Warm Function, LED Light Indicator, Cool Touch Handle
- **Product Dimensions:** 8.15"L x 6.14"W x 8.43"H
- **Item Weight:** 2.29 pounds
- **Manufacturer:** Taylor Swoden
- **Country/Region of Origin:** China

Warranty and Support

For any needs or questions regarding your Taylor Swoden Electric Kettle, please contact the TaylorTech Inc. customer support team. Refer to the product packaging or the official Taylor Swoden website for the most current contact information and warranty details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CSYWX6FZ

More documents and user manuals: **https://manuals.plus/**