Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tiptiper DJ502512

Tiptiper Nightstand Set 2 Instruction Manual

Model: DJ502512
Brand: Tiptiper

Introduction

Thank you for choosing the Tiptiper Nightstand Set 2. This manual provides essential information for the safe assembly, operation, and maintenance of your new nightstands. Please read these instructions carefully before beginning assembly and retain them for future reference.

Important Safety Information

- Always unplug the charging station when not in use to prevent electrical hazards.
- Keep the charging station dry. Avoid exposure to liquids to prevent damage and electrical shock.
- Do not insert any object other than the charging cable into the charging station ports.
- Always follow the assembly instructions carefully to avoid injury during setup and ensure structural integrity.

Setup and Assembly

Your Tiptiper Nightstand Set 2 requires assembly. Please ensure all components are present before beginning. The item will arrive in two packages.

Required Tools:

- Hammer
- Screwdriver

All necessary accessories and detailed assembly instructions are included with your purchase. Please refer to the separate assembly guide for step-by-step instructions. Carefully follow each step to ensure proper and secure construction of your nightstands.



Image: The Tiptiper Nightstand, showing its overall dimensions of 17.7 inches width, 26.8 inches height, and 13.8 inches depth. This image provides a visual reference for the assembled product size.



Image: A Tiptiper Nightstand placed next to a bed in a bedroom, illustrating its typical use and scale within a room.

Operating Instructions

Charging Station

Each nightstand is equipped with a built-in charging station for your convenience. This station includes:

- Two (2) Standard Plug Outlets (125V/12A)
- Two (2) USB Ports (5V/2.1A)
- One (1) On/Off Switch for power control

To use, simply plug the nightstand's power cord (5.9 feet long) into a wall outlet. Use the On/Off switch to activate or deactivate power to the outlets and USB ports. Connect your electronic devices to the appropriate ports for charging.



Image: A close-up view of the nightstand's charging station, showing two AC outlets, two USB ports, and an on/off switch. A tablet is shown charging via a USB port.

Your browser does not support the video tag.

Video: This video demonstrates the features of the Tiptiper Nightstand with Hutch, including the built-in charging station and storage drawers. It shows how to plug in devices and utilize the storage compartments.

Storage Drawers

Each nightstand features three (3) sliding drawers, providing ample space for organizing personal items. The drawers are designed for smooth operation.



Image: The nightstand with its three drawers partially open, revealing the interior storage space suitable for various items.

Hutch and Open Storage

The top section of the nightstand includes a hutch design with open shelving. This area is ideal for placing decorative items, books, or frequently accessed personal belongings.



Image: The nightstand displaying items on its top surface and within the hutch, such as a clock, plant, and framed picture, demonstrating its functional use.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the engineered wood finish.
- **Charging Station Care:** Ensure the charging station remains dry. If any liquid spills on it, immediately unplug the unit and allow it to dry completely before re-using.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If a drawer becomes stiff, ensure no debris is obstructing the slides.
- **General Care:** Avoid placing excessively hot or cold items directly on the surface without protection. Keep the nightstand away from direct sunlight and extreme temperature changes to prevent warping or discoloration.

Troubleshooting

Charging Station Not Working:

- Ensure the nightstand's main power cord is securely plugged into a functional wall outlet.
- Verify that the On/Off switch on the charging station is in the "On" position.
- Check if the device you are trying to charge is properly connected to the USB port or AC outlet.
- Test the wall outlet with another appliance to confirm it is receiving power.

Drawers Sticking or Not Sliding Smoothly:

- Check for any objects obstructing the drawer slides or caught inside the drawer.
- Ensure the nightstand is placed on a level surface. Uneven surfaces can cause drawers to misalign.
- During assembly, ensure all screws for the drawer slides were tightened correctly. If issues persist, re-check the assembly instructions for drawer slide installation.

Specifications

Brand	Tiptiper
Model Number	DJ502512
Product Dimensions (D x W x H)	13.8"D x 17.7"W x 26.8"H
Frame Material	Engineered Wood
Color	White
Number of Drawers	3
Number of Items	2 (Set of 2 Nightstands)
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2.1A), On/Off Switch
Power Cord Length	5.9 Feet
Assembly Required	Yes
Recommended Tools for Assembly	Hammer, Screwdriver

Warranty and Support

Warranty Information

Specific warranty details for the Tiptiper Nightstand Set 2 are typically provided with your purchase

documentation or can be obtained directly from the manufacturer. Please refer to the warranty card included in your packaging or visit the official Tiptiper website for the most current information.

Customer Support

If you have any questions regarding the assembly, operation, or maintenance of your Tiptiper Nightstand Set 2, please contact Tiptiper customer service. Contact information can usually be found on the product packaging, the manufacturer's website, or through your retailer.
For online support, you may visit the Tiptiper Store on Amazon.

© 2024 Tiptiper. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CT2GCQ7V

More documents and user manuals: **https://manuals.plus/**