**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Tefal BL83SD30**

# Tefal Perfectmix Cook BL83SD High-Speed Blender User Manual

Model: BL83SD30

## Introduction

Welcome to the user manual for your new Tefal Perfectmix Cook BL83SD High-Speed Blender. This versatile kitchen appliance is designed to help you prepare a wide range of recipes, from cold smoothies and shakes to hot, creamy soups and stews. With its powerful motor and intuitive touchscreen, preparing delicious meals is quick and effortless. The included steamer basket further expands its capabilities, allowing for healthy steaming of fish, vegetables, and seafood. Key features include:

- Incredible versatility for hot, cold, solid, and liquid recipes.
- 10 automatic programs: 4 cold (smoothie, milkshake, dessert, ice cream) and 6 hot (compote, smooth soup, chunky soup, blend, multigrain milk, hot sauce).
- Powerful 1400W motor with exclusive Powelix blades for fast performance.
- Easy-to-clean design with removable blades for thorough cleaning.
- Steamer basket accessory for healthy cooking.

## Safety Instructions

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the appliance from the power outlet before cleaning, assembling, or disassembling parts.
- Do not immerse the motor base in water or any other liquid.
- Keep hands and utensils out of the blending jar while blending to reduce the risk of severe injury to persons or damage to the blender.
- Never blend hot liquids above the maximum fill line indicated on the jar. Hot liquids can scald if they overflow.
- Ensure the lid is securely locked in place before operating the blender.
- Do not operate the blender with damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is for household use only.

## Components and Features

Familiarize yourself with the parts of your Tefal Perfectmix Cook BL83SD blender:




**Image Description:** A full view of the Tefal Perfectmix Cook BL83SD blender. The main unit is silver and black with a clear glass blending jar on top. The control panel on the front of the base shows various program icons and a digital display. To the left of the blender is a black steamer basket. To the right are a small clear measuring cup and a white cleaning brush.

## Main Components:

- **Motor Base:** The main unit containing the motor and control panel.
- **Glass Blending Jar:** A durable glass jar with measurement markings and a handle.
- **Lid:** Securely fits on top of the blending jar, often with a removable measuring cap.
- **Steamer Basket:** A black accessory designed to fit inside the blending jar for steaming.
- **Measuring Cup:** A small clear cup for precise ingredient measurement.
- **Cleaning Brush:** A brush provided for easier cleaning of the blades and jar.

## Control Panel (Touchscreen):

- **Digital Display:** Shows time and program status.
- **Cold Programs:**
    - **Milkshake:** For creamy milkshakes.
    - **Smoothie:** For smooth fruit and vegetable blends.

- **Dessert:** For various dessert preparations.
- **Ice Crush:** For crushing ice cubes.
- **Compote:** For fruit compotes.

- **Hot Programs:**
  - **Smooth Soup:** For velvety smooth soups.
  - **Chunky Soup:** For soups with a thicker, textured consistency.
  - **Stir:** For gentle mixing.
  - **Multigrain Milk:** For preparing plant-based milks.
  - **Hot Sauce:** For various hot sauces.
- **Manual Functions:**
  - **Blend:** General blending function.
  - **Pulse:** Short bursts of high-speed blending.
  - **Clean:** Automatic cleaning program.
  - **Heat:** Manual heating function.
  - **Start/Stop:** To begin or end a program/function.
- **Powelix Technology:** Advanced blade technology for optimal blending results.

## Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean Before First Use:** Wash the blending jar, lid, steamer basket, measuring cup, and cleaning brush with warm soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Position the Base:** Place the motor base on a clean, dry, stable, and flat surface. Ensure it is away from the edge of the counter and out of reach of children.
4. **Assemble the Jar:** Place the glass blending jar onto the motor base. Ensure it is securely seated and locked into position.
5. **Attach the Lid:** Place the lid onto the blending jar and twist or press down until it is securely closed. The blender will not operate if the lid is not properly secured.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet.

## Operating Instructions

### General Blending:

1. Ensure the blender is assembled correctly and plugged in.
2. Add ingredients to the blending jar. Do not exceed the MAX fill line, especially for hot liquids.
3. Secure the lid firmly.
4. Select your desired automatic program from the touchscreen (e.g., Smoothie, Smooth Soup) or choose a manual function (Blend, Pulse, Heat).
5. Press the "Start/Stop" button to begin operation.
6. The blender will automatically stop when the program is complete. For manual functions, press "Start/Stop" again to stop.
7. Unplug the blender before removing the jar and pouring out contents.

### Using the Steamer Basket:

1. Pour a small amount of water (e.g., 200-300ml) into the blending jar.
2. Place the steamer basket inside the blending jar, ensuring it sits above the water level.
3. Add your ingredients (e.g., chopped vegetables, fish) into the steamer basket. Do not overfill.
4. Secure the lid firmly.
5. Select a suitable hot program or use the "Heat" function manually, monitoring the steaming process.
6. Once steaming is complete, carefully remove the lid (beware of hot steam) and then the steamer basket.

## Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your blender.

### Automatic Cleaning Program:

- After use, rinse the jar.
- Fill the jar with warm water and a few drops of dish soap.
- Secure the lid and select the "Clean" program on the touchscreen.
- Allow the program to run. Once complete, empty the jar and rinse thoroughly.

### Manual Cleaning:

- **Blades:** The blades are removable for deep cleaning. Carefully detach them following the instructions in the full manual (not provided here). Use the provided cleaning brush to clean around the blades. Exercise extreme caution as blades are sharp.
- **Jar and Lid:** Wash with warm soapy water. The glass jar and lid are generally dishwasher safe, but refer to the full product manual for specific instructions.
- **Motor Base:** Wipe the motor base with a damp cloth. Never immerse it in water or place it under running water.
- Ensure all parts are completely dry before reassembling or storing.

## Troubleshooting

If you encounter issues with your blender, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Blender does not turn on. | Not plugged in; Lid not secured; Jar not properly seated. | Check power connection; Ensure lid is locked; Re-seat the blending jar on the base. |
| Ingredients are not blending smoothly. | Too little liquid; Overfilled jar; Ingredients too large. | Add more liquid; Reduce ingredient quantity; Cut ingredients into smaller pieces. |
| Leakage from the bottom of the jar. | Blades not properly assembled; Seal ring damaged or missing. | Ensure blades are securely attached; Check the seal ring for damage and proper placement. |
| Burning smell or loud noise. | Overloading the motor; Foreign object in blades. | Unplug immediately; Reduce load; Check for obstructions. Contact customer service if problem persists. |

For issues not listed here, or if solutions do not resolve the problem, please contact Tefal customer support.

## Specifications

| | |
|---|---|
| **Brand** | Tefal |
| **Model Number** | BL83SD30 |
| **Color** | Metal |
| **Dimensions (Product)** | 23.9P x 21.2l x 45.6H centimeters |
| **Capacity** | 1.75 Liters |
| **Power** | 1400 Watts |
| **Voltage** | 220 Volts |
| **Material** | Glass |
| **Item Weight** | 5.8 Kilograms |
| **Components Included** | Steamer basket, measuring cup, brush |
| **Special Feature** | Variety, powerful, healthy |

## Warranty and Support

Your Tefal Perfectmix Cook BL83SD blender comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage.
For technical support, service, or to inquire about replacement parts, please visit the official Tefal website or contact their customer service department. Contact information can typically be found on the Tefal website or in your product documentation.
Visit the Tefal Brand Store for more information.

© 2024 Tefal. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0CT39WZB3**

More documents and user manuals: **https://manuals.plus/**