realme S0454240

realme C53 Dual SIM Smartphone User Manual

Model: S0454240

1. Introduction

This user manual provides comprehensive instructions for the realme C53 Dual SIM Smartphone. Please read this manual carefully before using your device to ensure proper operation and to maximize its performance. Keep this manual for future reference.

2. Package Contents

Upon opening the package, please verify that all items are present and in good condition. The standard package for your realme C53 smartphone includes:

- realme C53 Dual SIM Smartphone
- USB Cable
- Quick Start Guide (may vary by region)
- SIM Ejector Tool (may vary by region)

Note: Other accessories such as a power adapter or protective case may be sold separately or included depending on your region and specific package.

3. Device Overview



Figure 3.1: Front and Rear View of realme C53 Smartphone. The image displays the phone's front screen with the realme C53 logo and the rear panel featuring a triple camera setup and the realme branding at the bottom.

The realme C53 features a sleek design with a large display and a prominent camera module. Familiarize yourself with the key components:

- **Front:** 6.74-inch IPS LCD display, front camera (8MP), earpiece, light sensor.
- **Rear:** Main camera (50MP), depth sensor (0.3MP), LED flash, realme logo.
- **Sides:** Power button (with integrated fingerprint sensor), volume buttons, SIM/microSD card tray, USB port, speaker, microphone.

Note: The realme C53 does not feature a 3.5mm headphone jack. Audio connectivity is primarily via the USB port or wireless options.

4. Setup

4.1. Installing SIM Cards and microSD Card

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray to open it.
3. Place your Nano-SIM cards (up to two) and/or a microSD card into the designated slots on the tray. Ensure the gold contacts face downwards.
4. Carefully push the tray back into the device until it clicks into place.

4.2. Initial Power On and Setup Wizard

1. Press and hold the Power button until the realme logo appears.
2. Follow the on-screen instructions to complete the initial setup, which includes selecting your language, connecting to Wi-Fi, setting up your Google account, and configuring security features like fingerprint unlock.

4.3. Network Compatibility Note

Important: This realme C53 smartphone is designed for GSM networks and is **not compatible** with CDMA networks, including carriers like VERIZON, SPRINT, and US CELLULAR. Please verify network compatibility with your service provider before attempting to use the device.
The device supports the following frequencies:

- **SIM Card 1 & 2:**
- 2G GSM: 850 / 900 / 1800 / 1900 MHz
- 3G WCDMA: 850(B5) / 900(B8) / 2100(B1) MHz
- 4G FDD-LTE: 850(B5) / 900(B8) / 1800(B3) / 2100(B1) MHz
- 4G TDD-LTE: 2300(B40) / 2500(B41) / 2600(B38) MHz

5. Operating Instructions

5.1. Basic Navigation

- **Touchscreen Gestures:** Tap, swipe, pinch-to-zoom are standard.
- **Power Button:** Press to wake/sleep the screen. Press and hold to power off or restart.
- **Volume Buttons:** Adjust media volume, call volume, or ringtone volume.
- **Fingerprint Sensor:** Integrated into the power button for quick and secure unlocking.

5.2. Camera Usage

The realme C53 is equipped with a 50MP main rear camera and an 8MP front camera.

1. Open the "Camera" application from your home screen or app drawer.
2. Select your desired mode (Photo, Video, Portrait, Night, etc.).
3. Tap the shutter button to capture a photo or start/stop video recording.
4. Use the toggle to switch between front and rear cameras.

5.3. Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available networks.
- **Bluetooth:** Go to Settings > Connected devices > Bluetooth to pair with other Bluetooth devices like headphones or speakers.
- **Mobile Data:** Ensure your SIM card is active and mobile data is enabled in Settings > Network & internet > Mobile network.

5.4. Storage Management

Your device comes with 256GB of internal storage. You can expand this using a microSDXC card in the dedicated slot. Regularly manage your storage by deleting unnecessary files, clearing app caches, and moving media to your microSD card or cloud storage.

6. Maintenance

6.1. Battery Care

- Use only the provided USB cable for charging.
- Avoid exposing the device to extreme temperatures.
- For optimal battery longevity, avoid frequently draining the battery completely or keeping it at 100% for extended periods.

6.2. Software Updates

Regularly check for software updates to ensure your device has the latest features, security patches, and performance improvements. Go to Settings > About phone > Software update.

6.3. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials. Do not immerse the device in water.

7. Troubleshooting

If you encounter issues with your realme C53, try the following common troubleshooting steps:

- **Device not responding:** Press and hold the Power button for about 10-15 seconds to force a restart.
- **App crashing:** Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache) or reinstall the app.
- **Network issues:** Toggle Airplane Mode on and off, restart the device, or check your SIM card insertion.
- **Battery draining quickly:** Check background app usage, reduce screen brightness, or disable unnecessary features like GPS/Bluetooth when not in use.
- **Slow performance:** Clear storage, uninstall unused apps, or restart the device.

If problems persist, you may consider performing a factory data reset (Settings > System > Reset options > Erase all data (factory reset)). **Warning:** This will erase all data on your phone. Back up important data before proceeding.

8. Specifications

Feature	Detail
Model Name	realme C53
Model Number	S0454240
Operating System	Android 13, Realme UI T
Processor	Unisoc Tiger T612 (12 nm), Octa-core (2x1.8 GHz Cortex-A75 & 6x1.8 GHz Cortex-A55)
GPU	Mali-G57
RAM	8 GB
Internal Storage	256 GB

Feature	Detail
Expandable Storage	microSDXC (dedicated slot)
Display	6.74 inches IPS LCD, 1080 x 2400 pixels
Rear Camera	50MP (main) + 0.3MP (depth)
Front Camera	8MP
Battery Capacity	5000 mAh (non-removable)
Connectivity	GSM, LTE, Wi-Fi, Bluetooth, GPS
SIM Type	Dual Nano-SIM
Dimensions	5.76 x 4.38 x 4.54 inches
Item Weight	13 ounces (0.37 Kilograms)
Color	Champion Gold
Audio Jack	No headphone jack
What's in the box	USB Cable

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official realme support website. You can also contact realme customer service for assistance with product inquiries, technical support, or service requests.

Official realme Store: realme Store on Amazon

© 2024 realme. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question