## Fantovpha TS4020

# Instruction Manual

TELESYSTEM Remote Control

Model: TS4020 | Brand: Fantovpha

### Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Fantovpha TELESYSTEM TS4020 Remote Control. Designed for use with compatible TELESYSTEM receivers, this remote offers intuitive control over your television and associated functions. Please read this manual thoroughly before using the device to ensure proper functionality and longevity.

### Safety Information

- Do not expose the remote control to direct sunlight, heat sources, or extreme temperatures.
- Avoid dropping or subjecting the remote control to strong impacts.
- Do not immerse the remote control in water or any other liquids.
- Keep out of reach of children to prevent accidental ingestion of small parts or batteries.
- Dispose of used batteries according to local regulations. Do not mix old and new batteries, or different types of batteries.
- If the remote control is not functioning correctly, do not attempt to disassemble or repair it yourself. Contact customer support.

### Product Overview

The Fantovpha TELESYSTEM TS4020 remote control is a lightweight, durable device made of ABS material, designed for controlling TELESYSTEM receivers and televisions via infrared technology.




*Figure 1: Front view of the TELESYSTEM TS4020 Remote Control. This image displays the full layout of the remote, including power, navigation, numeric, and media control buttons.*



*Figure 2: Back view of the TELESYSTEM TS4020 Remote Control. This image shows the smooth back casing and the battery compartment cover located at the bottom.*

### Key Components:

- **Power Button:** Located at the top left, used to turn the device on/off.
- **Mute Button:** Located at the top right, used to mute/unmute audio.
- **Numeric Keypad (0-9):** For direct channel input and other numerical functions.
- **Navigation Buttons (Up, Down, Left, Right, OK):** For menu navigation and selection.
- **Volume Control (+/-):** Adjusts audio volume.
- **Channel Control (+/-):** Changes channels.

- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** For controlling media playback.
- **Menu Button:** Accesses the main menu.
- **Exit/Back Buttons:** To exit menus or go back to the previous screen.
- **Battery Compartment:** Located on the back for battery installation.

## Setup

### Installing Batteries:

The TELESYSTEM TS4020 remote control requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control (refer to Figure 2).
2. Press down on the tab and slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

*Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage.*

## Operating Instructions

Point the remote control directly at your TELESYSTEM receiver or television for optimal performance. Ensure there are no obstructions between the remote and the device.

### Basic Functions:

- **Power (Red Button):** Press once to turn the connected device on or off.
- **Mute:** Press to mute the audio. Press again to restore audio.
- **Volume (+/-):** Press '+' to increase volume, '-' to decrease volume.
- **Channel (+/-):** Press '+' to go to the next channel, '-' to go to the previous channel.
- **Numeric Keypad (0-9):** Use to directly enter channel numbers or other numerical inputs.

### Navigation and Menu Functions:

- **MENU:** Press to access the main menu of your TELESYSTEM receiver or television.
- **Navigation Arrows (Up, Down, Left, Right):** Use these arrows to move through menu options, lists, or adjust settings.
- **OK:** Press to confirm a selection or enter a sub-menu.
- **EXIT:** Press to exit the current menu or screen.
- **BACK:** Press to return to the previous screen or menu level.
- **INFO:** Displays information about the current program or selected item.

### Media Playback and Special Functions:

- **USB:** Likely for accessing content from a connected USB device.
- **TIMER:** For setting sleep timers or recording timers.
- **FAV:** Accesses favorite channels list.
- **TV/RAD:** Switches between TV and Radio modes.

- **PVR:** Activates Personal Video Recorder functions.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Next, Previous):**Used for controlling playback of recorded content or media files.
- **Colored Buttons (Red, Green, Yellow, Blue):**These buttons typically correspond to on-screen prompts for specific functions within menus or applications.
- **EPG:** Electronic Program Guide, displays TV listings.
- **TTX:** Teletext function.
- **AUDIO:** Selects audio tracks or modes.
- **SUB:** Activates or deactivates subtitles.

## Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use abrasive cleaners, waxes, or solvents.
- **Battery Replacement:** Replace batteries when the remote's range decreases or it stops responding. Always replace both batteries at the same time.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and moisture when not in use for extended periods.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote not responding. | Dead or incorrectly inserted batteries. Obstruction between remote and device. Remote out of range. | Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the device. |
| Buttons are sticky or unresponsive. | Dirt or debris under buttons. | Clean the remote control surface with a soft, dry cloth. Do not use liquids. |
| Limited range. | Weak batteries. Interference from other electronic devices. | Replace batteries. Move away from other devices that might cause interference. |
| Remote controls other devices unintentionally. | Infrared signal overlap with other devices. | Ensure the remote is pointed directly at the intended device. Some universal remotes may have programming conflicts (not applicable for this specific model). |

## Specifications

| | |
|---|---|
| **Model Number** | TS4020 |
| **Compatible Devices** | Television (TELESYSTEM Receivers) |
| **Connectivity Technology** | Infrared |

| | |
|---|---|
| **Material** | ABS |
| **Special Feature** | Lightweight |
| **Item Weight** | 0.48 ounces |
| **Package Dimensions** | 1 x 0.5 x 0.3 inches |

## Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your TELESYSTEM receiver or contact Fantovpha customer service directly. Keep your purchase receipt as proof of purchase.
For further assistance, please visit the manufacturer's website or contact their support line. Specific contact details may vary by region.

© 2023 Fantovpha. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question