Hatchimals 6069555

Hatchimals Alive Mystery Hatch Tigrette Interactive Toy Instruction Manual

Model: 6069555

Introduction

Welcome to the magical world of Hatchimals Alive Mystery Hatch! This interactive toy provides a unique hatching experience with mist, lights, and over 100 sounds and reactions. This manual will guide you through the setup, hatching process, and interaction features of your new Tigrette companion.

What's Included

- 1 Hatchimals Alive Mystery Hatch Egg (containing 1 Tigrette character)
- 1 Pair of Hatchi-Wings
- 1 Quick Start Guide
- 1 Instruction Sheet (this manual)
- 4 AA Batteries (pre-installed)



Image: The product packaging showing a Tigrette hatching from an egg, alongside two fully hatched Tigrette toys in light blue and orange colors.

Setup

1. Battery Installation

Your Hatchimals Alive Mystery Hatch comes with 4 AA batteries pre-installed. If replacement is needed, locate the battery compartment on the bottom of the egg. Use a Phillips head screwdriver to open the compartment, replace the old batteries with new AA batteries, ensuring correct polarity, and secure the cover.

2. Attaching Hatchi-Wings

Before beginning the hatching process, gently insert the included Hatchi-Wings into the designated slot on the base of the egg. This accessory is crucial for the hatching mechanism.



Image: A pearlescent pink Hatchimals egg with a small heart-shaped slot at its base, next to a separate pair of purple heart-shaped wings, ready for attachment.

Hatching Your Hatchimal

The hatching process is interactive and requires your care. Follow these steps to help your Tigrette hatch:

1. **Nurture the Egg:** Hold and cuddle the egg. Listen for a heartbeat. Gently tap, lift, and rock the egg to encourage your Hatchimal inside.
2. **Observe Reactions:** The egg will rock and light up, and you will hear your Hatchimal reacting from within. Continue to interact with the egg.
3. **Rainbow Glow and Mist:** Once the egg has received enough interaction, it will glow with rainbow colors, and magical mist will appear, signaling that hatching is imminent.
4. **Hatching:** Your Hatchimal will begin to hatch, singing "Hatchi-Birthday" as it emerges from the egg.



Image: Two children observing a Hatchimals egg on a table, which is glowing with internal lights and emitting a gentle mist, indicating the magical hatching experience.



Image: Two children looking intently at a Hatchimals egg that is partially cracked open, showing the top of the creature's head emerging, signifying the hatching process.

Interacting with Your Hatchimal

After hatching, your Tigrette is ready for various interactions:

- **Petting and Feeding:** Gently pet your Hatchimal to elicit happy sounds and reactions. You can also pretend to feed it.
- **Peek-a-Boo:** Cover its eyes and then reveal yourself to play peek-a-boo.
- **Teaching to Talk:** Speak to your Hatchimal, and it may repeat phrases or respond with its own sounds.
- **Kisses:** Bring your face close to its sensor for a virtual kiss.
- **Movement:** Your Hatchimal can flutter its wings, rock, and dance in response to your interactions.



Image: A child's hand interacting with an orange Hatchimals Tigrette, pressing its chest where a heart-shaped light glows, demonstrating an interactive feature.



Image: A child gently touching the nose of a light blue Hatchimals Tigrette, with musical notes depicted above the toy, indicating sound interaction.



Image: A young boy smiling and gently holding a light blue Hatchimals Tigrette toy, which has a glowing heart on its chest, showing affectionate interaction.



Image: A young girl holding an orange Hatchimals Tigrette toy in her hands, looking at it with a happy expression, highlighting the toy's portability and interactive nature.

Maintenance

- **Cleaning:** To clean your Hatchimal, gently wipe it with a slightly damp cloth. Do not immerse the toy in water or use harsh cleaning agents.
- **Storage:** When not in use, store your Hatchimal in a dry, cool place away from direct sunlight.
- **Battery Care:** If the toy will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Hatchimal not hatching or reacting.	Insufficient interaction or low batteries.	Ensure Hatchi-Wings are properly inserted. Continue to cuddle, tap, lift, and rock the egg. Replace batteries if necessary.
Sounds are distorted or weak.	Low batteries.	Replace all 4 AA batteries with new ones.
Mist feature not working.	Water reservoir empty or blockage.	Ensure the water reservoir (if applicable, check quick start guide for location) is filled with clean water. Check for any obstructions.

If problems persist, please refer to the warranty and support information.

Specifications

Product Dimensions: 6.07 x 6.07 x 7.87 inches

Item Weight: 2.25 pounds

Item Model Number: 6069555

Manufacturer Recommended Age: 5 years and up

Batteries: 4 AA batteries (included)

Manufacturer: Spin Master

Safety Information

- Adult supervision is recommended during play.
- Keep away from water and excessive moisture to prevent damage to electronic components.
- Do not attempt to open or modify the toy beyond battery replacement.
- Dispose of batteries responsibly according to local regulations.
- Not suitable for children under 3 years due to small parts (if applicable, though recommended age is 5+).

Warranty and Support

This product is covered by the Spin Master Care Commitment. For detailed warranty information, product support, or to contact customer service, please visit the official Spin Master website or refer to the contact information provided on the product packaging.
You can find more information and support at theHatchimals Store on Amazon.

© 2025 Hatchimals. All rights reserved. Spin Master.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question