ZdalaMit RM-C3287

RM-C3287 Replacement Voice Remote Control Commander User Manual

Model: RM-C3287 | Brand: ZdalaMit

Introduction

This user manual provides comprehensive instructions for the ZdalaMit RM-C3287 Replacement Voice Remote Control Commander. This remote is designed to be compatible with JVC Smart Android TVs, offering voice control capabilities and essential functions for navigating your television. Please read this manual thoroughly before use to ensure proper operation and longevity of your device.

Product Overview

The RM-C3287 remote control features a user-friendly layout with dedicated buttons for common functions and streaming services. It is designed for comfortable handling and intuitive operation.





Figure 1: Front view of the RM-C3287 remote control. This image displays the full layout of the remote, highlighting the power button, quick access buttons for streaming services like Netflix and YouTube, the central navigation pad with an OK button, volume controls, channel controls, and colored function buttons at the bottom.


NETFLX
YuTbe
prm video
Gogle Play
OK
VOL
P



Figure 2: RM-C3287 remote control highlighting voice control. This image shows the remote alongside a microphone icon, emphasizing its voice command capabilities for hands-free operation and search functions.

Key Features:

- Direct replacement for original JVC Smart Android TV remotes.
- Integrated voice control for convenient command input.
- Dedicated buttons for popular streaming applications (Netflix, YouTube, Prime Video, Google Play).
- Ergonomic design for comfortable grip and use.

Setup

1. Battery Installation

The RM-C3287 remote control requires two (2) AAA size alkaline batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Note: *Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.*

2. Pairing the Remote Control

This remote control requires pairing with your JVC Smart Android TV to enable full functionality, especially voice control. The exact pairing procedure may vary slightly depending on your specific TV model. Please refer to your TV's user manual for detailed pairing instructions. A common pairing method is as follows:

1. Ensure your JVC Smart Android TV is powered on.
2. On your TV, navigate to the **Settings** menu. This is often accessible via a gear icon or a dedicated button on your original remote.
3. Look for options such as **Remotes & Accessories**, **Bluetooth Settings**, or **Add Device**.
4. Select the option to add a new device or pair a new remote control.
5. On the RM-C3287 remote, press and hold the **OK** button and the **Volume Down (-)** button simultaneously for a few seconds until an indicator light on the remote (if present) flashes or a pairing message appears on your TV screen.
6. Your TV should detect the "RM-C3287" or a similar device name. Select it to complete the pairing process.
7. Once successfully paired, a confirmation message will appear on your TV screen, and the remote should now be fully functional.

Tip: *If pairing fails, ensure the remote is close to the TV and try repeating the steps. You may also need to restart your TV.*

Operating Instructions

Once paired, the RM-C3287 remote control operates similarly to your original JVC Smart Android TV remote.

Basic Navigation:

- **Power Button ( ):** Turns the TV on or off.
- **Navigation Pad (Up, Down, Left, Right):** Moves the cursor or selection on the TV screen.
- **OK Button:** Confirms a selection or enters a menu.

- **Back Button (←):** Returns to the previous screen or menu.
- **Home Button (⌂):** Returns to the TV's home screen.
- **Volume Up/Down (+/- VOL):** Adjusts the TV volume.
- **Mute Button ( ):** Mutes or unmutes the TV sound.
- **Channel Up/Down (P ▲/▼):** Changes TV channels.

Voice Control:

To use the voice control feature, press the dedicated **Voice Assistant Button** (often represented by a microphone icon or Google Assistant logo) on the remote. Hold the button down while speaking your command clearly into the remote's microphone. Release the button when you are finished speaking.
Examples of voice commands include:

- "Open Netflix"
- "Search for action movies"
- "What's the weather like?"
- "Turn up the volume"

Quick Access Buttons:

The remote includes dedicated buttons for popular streaming services:

- **NETFLIX:** Launches the Netflix application.
- **YouTube:** Launches the YouTube application.
- **prm video (Prime Video):** Launches the Amazon Prime Video application.
- **Google Play:** Launches the Google Play Store or Google Play Movies & TV.

Maintenance

Battery Replacement:

When the remote control's performance degrades or it becomes unresponsive, it is likely time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section. Always replace both AAA batteries simultaneously with new ones.

Cleaning:

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals, abrasive cleaners, or immerse the remote in water.

Storage:

If the remote control will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage to the device.

Troubleshooting

Problem	Possible Cause	Solution
Remote is unresponsive or intermittent.	• Low or dead batteries. • Remote not properly paired. • Obstruction between remote and TV.	• Replace batteries with new AAA alkaline batteries. • Re-pair the remote control with your TV (refer to "Pairing the Remote Control" section). • Ensure a clear line of sight to the TV's IR receiver (if applicable) or that Bluetooth is enabled on the TV.

Problem	Possible Cause	Solution
Voice control is not working.	• Remote not paired for voice functionality. • Microphone blocked or damaged. • TV's voice assistant settings.	• Ensure the remote is fully paired, including Bluetooth for voice. • Check for any obstructions over the microphone hole. • Verify voice assistant settings on your JVC Smart Android TV.
Batteries drain quickly.	• Faulty batteries. • Remote constantly transmitting (e.g., stuck button). • Compatibility issue (less common).	• Try a different brand of high-quality alkaline batteries. • Check if any buttons are physically stuck. • If the issue persists, contact customer support.

Specifications

Model Number	RM-C3287
Brand	ZdalaMit
Compatible Devices	JVC Smart Android TV
Power Source	2 x AAA Batteries (not included)
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	1.76 ounces
Color	Black
Special Feature	Ergonomic, Voice Control

Warranty and Support

For any issues not covered in this manual, or for further assistance, please contact the retailer or manufacturer's customer support. Keep your purchase receipt as proof of purchase for any warranty claims.
While specific warranty details are not provided here, most electronic accessories come with a limited warranty against manufacturing defects. Please refer to the product packaging or the seller's policy for precise warranty terms and conditions.

© 2025 ZdalaMit. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.