Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Glitzhome 2035100001-1

Glitzhome Interchangeable Home Table Signs User Manual

Model: 2035100001-1

1. Product Overview

The Glitzhome Interchangeable Home Table Signs set is a decorative item designed to enhance your home decor throughout the year. It features the letters "H", "M", "E" and a collection of 10 interchangeable seasonal icons that replace the letter "O" to suit various holidays and seasons.

This set allows for customization to celebrate events such as Valentine's Day, St. Patrick's Day, Easter, Independence Day, Halloween, Thanksgiving, and Christmas, as well as general spring, summer, and winter themes.



Image: Close-up view of the wooden letters and interchangeable icons, highlighting the wood material, hand-sanded edges, and 1.10-inch thickness.

2. Package Contents

Your package includes 13 pieces of wooden decorative items:

- 3 x Wooden Letters: H, M, E
- 10 x Interchangeable Seasonal Icons: Pumpkin, Snowman, Snowflake, Turkey, Bunny, Flower, Clover, Star, Heart, Butterfly



Image: All components of the set, including the letters and various seasonal icons, with approximate dimensions of 4.68 inches wide by 5.00 inches high and 1.10 inches thick.

3. Setup Instructions

1. **Unpack Components:** Carefully remove all 13 pieces from the packaging. Inspect each piece for any damage.
2. **Choose Placement:** Select a flat, stable surface for display, such as a desktop, shelf, mantelpiece, or kitchen counter.
3. **Arrange Letters:** Place the wooden letters "H", "M", and "E" in their desired positions.
4. **Insert Seasonal Icon:** Choose one of the 10 seasonal icons to represent the letter "O" in "HOME". Gently place the chosen icon between the "H" and "M" letters. Ensure it is stable and upright.



Image: The "HOME" sign with a pumpkin icon, set up as a Halloween decoration on a table.

4. Operating Instructions

The primary operation of this product involves interchanging the seasonal icons to match different holidays or times of the year.

1. **Select Icon:** Choose the icon that corresponds to the current season or upcoming holiday (e.g., Snowflake for winter, Heart for Valentine's Day).
2. **Replace Icon:** Carefully remove the currently displayed icon from the "O" position. Place the new chosen icon into the space between the "H" and "M" letters.
3. **Store Unused Icons:** Keep the unused icons in a safe place to prevent loss or damage. The original packaging can be used for storage.



Image: The "HOME" sign featuring a snowman icon, suitable for winter or Christmas decor.

Your browser does not support the video tag.

Video: An official demonstration by Glitzhome showcasing the interchangeable nature of the HOME table signs and various seasonal icons.

5. Maintenance

- **Cleaning:** To clean the wooden letters and icons, gently wipe them with a soft, dry cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish or paint.
- **Storage:** When not in use, store the interchangeable icons in a cool, dry place away from direct sunlight and extreme temperature fluctuations. This helps prevent warping, fading, or cracking of the wood.
- **Handling:** Handle all pieces with care to avoid chipping the edges or scratching the painted surfaces.

6. Troubleshooting

Issue	Possible Cause	Solution
Sign appears unstable or wobbly.	Uneven surface; pieces not properly seated.	Ensure the display surface is flat and level. Gently press down on each letter and icon to ensure they are firmly seated.
Interchangeable icon does not fit correctly.	Icon misalignment; minor manufacturing variation.	Verify that the icon is oriented correctly. Gently adjust its position. Avoid forcing the icon into place.
Paint or finish appears dull.	Dust accumulation; exposure to harsh conditions.	Wipe with a soft, dry cloth. Ensure the product is not exposed to direct sunlight for prolonged periods or high humidity.

7. Specifications

Feature	Detail
Product Name	Wooden Interchangeable HOME Sign
Brand	Glitzhome
Model Number	2035100001-1
Material	Wood
Overall Size (each block)	Approximately 4.68" W x 5.00" H x 1.10" D
Number of Items	13 (3 letters + 10 icons)
Mounting Type	Tabletop, Freestanding
Theme	Seasonal, Holiday, Farmhouse, Rustic

8. Warranty and Support

This product is intended for decorative use. For any questions regarding product defects or assistance, please contact Glitzhome customer support through the retailer where the product was purchased. Please retain your proof of purchase for any inquiries.

© 2026 Glitzhome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTLRVHLH

More documents and user manuals: **https://manuals.plus/**