Ariete 4626

Ariete 4626 6L Air Fryer Instruction Manual

Model: 4626

1. Introduction

Thank you for choosing the Ariete 4626 6L Air Fryer. This appliance is designed to provide a healthier way to enjoy your favorite fried foods by using hot air circulation. With its generous 6-liter capacity and 1300W power, you can prepare a variety of dishes with minimal oil. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Figure 1.1: The Ariete 4626 6L Air Fryer, showcasing its digital display and transparent cooking basket.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

3. Product Components

The Ariete 4626 Air Fryer consists of the main unit, a removable cooking basket, and a digital control panel. The transparent window on the basket allows for easy monitoring of the cooking process.



Figure 3.1: Key features of the Ariete 4626 Air Fryer, including its 6L capacity and hot air cooking technology.

- **Main Unit:** Houses the heating element and fan.
- **Cooking Basket:** Removable, non-stick basket with a grill insert for food. Features a transparent window.
- **Digital Control Panel:** Touchscreen interface for setting time, temperature, and selecting preset programs.
- **Handle:** For safely pulling out and inserting the cooking basket.

4. Setup

1. **Unpack:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Clean:** Wash the cooking basket and grill insert with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface, ensuring adequate space (at least 10 cm) around the appliance for proper ventilation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The appliance will enter standby mode.

5. Operating Instructions

5.1 Basic Operation

1. **Power On:** Press the power button on the digital control panel to turn on the air fryer.
2. **Prepare Food:** Place your food into the cooking basket. For best results, do not overfill the basket. For some recipes, a small amount of oil (approximately one tablespoon) may be added directly to the food for enhanced crispiness.
3. **Set Temperature and Time:** Use the temperature and time adjustment buttons (usually '+' and '-' symbols) to set your desired cooking parameters. The temperature can be adjusted from 80°C to 200°C.
4. **Start Cooking:** Press the start button to begin the cooking cycle.
5. **Monitor Progress:** Utilize the transparent basket to visually check the cooking progress without opening the drawer.
6. **Shake/Flip (Optional):** For even cooking, especially with items like fries, pull out the basket halfway through the cooking time and shake or flip the food. Reinsert the basket to resume cooking.
7. **Finish:** The air fryer will beep when the cooking cycle is complete. Carefully pull out the basket and remove the food.
8. **Power Off:** Press the power button to turn off the appliance. Unplug from the wall outlet when not in use.

5.2 Using Preset Programs

The Ariete 4626 features 8 preset programs for common dishes. These programs automatically set optimal temperature and time for specific foods.



Figure 5.1: The digital control panel displaying the 8 preset cooking programs.

To use a preset program:

1. Power on the air fryer.
2. Press the 'M' (Mode) button to cycle through the available preset programs.
3. Once the desired program icon is selected, the display will show the default time and temperature.
4. You can adjust the time and temperature manually if needed, even after selecting a preset.
5. Press the start button to begin cooking.

The 8 preset programs include:

- Fries
- Fresh Potatoes
- Red Meat
- Fish
- Chicken

- Pizza
- Desserts
- Defrosting

6. Cooking Tips

- **Minimal Oil:** For many foods, especially frozen pre-fried items, no additional oil is needed. For fresh ingredients, a tablespoon of oil can enhance crispiness.
- **Even Cooking:** Shake the basket or flip food items halfway through the cooking time for more even results.
- **Preheating:** While not always necessary, preheating the air fryer for 3-5 minutes at the desired temperature can improve cooking times and crispiness for some foods.
- **Batch Cooking:** If cooking large quantities, cook in smaller batches to ensure even air circulation and optimal results.
- **Food Variety:** The air fryer is suitable for a wide range of foods, including vegetables, meats, fish, and baked goods. Experiment with different recipes.



Figure 6.1: Demonstrating the minimal oil required for air frying.



Figure 6.2: Examples of diverse dishes prepared with the air fryer.

7. Maintenance and Cleaning

Regular cleaning will ensure the longevity and optimal performance of your Ariete 4626 Air Fryer.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Clean Basket and Grill:** The non-stick cooking basket and grill insert are dishwasher safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
3. **Clean Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. **Heating Element:** If necessary, gently clean the heating element with a soft brush to remove any food residue. Ensure the appliance is completely cool and unplugged.
5. **Storage:** Store the cleaned and dried air fryer in a cool, dry place.

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Air fryer does not turn on	Appliance not plugged in; Power outlet not working; Power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button.
Food is not cooked evenly	Basket is overfilled; Food not shaken/flipped; Incorrect temperature/time.	Cook in smaller batches. Shake or flip food halfway through. Adjust temperature and time as needed.
Food is not crispy	Not enough oil (for fresh food); Temperature too low; Cooking time too short.	Add a small amount of oil to fresh food. Increase temperature or cooking time. Ensure food is not overcrowded.
White smoke coming from appliance	Grease residue from previous use; Fatty food being cooked.	Clean the basket and grill thoroughly after each use. For fatty foods, drain excess fat during cooking.

9. Specifications

Technical details for the Ariete 4626 6L Air Fryer:

- **Brand:** Ariete
- **Model Number:** 4626
- **Color:** White
- **Capacity:** 6 Liters
- **Power:** 1300 Watts
- **Material:** Plastic
- **Product Dimensions (L x W x H):** 23 x 35 x 33 cm
- **Item Weight:** 5.4 Kilograms
- **Temperature Range:** 80°C to 200°C
- **Special Feature:** Programmable, Transparent Basket



Figure 9.1: Physical dimensions of the Ariete 4626 Air Fryer.

10. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or contact Ariete customer service directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question