Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kircuit 9V AC/DC Adapter

Kircuit 9V AC/DC Adapter User Manual

Model: 9V AC/DC Adapter

Compatible with Wockoder Turntables: KD-3010, KD-3010BL, KD-3011, KD-3011BL, KD-7001, KD-7001BL

1. Introduction

This manual provides essential instructions for the safe and effective use of your Kircuit 9V AC/DC Adapter. This power supply is designed to convert standard AC wall power into the specific DC power required by compatible Wockoder portable briefcase turntables. It serves as a reliable power source for operating your device or charging its internal battery.



Image 1.1: The Kircuit 9V AC/DC Adapter, showing the main unit with two prongs for wall outlets and the attached power cord terminating in a barrel plug connector.

2. Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or damage to the adapter or connected device.

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose it to rain, moisture, or extreme temperatures.
- **Correct Voltage:** Ensure the wall outlet voltage (100-240V AC) matches the adapter's input specifications.
- **Compatible Devices:** Only use this adapter with the specified Wockoder turntable models (KD-3010, KD-3010BL, KD-3011, KD-3011BL, KD-7001, KD-7001BL) or other devices requiring 9V DC and a maximum of 1.5A with a compatible barrel plug. Using it with incompatible devices may cause damage.
- **Avoid Overloading:** Do not connect devices that exceed the adapter's maximum output current of 1.5A.
- **Proper Handling:** Do not modify, disassemble, or drop the adapter. Keep it away from heat sources and sharp objects.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use for extended periods.
- **Children and Pets:** Keep the adapter out of reach of children and pets.

3. Package Contents

Verify that all items are present in the package:

- 1 x Kircuit 9V AC/DC Adapter

4. Setup

Follow these steps to set up your Kircuit 9V AC/DC Adapter:

1. **Inspect the Adapter:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
2. **Connect to Device:** Locate the power input port on your Wockoder turntable. Carefully insert the barrel plug connector of the adapter into the device's power input port. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the adapter's prongs into a standard 100-240V AC wall power outlet.
4. **Verify Power:** Once connected, your device should receive power. Refer to your device's manual for specific power indicators.



Image 4.1: The Kircuit 9V AC/DC Adapter shown plugged into a power strip, illustrating a typical setup scenario.

5. Operating

Once properly connected, the adapter provides continuous power to your compatible Wockoder turntable. It is designed for reliable operation and features built-in dynamic IC, charger IC, and power fuse for rapid charging and overcharge protection, ensuring the safety of your device.

6. Maintenance

Proper care and maintenance will extend the life of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use. Avoid tightly

coiling the cable to prevent damage.

- **Cable Care:** Do not pull on the cable to disconnect the adapter. Always grasp the plug firmly. Avoid placing heavy objects on the cable or bending it sharply.

7. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

- **No Power to Device:**
  - Ensure the adapter is securely plugged into both the wall outlet and the device.
  - Check if the wall outlet is functional by plugging in another device.
  - Verify that your device is compatible with this 9V DC, 1.5A adapter.
- **Adapter Feels Hot:**
  - It is normal for adapters to feel slightly warm during operation. If it becomes excessively hot or emits a burning smell, immediately unplug it and discontinue use.
  - Ensure adequate ventilation around the adapter.
- **Device Not Charging/Operating Correctly:**
  - Confirm the adapter's specifications (9V DC, 1.5A) match your device's power requirements.
  - Inspect the barrel plug and device's power port for any debris or damage.

If problems persist, contact the manufacturer or seller for further assistance.

8. Specifications

Input Voltage	100-240V AC, 50/60Hz
Output Voltage	9V DC
Output Current	1.5A (Max)
Connector Type	Barrel Plug
Cord Length	Approximately 6.5 feet (2 meters)
Special Features	Dynamic IC, Charger IC & Power fuse for rapid charging and over charge protection.
Compatible Devices	Wockoder KD-3010, KD-3010BL, KD-3011, KD-3011BL, KD-7001, KD-7001BL Turntables



Image 8.1: The Kircuit 9V AC/DC Adapter with its power cord, indicating a length of 6.5 feet.

9. Warranty and Support

Specific warranty details for this Kircuit 9V AC/DC Adapter are not provided in this manual. For warranty information, technical support, or customer service inquiries, please refer to the product packaging or contact the seller or manufacturer directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTSXPM8Y

More documents and user manuals: **https://manuals.plus/**