Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mr.Go LED Ball Light Bundle (10-inch, 8-inch, 6-inch)

Mr.Go LED Ball Light Bundle User Manual

Models: 10-inch, 8-inch, 6-inch RGB Rechargeable Waterproof LED Ball Lights

Introduction

Thank you for choosing the Mr.Go LED Ball Light Bundle. This manual provides essential information for the safe and optimal use of your 10-inch, 8-inch, and 6-inch RGB rechargeable and waterproof LED ball lights. These versatile lights are designed to enhance any indoor or outdoor setting with vibrant colors and adjustable ambiance.

Safety Information

- Keep the lights away from open flames or extreme heat sources.
- Do not attempt to disassemble or modify the lights. This will void the warranty and may cause damage.
- Use only the provided charging cable and adapter (if included) to charge the lights.
- Ensure the charging port is completely dry before charging to prevent electrical hazards.
- Though waterproof, avoid submerging the lights for extended periods or in deep water.
- Keep the remote control batteries out of reach of children.

Package Contents

Your Mr.Go LED Ball Light Bundle includes:

- 1 x 10-inch LED Ball Light
- 1 x 8-inch LED Ball Light
- 1 x 6-inch LED Ball Light
- 1 x Remote Control
- 1 x USB Charging Cable (or multiple, depending on packaging)
- 1 x User Manual (this document)

Setup

1. Charging the LED Ball Lights

Before first use, fully charge each LED ball light. Locate the charging port, typically at the bottom of the light. Connect the provided USB charging cable to the light and to a compatible USB power adapter (not included) or computer USB port. The indicator light will show charging status (e.g., red for charging, green for fully charged). A full charge typically takes 4-6 hours.

Note: Ensure the charging port is dry before connecting the cable.

2. Remote Control Battery Installation

The remote control requires a CR2025 button cell battery (usually pre-installed with a protective tab). If the remote is not working, check the battery.

1. Locate the battery compartment on the back or side of the remote control.
2. If a plastic tab is present, pull it out to activate the battery.
3. If replacing the battery, slide out the battery tray or open the compartment, insert a new CR2025 battery with the positive (+) side facing up, and close the compartment.



Image: Detailed view of the Mr.Go remote control, showing buttons for power, color selection, mode, and brightness. Note the instruction to remove the clear plastic piece before using.

Operating Instructions

Use the provided remote control to operate your Mr.Go LED Ball Lights. Ensure the remote is pointed towards the light within its operating range (16 to 26 feet).

Remote Control Functions:

- **Power ON/OFF:** Press the **ON** button to turn the light on, and the**OFF** button to turn it off.
- **Static Colors:** Select from 16 preset RGB colors by pressing the corresponding color buttons.
- **Brightness Adjustment:** Use the **+** and **-** buttons (labeled "Static Brightness") to increase or decrease the brightness of the static color.
- **Dynamic Modes:**
  - **FLASH:** Light jumps through RGB colors.
  - **STROBE:** Light strobes in white color.
  - **FADE:** Light fades in and out through RGB colors.
  - **SMOOTH:** Light gradually cycles through RGB colors.
- **Dynamic Speed Adjustment:** Use the **+** and **-** buttons (labeled "Dynamic Speed") to adjust the speed of the selected dynamic mode.



Image: Visual representation of the 16 RGB colors available and the dimming capability of the Mr.Go LED ball lights, showing brightness levels from 20% to 100% and corresponding battery life.

Maintenance

Cleaning

To clean your LED ball lights, wipe them with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the surface or internal components.

Water Resistance

The Mr.Go LED Ball Lights are designed to be waterproof. They are suitable for outdoor use and can withstand rain or splashes. However, avoid prolonged submersion in water or exposing the charging port to water when not securely sealed.

Battery Care

- For optimal battery life, avoid completely draining the battery frequently.

- If storing the lights for an extended period, charge them to about 50% every 3 months to prevent deep discharge.
- Replace the remote control battery (CR2025) when its range or responsiveness decreases.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted. Remote control battery is dead or tab not removed. Light is faulty.	Charge the light fully. Replace remote battery or remove protective tab. Contact customer support if charging does not resolve the issue.
Remote control not working.	Protective tab still in place. Battery is dead. Out of range or obstructed.	Remove the clear plastic tab from the battery compartment. Replace the CR2025 battery. Ensure remote is pointed at the light and within 16-26 feet, without major obstructions.
Colors are not changing or light is stuck on one color.	Remote signal issue. Light internal error.	Ensure remote is working correctly (check battery). Try turning the light off and on again.
Light flickers or dims unexpectedly.	Low battery. Environmental interference.	Recharge the light. Move the light away from strong electromagnetic sources.

Specifications

- **Product Dimensions:** 10-inch, 8-inch, and 6-inch diameter spheres
- **Light Source:** LED
- **Colors:** 16 RGB colors
- **Modes:** Flash, Strobe, Fade, Smooth
- **Control Method:** IR Remote Control
- **Power Source:** Rechargeable Battery
- **Material:** Plastic (Shade Material: Plastic)
- **Water Resistance:** Waterproof
- **Indoor/Outdoor Usage:** Indoor and Outdoor
- **Battery Life:** Up to 48+ hours (dim), 8 hours (bright)
- **Model Number:** 647ef28f-16f9-4fe5-8867-390fa493d75c

Warranty and Support

Specific warranty details are not provided in the product information. For warranty claims, technical support, or further inquiries, please refer to the retailer where you purchased the product or visit the official Mr.Go store on Amazon:

Visit the Mr.Go Store on Amazon

© 2023 Mr.Go. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTX6GTLW

More documents and user manuals: **https://manuals.plus/**