Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Innoteck DS-5393

Innoteck Essentials Electric Salt and Pepper Mill Set User Manual

Model: DS-5393

Introduction

Thank you for choosing the Innoteck Essentials Electric Salt and Pepper Mill Set. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new electric mills. Please read these instructions thoroughly before first use and retain them for future reference.



Image: The Innoteck Essentials Electric Salt and Pepper Mill Set, showcasing its sleek grey design and transparent chambers filled with spices.

Safety Instructions

- Keep out of reach of children.

- Do not immerse the motor unit in water or any other liquid.
- Use only the specified battery type (AA batteries, not included).
- Remove batteries if the mills will not be used for an extended period.
- Do not attempt to grind anything other than dry salt crystals or whole peppercorns.
- Avoid contact with moving parts during operation.

Package Contents

- 2 x Innoteck Essentials Electric Mills (Grey)
- 1 x User Manual

Setup

1. Battery Installation

1. Twist the top section of the mill counter-clockwise to separate it from the transparent spice chamber.
2. Insert 4 x AA batteries (not included) into the battery compartment, ensuring correct polarity (+/-).
3. Align the top section with the spice chamber and twist clockwise to secure.



Image: Visual representation of key features including battery operation, indicating where batteries are installed.

2. Filling the Mills

1. Unscrew the transparent spice chamber from the main body of the mill.
2. Fill the chamber with your desired dry salt crystals or whole peppercorns. Do not overfill.
3. Screw the transparent spice chamber back onto the main body until securely fastened.

Operating Instructions

1. Grinding Spices

- Remove the base cap from the bottom of the mill.
- Hold the mill over your food or dish.
- Press and hold the button located on the top of the mill to activate the grinding mechanism. The built-in LED light will illuminate during operation.

- Release the button to stop grinding.



Image: The mill in action, demonstrating the LED light indicator for precise seasoning.

2. Adjusting Coarseness

- Locate the adjustable knob at the bottom of the mill, above the grinding mechanism.
- Turn the knob clockwise for a finer grind.
- Turn the knob counter-clockwise for a coarser grind.
- Test the grind setting on a plate before applying to food.

Maintenance and Care

1. Cleaning

- Wipe the exterior of the mill with a soft, damp cloth to remove fingerprints and dust.

- The transparent spice chamber can be rinsed under running water. Ensure it is completely dry before reattaching.
- Do not immerse the main body (motor unit) in water or place it in a dishwasher.
- Ensure all parts are thoroughly dry before reassembling and storing.



Image: The base cap design, which helps keep counters clean and protects the grinding mechanism.

2. Refilling

- When the transparent chamber appears low, unscrew it from the top section.
- Refill with your chosen dry salt or peppercorns.
- Screw the chamber back onto the top section until secure.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Mill does not grind.	Batteries are depleted or incorrectly installed. Spice chamber is empty. Grinding mechanism is jammed.	Check and replace batteries, ensuring correct polarity. Refill the spice chamber. Clear any obstructions from the grinding mechanism.
LED light does not illuminate.	Batteries are depleted or incorrectly installed. Connection issue.	Check and replace batteries. Ensure the top section is securely twisted onto the chamber.
Inconsistent grind.	Coarseness setting needs adjustment. Spice chamber is low.	Adjust the coarseness knob at the bottom of the mill. Refill the spice chamber.

Specifications

- **Brand:** Innoteck
- **Model Number:** DS-5393
- **Colour:** Grey
- **Product Dimensions:** 5.5 cm (Diameter) x 22.5 cm (Height)
- **Item Weight:** 720 g (for the set)
- **Material:** Stainless Steel, Acrylic, Ceramic
- **Operation Mode:** Automatic (One-Touch)
- **Power Source:** 4 x AA Batteries per mill (NOT INCLUDED)
- **Grinding Mechanism:** Ceramic
- **Dishwasher Safe:** No

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Innoteck website. Keep your proof of purchase for any warranty claims.
For further assistance, please contact Innoteck customer service through their official channels.

© 2024 Innoteck. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CV129987

More documents and user manuals: **https://manuals.plus/**