Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEGO 43253

LEGO Disney Advent Calendar 2024 Instruction Manual

Model: 43253

Introduction

This instruction manual provides essential information for the LEGO Disney Advent Calendar 2024, Model 43253. This set is designed for children aged 5 and up, offering a daily building experience leading up to Christmas. It includes 253 pieces, featuring Disney micro-doll figures and mini-builds.
The Advent Calendar box transforms into a game board, enhancing the play experience for up to 5 players. Each day reveals a new festive build or character, encouraging creative play and storytelling.

Safety Information

WARNING: CHOKING HAZARD - Small Parts.
This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended during assembly and play, especially for younger children within the recommended age range.

What's Included

The LEGO Disney Advent Calendar 2024 (Model 43253) contains 253 LEGO building elements. Key components include:

- Elsa micro-doll figure
- Tiana micro-doll figure
- Ariel micro-doll figure
- Mirabel micro-doll figure
- Moana micro-doll figure
- Pua character
- Snowgie character
- Baby reindeer Sven character
- Various mini-builds such as a seesaw for the Snowgie, Ariel’s undersea palace, Moana’s mini boat, Elsa’s ice palace, a sled, and a Christmas tree.
- The Advent Calendar box, which converts into a game board.



Image: The LEGO Disney Advent Calendar 2024 box, showing two children interacting with the opened calendar and its mini-builds on the game board.



Image: Close-up of the included micro-doll figures and characters: Sven, Elsa, Snowgie, Moana, Mirabel, Ariel, and Tiana.

Setup

1. **Unpack the Calendar:** Carefully remove the Advent Calendar box from its packaging.
2. **Open the Calendar:** The front panel of the box can be folded down to reveal a festive game board. Ensure the calendar stands upright.
3. **Locate Day 1:** Identify the first numbered door on the calendar.



Image: The Advent Calendar box opened flat, showing the game board design and various mini-builds placed on it.

Your browser does not support the video tag.

Video: A 7-second preview demonstrating the LEGO Disney Princess Advent Calendar 2024 (Model 43253) in a 360-degree spin, showcasing its design and features.

Operating Instructions

1. **Daily Discovery:** Starting from December 1st, open one numbered door each day.

2. **Assemble Mini-Builds:** Inside each door, you will find LEGO elements to build a small model or a micro-doll figure. Follow the included mini-instructions for assembly.
3. **Engage with the Game Board:** Once assembled, place the mini-builds and figures on the game board. The board provides a backdrop for imaginative play and can be used for a simple game with up to 5 players.
4. **Combine with Other Sets:** The mini-builds and figures are compatible with other LEGO Disney building kits and general LEGO sets (sold separately), allowing for expanded play scenarios.



Image: A detailed view of the Elsa micro-doll figure on a sled, accompanied by a Snowgie on a seesaw, and an ice palace mini-build.



Image: A close-up of the Ariel micro-doll figure next to her undersea palace mini-build and other small treasures.

Maintenance

- **Cleaning:** To clean LEGO elements, use a soft cloth dampened with water and a mild soap. Rinse thoroughly and air dry. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store LEGO elements in a cool, dry place away from direct sunlight to prevent discoloration or damage. Keep small parts organized to avoid loss.
- **Handling:** Handle LEGO elements gently to prevent breakage. Do not force pieces together if they do not fit easily.

Troubleshooting

Issue	Solution

Issue	Solution
Missing Piece	Carefully check all packaging materials. If a piece is genuinely missing, contact LEGO Customer Service for assistance.
Difficulty Assembling	Refer to the mini-instructions provided with each daily build. Ensure pieces are oriented correctly. Do not force pieces.
Damaged Piece	If a piece is damaged upon opening, contact LEGO Customer Service for a replacement.

Specifications

- **Brand:** LEGO
- **Model Number:** 43253
- **UPC:** 673419391184
- **Number of Pieces:** 253
- **Recommended Age:** 5 years and up
- **Material:** Plastic
- **Item Weight:** 14.08 ounces
- **Item Dimensions:** 15.04 x 10.32 x 2.78 inches
- **Included Characters:** Elsa, Tiana, Ariel, Mirabel, Moana, Pua, Snowgie, Sven

Warranty

This product is provided without a manufacturer's warranty. For any issues or concerns, please refer to the troubleshooting section or contact LEGO Customer Service.

Support

For further assistance, missing parts, or product inquiries, please visit the official LEGO website or contact their customer service department.
Official LEGO Website: www.lego.com

© 2024 LEGO Group. All rights reserved. Disney elements © Disney.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CV2DXF71

More documents and user manuals: **https://manuals.plus/**