Ninja R-SFP701

Ninja R-SFP701 14-in-1 Multicooker, Oven & Air Fryer Instruction Manual

1. Product Overview

The Ninja R-SFP701 is a versatile 14-in-1 multicooker designed to simplify your cooking experience. It combines the functionalities of a multicooker, oven, and air fryer, allowing you to prepare a wide variety of meals efficiently. This appliance is engineered for convenience, offering multiple cooking modes and easy cleanup.

Key Features:

- **14-in-1 Versatility:** Offers Combi Meals, Combi Crisp, Combi Bake, Rice/Pasta, Sear/Sauté, Steam, Bake, Toast, Pizza, Slow Cook, Proof, Sous Vide, Air Fry, and Broil functions.
- **Rapid Meal Preparation:** Cook complete meals including proteins, vegetables, and grains simultaneously, achieving results up to 50% faster than a traditional wall oven.
- **Ninja Combi Cooker Technology:** Utilizes HyperSteam for juicy interiors and rapid cyclonic air for crispy exteriors.
- **No Defrosting Required:** Super-heated steam thaws frozen ingredients and cooks them to a safe temperature in under 30 minutes.
- **Family-Sized Capacity:** Designed to feed up to 8 people, accommodating large roasts, pizzas, and significant quantities of pasta or rice.
- **Easy Cleanup:** All included accessories are dishwasher safe, and the Combi Cooker Pan doubles as a serving dish.



Image: A collage showcasing the 14-in-1 functionality with various dishes like pizza, salmon with asparagus and rice, nachos, proofed dough, french fries, cookies, plain rice, pasta dishes, roasted vegetables, and toast.

2. What's Included

Your Ninja R-SFP701 package includes the following components:

- Ninja R-SFP701 Countertop Multicooker Unit
- Combi Cooker Pan
- Bake Tray
- Crisper Tray
- Quick Start Guide / Recipe Book



Image: The Ninja Combi Multicooker displayed with its included accessories: the Combi Cooker Pan, Bake Tray, and Crisper Tray.

3. Setup Instructions

Before first use, ensure all packaging materials are removed from the unit and accessories. Place the multicooker on a clean, stable, and heat-resistant surface. Ensure adequate clearance around the unit for proper ventilation.

Initial Setup Steps:

1. **Unpack the Unit:** Carefully remove the Ninja R-SFP701 from its packaging.
2. **Remove Internal Packaging:** Open the front door and remove any cardboard inserts, plastic bags, or protective materials from inside the cooking chamber.
3. **Wash Accessories:** Wash the Combi Cooker Pan, Bake Tray, and Crisper Tray with warm, soapy water. Rinse thoroughly and dry completely.
4. **Placement:** Position the unit on a countertop, ensuring it is at least 6 inches away from walls or other appliances to allow for proper airflow.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Video: An unboxing and setup guide for the Ninja Combi, demonstrating how to remove packaging and place accessories. This video provides a visual walkthrough of the initial setup process.

4. Operating Instructions

The Ninja R-SFP701 features an intuitive control panel with various functions for diverse cooking needs. The control panel is located on the right side of the unit and allows for easy selection of cooking modes, temperature, and time.

Control Panel Overview:

- **Power Button:** Turns the unit on/off.
- **Temperature/Shade Controls:** Adjusts cooking temperature or toast shade.
- **Time/Slices Controls:** Adjusts cooking time or number of toast slices.
- **Function Button:** Cycles through available cooking functions.
- **Start/Stop Button:** Initiates or pauses the cooking cycle.
- **Light Button:** Illuminates the interior of the cooking chamber.

Using Combi Cooker Modes:

For Combi Cooker modes (Combi Meals, Combi Crisp, Combi Bake, Steam, Proof, Rice/Pasta), ensure the top lid is in the closed position. These modes often utilize HyperSteam technology for optimal results.

- **Combi Meals:** Cook proteins, vegetables, and grains simultaneously. Refer to the unit's internal guide for water recommendations and tray levels.
- **Combi Crisp:** Ideal for perfectly crispy, juicy proteins and vegetables without drying out. Add water as recommended for smaller proteins/veggies or larger roasts.
- **Combi Bake:** For higher-rise cakes and breads with better crusts. Unit will steam for 20 minutes, then begin convection heating. Reduce cook times by half compared to conventional recipes.

Using Air Fry / Stovetop Modes:

For Air Fry / Stovetop modes (Air Fry, Bake, Broil, Pizza, Toast, Sear/Sauté, Slow Cook, Sous Vide), ensure the top lid is in the open position. These modes utilize convection heat or direct heat for cooking.

- **Air Fry:** Achieve crispy results with little to no oil. Use the Crisper Tray for best airflow.
- **Bake/Roast:** Use the Bake Tray for traditional oven cooking.
- **Toast:** Perfect for bread, bagels, and more. Adjust shade level as desired.
- **Slow Cook:** Ideal for tender, slow-cooked dishes.

Video: A 30-day review of the Ninja Combi, highlighting its various cooking functions, ease of use, and performance for different types of meals. This video offers practical insights into the appliance's operation.



Image: A cutaway diagram of the Ninja Combi showing the HyperSteam zone for super-heated steam and the Air Fry zone for rapid cyclonic air, illustrating how they combine for cooking.

5. Cooking Tips

- **Frozen to Table:** The HyperSteam function allows you to cook frozen proteins and vegetables directly without pre-thawing.
- **Optimal Crisping:** For best air frying results, ensure food is arranged in a single layer on the Crisper Tray to allow for even air circulation.
- **Moisture Retention:** Combi Cooker modes are excellent for retaining moisture in foods, resulting in tender and juicy outcomes.
- **Adjust Cook Times:** When using the Ninja Combi, especially for air frying, you may need to reduce cooking times compared to conventional oven or basket air fryer recipes due to its efficient heating. Monitor food closely to prevent overcooking.



Image: The Ninja Combi Multicooker on a kitchen counter, with cooked chicken and pasta in serving bowls, illustrating the 'Never defrost again' feature.

6. Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your Ninja R-SFP701 multicooker.

- **Dishwasher Safe Accessories:** The Combi Cooker Pan, Bake Tray, and Crisper Tray are all dishwasher safe for convenient cleaning.
- **Wipe Down Unit:** After each use, allow the unit to cool completely. Wipe the exterior and interior of the cooking chamber with a damp cloth. For stubborn residue, use a non-abrasive sponge and mild dish soap.
- **Avoid Abrasive Cleaners:** Do not use abrasive cleaning pads or harsh chemicals, as these can damage the non-stick coating and stainless steel finish.

7. Specifications

Feature	Specification
Brand	Ninja
Model Name	Ninja SFP701 (or SFP703CO)
Color	Grey
Product Dimensions	13.11"D x 15.43"W x 13.11"H
Item Weight	20.2 pounds
Power Source	Electric
Control Type	Touch Control
Special Features	Auto Cook Menu, Automatic Shut-Off, Timer
Capacity	10 Cubic Inches (Internal Volume)
UPC	732388010110

8. Troubleshooting

If you encounter any issues with your Ninja R-SFP701, please refer to the following general troubleshooting advice:

- **Unit Not Turning On:** Ensure the power cord is securely plugged into a functional electrical outlet. Check if the outlet is receiving power.
- **Food Not Cooking Evenly:** Ensure food is arranged in a single layer on the appropriate tray (e.g., Crisper Tray for air frying) to allow for proper air circulation. Avoid overcrowding the cooking chamber.
- **Steam/Moisture Issues:** For Combi Cooker modes, ensure the water reservoir is filled to the recommended level. For Air Fry/Stovetop modes, ensure the top lid is open.
- **Unusual Noises:** Some operational noises are normal, especially during preheating or fan operation. If you hear excessive or unusual noises, ensure no foreign objects are inside the unit.
- **Error Codes:** If an error code appears on the display, consult the full product manual (if available) or contact Ninja customer support for specific guidance.

9. Warranty and Support

For detailed warranty information, product registration, and customer support, please refer to the official Ninja website or the documentation included with your product. Keep your purchase receipt as proof of purchase for warranty claims.

- **Product Registration:** Register your product online to receive exclusive savings, helpful tips, and support.
- **Customer Service:** Contact Ninja customer service for assistance with product operation, troubleshooting, or parts replacement.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question