Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BoxWave AccuPoint Active Stylus

BoxWave AccuPoint Active Stylus Instruction Manual

Model: AccuPoint Active Stylus

Introduction

The BoxWave AccuPoint Active Stylus is designed to provide a precise and natural writing experience on your touchscreen device. This electronic stylus features an ultra-fine tip for accuracy and a FiberMesh tip for broader interactions. It operates without the need for Bluetooth pairing, making it simple to use. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.

Setup

1. Initial Charging

Before first use, fully charge your AccuPoint Active Stylus. Use the included MicroUSB cable to connect the stylus to any standard USB power source (e.g., computer USB port, wall adapter).

- The indicator light will glow **red** during charging.
- The indicator light will turn **green** when fully charged.
- A full charge provides approximately 12 hours of use.

Image: The stylus connected to a charging cable, showing the indicator light for charging status.

2. Powering On/Off

To turn on the stylus, simply press the button located on the barrel. The indicator light will glow **blue** when the stylus is active. To turn off, press the button again.

3. No Pairing Required

The AccuPoint Active Stylus does not require Bluetooth pairing. It emits electronic pulses to interact with your device's screen directly.

Image: A detailed breakdown of the stylus features, highlighting the built-in charging port, indicator light, 1.9mm extra fine tip, and FiberMesh tip. It also indicates 'No Bluetooth Required'.

Operating Instructions

Using the Fine Tip

The ultra-fine 1.9mm tip is designed for precise tasks such as writing, drawing, and detailed navigation. Hold the stylus like a regular pen and gently touch the tip to your device's screen. The electronic pulses will allow for accurate interaction.

Image: A hand holding the stylus, using its fine tip to interact with an application icon on a tablet screen.

Using the FiberMesh Tip

The FiberMesh tip provides a softer, more responsive touch for general navigation, tapping, and swiping. This tip is located at the opposite end of the stylus and can be used for broader interactions.

Important Notes

- The AccuPoint Active Stylus does **not** support palm rejection. Avoid resting your palm on the screen while using the stylus for best results.
- The stylus does **not** support pressure sensitivity.

Image: The stylus positioned over a tablet screen, illustrating its use for higher accuracy and sensitivity.

Maintenance

Cleaning

To clean the stylus, gently wipe the barrel with a soft, dry cloth. Do not use harsh chemicals or abrasive materials, as these can damage the finish. For the tips, a slightly damp cloth can be used, ensuring no moisture enters the charging port.

Storage

Store the stylus in a cool, dry place away from direct sunlight and extreme temperatures. When not in use, ensure the stylus is turned off to conserve battery life.

Troubleshooting

- **Stylus Not Turning On:** Ensure the stylus is fully charged. Connect it to a power source using the MicroUSB cable and check if the red charging indicator light appears.

- **Stylus Not Responding on Screen:**
  a. Verify the stylus is turned on (blue indicator light).
  b. Ensure your device's screen is clean and free of debris.
  c. Restart your device.
  d. If using a screen protector, ensure it is compatible with stylus input.
- **Charging Issues:**
  a. Try a different MicroUSB cable and/or USB power source.
  b. Ensure the charging port on the stylus is clean and free of obstructions.

Specifications

Item Weight	1.3 ounces
Battery	1 Product Specific battery (included)
Battery Life	Up to 12 hours of use
Charging Port	MicroUSB
Fine Tip Size	1.9mm
Material	Brushed Aluminum

Warranty and Support

Return Policy

This product is eligible for a 30-day return for refund or replacement, subject to the retailer's return policy.

Manufacturer Support

For further assistance or inquiries regarding your BoxWave AccuPoint Active Stylus, please refer to the manufacturer's official website or contact their customer support directly. Contact information can typically be found on the product packaging or the BoxWave website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVNMRHFY

More documents and user manuals: **https://manuals.plus/**