Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bene Casa BC-58843

Bene Casa BC-58843 Electric Espresso Coffee Maker User Manual

Model: BC-58843

Important Safety Instructions

Please read all instructions carefully before using the Bene Casa BC-58843 Electric Espresso Coffee Maker. Keep this manual for future reference.

- Do not immerse the base unit in water or other liquids.
- Ensure the voltage rating matches your power supply.
- Do not operate the appliance with a damaged cord or plug.
- Keep out of reach of children.
- Always place the coffee maker on a stable, heat-resistant surface.
- Do not touch hot surfaces. Use handles or knobs.
- Unplug from outlet when not in use and before cleaning.
- Do not use outdoors.
- Use only with cold water.
- Do not overfill the water reservoir beyond the safety valve.
- Use only medium-ground coffee.

Product Overview

The Bene Casa BC-58843 is a portable electric espresso coffee maker designed for convenience and ease of use. It features an aluminum body and a detachable base for heating.



Image: Bene Casa BC-58843 Electric Espresso Coffee Maker, assembled on its base.

Components:

- **Upper Pot/Carafe:** Collects brewed coffee. Features a transparent lid and handle.
- **Filter Funnel:** Holds the ground coffee.
- **Lower Pot/Water Reservoir:** Holds water and contains the safety valve.
- **Heating Base:** Provides power and heat to the coffee maker. Includes an ON/OFF switch with indicator light.
- **Adapter for 3 or 6 cups:** Allows adjustment for different coffee volumes.
- **Silicone Gasket:** Ensures a tight seal between the upper and lower pots.

Setup Instructions

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash all detachable parts (upper pot, filter funnel, silicone gasket) with warm soapy water. Rinse thoroughly and dry. Do NOT immerse the heating base or the lower pot (water reservoir) in water. Wipe the exterior of the lower pot with a damp cloth.
3. **Assemble:**

- Ensure the silicone gasket is properly seated in the upper pot.
- Place the filter funnel into the lower pot.

4. **Fill Water:** Fill the lower pot (water reservoir) with cold water.
   - For 3 cups: Fill water up to half the height of the safety valve.
   - For 6 cups: Fill water just below the safety valve.

   Do not exceed the safety valve level to prevent overflow and ensure proper operation.
5. **Add Coffee:** Add medium-ground coffee to the filter funnel.
   - Do not press or tamp the coffee grounds. Level the coffee gently.
   - Ensure no coffee grounds are on the rim of the lower pot to ensure a tight seal.
6. **Assemble Pots:** Carefully screw the upper pot onto the lower pot, ensuring it is tightly sealed to prevent steam leakage.
7. **Place on Base:** Place the assembled coffee maker onto the heating base.

Visual Guide for Setup:

Your browser does not support the video tag.

Video: Demonstrates the assembly and filling process for the electric espresso coffee maker.

Your browser does not support the video tag.

Video: Step-by-step guide on how to use the electric espresso maker.

Operating Instructions

1. **Connect Power:** Plug the heating base into a suitable electrical outlet.
2. **Start Brewing:** Press the ON/OFF switch on the heating base. The indicator light will illuminate, signaling that the brewing process has started.
3. **Brewing Process:** Water will heat up and be forced through the coffee grounds into the upper pot. This process typically takes 3-5 minutes.
4. **Coffee Ready:** Once the upper pot is filled with brewed coffee and the flow slows or stops, the coffee is ready. The coffee maker will automatically switch to a keep-warm function (if available on your model) or turn off.
5. **Serve:** Carefully remove the coffee maker from the heating base by holding the handle. Pour the fresh espresso into your cups.
6. **Enjoy:** Your Bene Casa espresso is ready to be enjoyed as is, or as a base for lattes, cappuccinos, or Americanos.

Brewing Demonstration:

Your browser does not support the video tag.

Video: Shows the electric espresso maker in operation, brewing coffee.

Maintenance & Cleaning

Regular cleaning ensures optimal performance and longevity of your coffee maker.

1. **Unplug and Cool:** Always unplug the coffee maker from the power outlet and allow it to cool completely before cleaning.
2. **Disassemble:** Unscrew the upper pot from the lower pot. Remove the filter funnel and silicone gasket.
3. **Wash Parts:** Wash the upper pot, filter funnel, and silicone gasket with warm soapy water. Rinse thoroughly under running water.
4. **Clean Lower Pot:** Wipe the interior and exterior of the lower pot (water reservoir) with a damp cloth. Do NOT immerse the lower pot or the heating base in water.
5. **Dry:** Ensure all parts are completely dry before reassembling or storing.
6. **Storage:** Store the coffee maker in a dry place.

Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew or brews slowly.	• Insufficient water. • Coffee grounds too fine or tamped too hard. • Lid not tightly sealed. • Appliance not plugged in or switched on.	• Add water to the correct level. • Use medium-ground coffee and do not tamp. • Ensure upper pot is tightly screwed onto the lower pot. • Check power connection and switch.
Water leaks from the side.	• Upper and lower pots not tightly sealed. • Silicone gasket is worn or improperly placed. • Coffee grounds on the rim.	• Tighten the upper pot securely. • Check gasket placement; replace if worn. • Clean coffee grounds from the rim before assembly.
Coffee tastes weak.	• Too little coffee. • Coffee grounds too coarse. • Water level too high.	• Add more coffee grounds. • Use medium-ground coffee. • Ensure water is filled to the correct level (below safety valve).

Specifications

Feature	Detail
Brand	Bene Casa
Model Name	BC-58843
Coffee Maker Type	Espresso Machine
Capacity	6 Cups
Material	Aluminum, Plastic
Special Feature	Portable
Filter Type	Reusable
Operation Mode	Semi-Automatic
Voltage	120 Volts
Item Weight	2 pounds
Product Dimensions	9"D x 6"W x 11"H

Warranty and Support

For warranty information or product support, please refer to the contact details provided with your purchase or visit the official Bene Casa website.
Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Bene Casa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVNS7C28

More documents and user manuals: **https://manuals.plus/**