Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SUPERLEX Standmixer

SUPERLEX Electric Smoothie Blender and Multifunction Mixer User Manual

Model: Standmixer | Brand: SUPERLEX

Introduction

Thank you for choosing the SUPERLEX Electric Smoothie Blender and Multifunction Mixer. This appliance is designed for versatile kitchen tasks, including blending, chopping, grinding, and pureeing. With its powerful motor and durable stainless steel blades, you can easily prepare a variety of healthy beverages and meals. Please read this manual carefully before use to ensure safe and optimal operation.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the appliance.
- Keep the appliance out of reach of children.
- Do not immerse the motor base in water or other liquids. Clean only with a damp cloth.
- Ensure the lid and blade assembly are securely in place before operating the blender.
- Never operate the blender when empty.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not blend hot liquids in sealed containers, as pressure buildup can cause injury.
- This appliance features automatic overheat protection. If the motor stops due to overheating, unplug it and let it cool down for at least 15 minutes before resuming use.
- Do not use attachments not recommended or sold by the manufacturer.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.

Product Components

The SUPERLEX Electric Smoothie Blender comes with several components designed for various functions:

Motor Base: The main unit housing the 400W motor and control dial.

1.25L Blending Bowl: Large capacity container for smoothies, juices, and other mixtures.

2 x Portable Bottles: For on-the-go beverages.

Cross Blade Assembly (4-blade): Ideal for blending smoothies, juices, and crushing ice.

Flat Blade Assembly (2-blade): Suitable for grinding coffee beans, nuts, and chopping ingredients.

Measuring Cap: Removable cap on the blending bowl lid for adding ingredients during operation.

Grinding Attachment: A smaller container used with the flat blade for grinding tasks.

Juice Extractor: Component for extracting juice.



Image: The SUPERLEX blender system showing the motor base, large blending jar, portable bottles, and various ingredients like fruits, vegetables, and coffee beans, illustrating its multifunctionality.



Image: Detailed view of the blender's containers, including the 1000ml main blending jar, a 300ml coffee grinder attachment, and a 500ml portable sport bottle, highlighting their capacities and uses.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash all detachable parts (blending bowls, bottles, blade assemblies, lids) in warm, soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Assemble:**
    - Place the motor base on a clean, dry, and stable surface.
    - Attach the desired blade assembly (cross blade for blending, flat blade for grinding) to the appropriate container (blending bowl, portable bottle, or grinding attachment). Ensure it is twisted on tightly.
    - Place the assembled container onto the motor base. Align the tabs on the container with the slots on the motor base and twist clockwise until it locks securely into place. The built-in safety lock prevents operation if not correctly assembled.



Image: Illustration of the blender's safety features, including the removable measuring cap for adding ingredients, the safety interlock mechanism that ensures proper assembly before operation, and the automatic overheat protection.

Operating Instructions

General Blending/Mixing

1. **Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 1-2 cm). Do not overfill the container; ensure ingredients do not exceed the MAX fill line.
2. **Add Liquid:** For best results, always add some liquid (water, milk, juice) when blending solid ingredients.
3. **Assemble:** Securely attach the cross blade assembly to the blending bowl or portable bottle. Place the assembled container onto the motor base and twist to lock.
4. **Select Speed:** Plug in the appliance. Turn the control dial to the desired speed setting:
    - **"P" (Pulse):** For short bursts of power, ideal for crushing ice or chopping tough ingredients. Release the dial to stop.
    - **"1" (Low Speed):** Suitable for soft fruits, vegetables, and general mixing.

- **"2" (High Speed):** For harder ingredients, nuts, and achieving smoother consistencies.

5. **Blend:** Operate the blender for short intervals (e.g., 30-60 seconds) to avoid overheating. If blending for longer, allow brief pauses.
6. **Finish:** Once blending is complete, turn the dial to "0" (Off) and unplug the appliance. Twist the container counter-clockwise to unlock and remove it from the motor base.



Image: Close-up of the blender's control dial, illustrating the three speed settings: "P" for pulse (ice and hard ingredients), "1" for low speed (berries and vegetables), and "2" for high speed (hard-shelled fruits, meat, and nuts).



Image: Visual comparison of the two blade types: the 4-blade cross blade designed for blending smoothies, juices, and crushing ice, and the 2-blade flat blade used for grinding coffee, nuts, and chopping.

Grinding (Coffee Beans, Nuts)

1. Use the grinding attachment and the flat blade assembly.
2. Add dry ingredients to the grinding attachment. Do not overfill.
3. Securely attach the flat blade assembly to the grinding attachment.
4. Place the assembled grinding attachment onto the motor base and twist to lock.
5. Use the "P" (Pulse) setting for short bursts until desired consistency is achieved.
6. Turn off, unplug, and remove the attachment.

Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your SUPERLEX blender.

Cleaning

- **Always unplug** the appliance before cleaning.
- **Motor Base:** Wipe the motor base with a damp cloth. Never immerse it in water or any other liquid.
- **Detachable Parts:** All detachable parts (blending bowls, bottles, blade assemblies, lids) are dishwasher safe. Alternatively, they can be washed by hand in warm, soapy water. Rinse thoroughly and dry immediately.
- **Self-Cleaning Function:** For quick cleaning, add a small amount of water and a drop of dish soap to the blending bowl. Secure the lid and place it on the motor base. Run on speed "1" or "P" for a few seconds. Rinse thoroughly.
- **Caution:** Handle blade assemblies with extreme care as the blades are very sharp.



Image: Instructions for easy cleaning, showing that all detachable parts are dishwasher safe (except the motor body). It also illustrates the self-cleaning method by adding water and running the blender, and the process of carefully removing and rinsing the blades.

Storage

Store the appliance in a dry place, away from direct sunlight and out of reach of children. Ensure all parts are clean and dry before storing.

Troubleshooting

Problem	Possible Cause	Solution
Blender does not turn on.	◦ Not plugged in. ◦ Container not locked onto motor base. ◦ Overheat protection activated.	◦ Ensure the power cord is securely plugged into a working outlet. ◦ Twist the container clockwise until it locks into place. ◦ Unplug the blender and let it cool for 15 minutes.
Ingredients are not blending smoothly.	◦ Too little liquid. ◦ Container is overfilled. ◦ Ingredients are too large.	◦ Add more liquid. ◦ Reduce the amount of ingredients. ◦ Cut ingredients into smaller pieces. Use pulse function for tough items.
Leakage from the container.	◦ Blade assembly not tightened properly. ◦ Container overfilled. ◦ Seal ring is damaged or missing.	◦ Ensure the blade assembly is twisted on tightly. ◦ Do not exceed the MAX fill line. ◦ Check the seal ring for proper placement and damage. Replace if necessary.

Specifications

Feature	Detail
Brand	SUPERLEX
Model Number	Standmixer
ASIN	B0CVS3Z28N
Power Source	Corded Electric
Wattage	400 Watts
Voltage	220 Volts
Number of Speeds	3 (P, 1, 2)
Capacity	1.25 Liters (main blending bowl)
Product Dimensions	13D x 13W x 35H Centimeters
Material	Stainless Steel (Blades, Container Material)
Blade Material	Stainless Steel
Container Material	Stainless Steel

Feature	Detail
Special Features	Multiple attachments, Adjustable speed setting, Safety lock, Overheat protection, BPA-Free
Included Components	Blender, Juice container, Cups, Grinding attachment
Dishwasher Safe	Yes (detachable parts)

Warranty and Support

This SUPERLEX Electric Smoothie Blender comes with a full warranty. For detailed warranty terms and conditions, please refer to the documentation provided with your purchase or contact SUPERLEX customer support.
If you encounter any issues or have questions regarding your product, please contact the manufacturer's customer service for assistance. Please have your model number (Standmixer) and ASIN (B0CVS3Z28N) ready when contacting support.

© 2024 SUPERLEX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVS3Z28N

More documents and user manuals: **https://manuals.plus/**