Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MM-SOMNIA24ESTV-NP

ALLIMITY Replacement Remote Control for Telefunken TV User Manual

Model: MM-SOMNIA24ESTV-NP

Introduction

This manual provides detailed instructions for the ALLIMITY Replacement Remote Control, designed for various Telefunken TV models. This remote control offers full functionality without the need for programming or setup, serving as a direct replacement for your original remote.

Product Overview



Figure 1: Front view of the ALLIMITY replacement remote control, showing all buttons including power, number pad, volume, channel, navigation, and dedicated

app buttons for Netflix, YouTube, and Prime Video.



Figure 2: Angled view of the remote control, highlighting its ergonomic design and button layout.

Key Features:

- **No Programming Required:** Ready to use directly out of the box.
- **Full Functionality:** Designed to cover all functions of your original remote control.
- **Ergonomic Design:** Lightweight and comfortable to hold.
- **Stable Performance:** Offers a longer transmission distance and stable remote control performance.
- **Dedicated App Buttons:** Quick access to Netflix, YouTube, and Prime Video.

Setup

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.



Figure 3: Back view of the remote control, illustrating the battery compartment location.

The remote control is now ready for use with your compatible Telefunken TV.

Operating Instructions

This remote control operates via infrared (IR) technology. Ensure a clear line of sight between the remote and your TV's IR receiver for optimal performance.

Button Functions:

Button	Function
Power (Red Button)	Turns the TV on or off.
1-9, 0	Direct channel selection.
Volume (+/-)	Adjusts the volume level.
Channel (P Up/Down)	Changes the TV channel up or down.
Mute	Mutes or unmutes the TV audio.
Home (House Icon)	Accesses the TV's main menu or smart hub.
Navigation (Up/Down/Left/Right) & OK	Navigates through menus and confirms selections.
Back	Returns to the previous screen or menu.
Exit	Exits the current menu or application.
Netflix	Direct access to the Netflix application.
YouTube	Direct access to the YouTube application.
Prime Video	Direct access to the Prime Video application.
Colored Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions within menus or applications.
Media Control (Play, Pause, Stop, Rewind, Fast Forward)	Controls media playback.

Maintenance

Cleaning:

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's surface or internal components.

Battery Care:

- Replace batteries when the remote's response becomes sluggish or inconsistent.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new ones, ensuring correct polarity (+/-).
Remote not responding.	Obstruction between remote and TV.	Ensure a clear line of sight to the TV's IR receiver.
Remote has limited range.	Weak batteries.	Replace batteries.
Specific buttons not working.	Remote may not be fully compatible with all TV models or functions.	Verify your TV model is listed as compatible. Some advanced functions might require the original remote.

If issues persist after trying these solutions, please refer to your TV's user manual or contact the TV manufacturer for further assistance.

Specifications

Brand: ALLIMITY

Model Name: MM-SOMNIA24ESTV-NP

Color: Black

Connectivity Technology: Infrared

Special Feature: No programming required

Compatible Devices: Telefunken TV models including 40U298N4CWH, 287M4CWI, D50U293N4CWH, D32H289N4CWI, D40U297M4CW, 40DTF531, 43U297N4CWH, D50U600M4CWII, D55U297N4CWH, 65U4000N4CWH, JJ T-55UBS300, JT-65UBS300, L24H472F4CWI, L55U405N4CWH, D43U7000M4CWH, 49U70 0M4CWH, 32DTH531D32HXU43E512, D32H289N4CWD, SOMNIA24 ESTV, SOMNIA40DSTV, TE43292S31Y2P, TFL32SWB17/2, XU55E512, D43U600M4CWII, 49DTU652, 55DTU652, D32F289M4CWII.

Number of Buttons: 25

Controller Type: Button Control

Maximum Range: 10 Meters

Item Weight: 59 Grams

Country of Origin: China

Warranty and Support

Information regarding specific warranty terms for this ALLIMITY product is not provided in the product details. For warranty claims or technical support, please refer to the seller's return policy or contact the seller directly through the platform where the product was purchased.
Seller: ZHICHENGMAO
Return Policy: Typically 30 days for refund/replacement, as per platform policy.

© 2025 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVVLRVVZ

More documents and user manuals: **https://manuals.plus/**