Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE LSD132K02

VASAGLE Electric Standing Desk User Manual

MODEL: LSD132K02

Introduction

Thank you for choosing the VASAGLE Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions thoroughly before use and retain them for future reference.

Important Safety Instructions

- Do not place the desk directly against a wall to prevent scratches during height adjustments.
- This desk is designed for indoor use only. Keep all electrical components away from liquids to avoid damage or electric shock.
- If the desk is raised or lowered continuously for 2 minutes, the overheating protection system will activate automatically. You must wait 18 minutes before adjusting the height again.
- To protect the tabletop from bumps and scratches, you can adjust the sensitivity of the built-in sensor to detect solid objects when adjusting the height. Refer to the operating instructions for details on adjusting sensitivity.
- Ensure all cables are properly managed and secured to prevent entanglement during desk movement.
- Keep children and pets away from the desk during operation.
- Do not sit or stand on the desk.
- Do not exceed the maximum load capacity of 70 kg (154 lb).

Package Contents

Please verify that all components are present before beginning assembly:

- 1 x Electric Standing Desk Frame and Tabletop Components
- 1 x Storage Pocket
- 3 x Hook (2 for Hanging Storage Pocket)
- 1 x Accessory Kit (includes screws, Allen key, etc.)
- 1 x Instructions Manual (this document)

Setup and Assembly

Assembly of this height-adjustable desk is designed to be straightforward. All parts are labeled, and clear instructions are provided in the included accessory kit. An Allen key is provided, but a Phillips screwdriver (not included) will also be needed.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Follow the step-by-step diagrams and instructions provided in the separate assembly guide.
3. Ensure all screws are tightened securely, but do not overtighten.
4. Connect all electrical cables as indicated in the assembly guide.
5. Once assembled, place the desk in its desired location, ensuring adequate clearance for height adjustments.



Figure 1: Typical assembly diagram for the desk frame and tabletop. Refer to your specific assembly guide for detailed steps.

Operating Instructions

Control Panel Overview

The control panel allows you to adjust the desk height and save preferred positions.



Figure 2: Example of the desk's control panel. Button layout may vary slightly.

- **Up/Down Buttons:** Press and hold to move the desk up or down. Release to stop.
- **M Button:** Used to save memory presets.
- **1, 2, 3, 4 Buttons:** Memory preset buttons. Press to move the desk to a saved height.

Adjusting Desk Height

Press and hold the **Up** or **Down** button until the desk reaches your desired height. The desk can be adjusted between 72 cm (28.3 inches) and 120 cm (47.2 inches).

Setting Memory Presets

The desk allows you to save up to four preferred heights for quick access.

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **M** button. The display will show 'S-'.
3. Within 3 seconds, press one of the memory buttons (**1**, **2**, **3**, or **4**). The display will show 'S-1', 'S-2', etc., confirming the height is saved.
4. To recall a saved height, simply press the corresponding memory button (1, 2, 3, or 4).

Anti-Collision System

The desk is equipped with an anti-collision system that stops and retracts slightly if the tabletop encounters a solid obstacle during height adjustment. This feature helps prevent damage to the desk or objects.

- **Adjusting Sensitivity:** Refer to the detailed instructions in your assembly guide for steps on how to adjust the anti-collision sensitivity (e.g., low, medium, high). A higher sensitivity setting will detect obstacles more readily.

Overheating Protection

To prevent motor damage, the desk has an overheating protection system. If the desk is operated continuously for approximately 2 minutes, it will temporarily stop functioning. A cool-down period of 18 minutes is required before normal operation can resume.

Features and Accessories

- **Storage Pocket:** A durable Oxford fabric pocket is included for convenient storage of books, stationery, or other small items. It attaches to the desk using the provided hooks.
- **Hooks:** Three hooks are provided. Two are for hanging the storage pocket, and one can be used for headphones, bags, or other accessories.
- **Cable Holes:** Two integrated cable holes help manage and organize your power cords and other cables, keeping your workspace tidy.

Maintenance and Care

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Electrical Components:** Ensure all electrical connections are secure and free from dust. Do not attempt to open or repair the motor or control box yourself.
- **General Care:** Regularly check all screws and fasteners to ensure they remain tight. Avoid placing excessively heavy or sharp objects on the desk surface that could cause damage.

Troubleshooting

If you encounter issues with your desk, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Overheating protection active; Motor fault.	Check power connection; Wait 18 minutes if overheating; Contact customer support.
Desk moves unevenly or makes unusual noise.	Loose connections; Obstruction; Uneven load.	Check all assembly screws; Remove any obstructions; Distribute weight evenly.
Anti-collision system triggers too often/not at all.	Sensitivity setting incorrect.	Adjust anti-collision sensitivity as per assembly guide.
Display shows an error code (e.g., E01, E02).	Specific system error.	Refer to the detailed assembly guide for specific error code meanings and reset procedures. If the issue persists, contact customer support.

Specifications

Feature	Specification
Model Number	LSD132K02
Dimensions (D x W x H)	60 x 120 x (72-120) cm (23.6"D x 47.2"W x (28.3"-47.2"H))

Feature	Specification
Maximum Load Capacity	70 kg (154 lb)
Material	Particleboard, Steel, Oxford Fabric
Noise Level	Below 50 dB
Height Adjustment Range	72 cm to 120 cm (28.3" to 47.2")
Memory Presets	4
Assembly Required	Yes

Warranty and Customer Support

For warranty information, specific product support, or to report any issues not covered in this manual, please contact VASAGLE customer support. Details can typically be found on the product packaging or the official VASAGLE website.

You can also visit the VASAGLE Store on Amazon for more information and contact options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVVRSGZL

More documents and user manuals: **https://manuals.plus/**