Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SUPERLEX B0CVZZG5YR

SUPERLEX 4-in-1 Electric Smoothie Maker and Blender Set User Manual

Model: B0CVZZG5YR

1. Introduction

Thank you for choosing the SUPERLEX 4-in-1 Electric Smoothie Maker and Blender Set. This versatile kitchen appliance is designed to simplify your food preparation with its multifunctional capabilities, including blending, juicing, grinding, and ice crushing. With a powerful 400W motor and durable stainless steel blades, it offers efficient performance for a variety of tasks.
This manual provides essential information on the safe and effective use of your new blender set. Please read it thoroughly before first use and keep it for future reference.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Electrical Safety:** Ensure the voltage indicated on the appliance matches your local power supply before connecting. Do not immerse the motor base in water or other liquids.
- **Blade Safety:** The blades are extremely sharp. Handle them with extreme care, especially when assembling, disassembling, or cleaning.
- **Overheating Protection:** The blender is equipped with an automatic shut-off function to protect against overheating. If the appliance stops during operation, unplug it and allow it to cool down for at least 15 minutes before resuming use.
- **Safety Lock:** The appliance features a built-in safety lock device. The blender will only operate if all components are correctly assembled and locked into place. Do not attempt to force the appliance to operate if it is not properly assembled.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Usage:** Do not use the appliance for purposes other than its intended use. Do not operate the appliance with a damaged cord or plug.

3. Product Components

Your SUPERLEX 4-in-1 Electric Smoothie Maker and Blender Set includes the following main components:

- Motor Base with Control Dial

- 1.25L Blending Cup with Lid and Removable Measuring Cap
- Cross Blade Attachment (for blending/juicing)
- Flat Blade Attachment (for grinding/chopping)
- Grinder Attachment (300ml capacity)
- Juicer Attachment
- 2 Portable Bottles (500ml capacity each)



Figure 3.1: Overview of the SUPERLEX Blender Set and its components, including the motor base, large blending cup, two types of blade attachments, and portable bottles.



Figure 3.2: Detailed view of the two stainless steel blade attachments: the 4-blade for blending and juicing, and the 2-blade for grinding and crushing.



Figure 3.3: The 1000ml main blending jar, the 300ml coffee mill for grinding, and the 500ml sports bottle for on-the-go drinks.

4. Setup

Before first use, wash all detachable parts (blending cup, blades, lids, bottles) in warm soapy water, rinse thoroughly, and dry. The motor base should only be wiped with a damp cloth.

1. Place the motor base on a stable, flat, and dry surface.
2. Select the appropriate attachment (blending cup with cross blade, grinder with flat blade, or juicer).
3. Ensure the chosen attachment is securely fastened to the motor base. The safety lock device will prevent operation if not correctly assembled.
4. Plug the power cord into a suitable electrical outlet.



Figure 4.1: Illustration of the safety lock mechanism. The appliance will only operate when the blending cup is correctly assembled and locked onto the motor base.

5. Operation

The SUPERLEX blender offers three speed settings and a pulse function for precise control over your blending tasks.

Speed Settings:

- **'P' (Pulse):** Provides short bursts of power, ideal for crushing ice, chopping tough ingredients, or achieving a coarse texture. Hold the dial in the 'P' position for desired duration.
- **'1' (Low Speed):** Suitable for soft fruits, vegetables, and general blending tasks like making milkshakes or light smoothies.
- **'2' (Fast Speed):** Designed for harder ingredients, such as nuts, coffee beans, or mincing meat, requiring higher power and speed.



Figure 5.1: The control dial with 'P' for pulse, '1' for low speed, and '2' for fast speed, allowing precise control over blending.

General Operation Steps:

1. Add ingredients to the blending cup or grinder attachment. Do not exceed the MAX fill line. For the 1.25L blending cup, ensure ingredients are cut into small pieces.
2. Securely attach the lid or blade assembly.
3. Place the assembled cup onto the motor base, ensuring it locks into place.
4. Turn the control dial to the desired speed setting ('1', '2', or 'P').
5. Blend until the desired consistency is achieved. For continuous operation, do not run for more than 60 seconds at a time. Allow a short break between cycles.
6. Once finished, turn the dial to '0' (off) and unplug the appliance.
7. Carefully remove the blending cup or attachment from the motor base.



Figure 5.2: Visual guide for preparing various beverages such as fruit juice, milkshakes, vegetable juice, and smoothies using the blender.



Figure 5.3: The blender's versatility is demonstrated by its ability to prepare jam, juice, baby food, milkshake, smoothie, fruit puree, coffee, and minced meat.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your blender.

- **Motor Base:** Unplug the appliance before cleaning. Wipe the motor base with a damp cloth. Do not immerse it in water or any other liquid.
- **Detachable Parts:** All detachable parts, including the blending cup, blades, lids, and bottles, are dishwasher safe. For best results, rinse them immediately after use to prevent food residue from drying.
- **Self-Cleaning Function:** For quick cleaning of the blending cup, add a small amount of water and a drop of dish soap to the cup. Secure the lid and turn the knob to position '1' for a few seconds. Rinse thoroughly afterwards.
- **Caution:** Exercise extreme caution when handling the sharp blades. Always hold them by the plastic base, not the blades themselves.



Figure 6.1: The blender features easy-to-clean detachable parts and a self-cleaning function for convenience. Remember to exercise caution with sharp blades.

7. Troubleshooting

If you encounter issues with your SUPERLEX blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; Safety lock not engaged; Overheating.	Ensure power cord is securely plugged in. Check that the blending cup/attachment is correctly assembled and locked onto the motor base. If the unit overheated, unplug and let it cool for 15 minutes.
Motor stops during operation.	Overloaded; Overheating.	Reduce the amount of ingredients. Unplug the appliance and allow it to cool down for at least 15 minutes before restarting.

Problem	Possible Cause	Solution
Ingredients are not blending smoothly.	Too little liquid; Ingredients too large; Incorrect speed setting.	Add more liquid. Cut ingredients into smaller pieces. Use a higher speed setting or the pulse function for tougher ingredients.
Leakage from the blending cup.	Lid not properly sealed; Blade assembly not tightened.	Ensure the lid is securely closed. Check that the blade assembly is tightly screwed onto the blending cup.

8. Specifications

Key technical specifications for the SUPERLEX 4-in-1 Electric Smoothie Maker and Blender Set:

Brand: SUPERLEX

Model: B0CVZZG5YR

Colour: Silver

Product Dimensions: 15 x 15 x 34 cm

Item Weight: 2.3 kg

Capacity: 1.25 Litres (main blending cup)

Motor Power: 400W

Max RPM: 22,000 RPM

Number of Speeds: 3 (P, 1, 2)

Auto Shutoff: Yes (Overheat Protection)

Special Features: Safety Lock, Adjustable Speed Control, Multiple Attachments, Detachable Attachment, Compact Design.

9. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your product packaging or visit the official SUPERLEX website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 SUPERLEX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVZZG5YR

More documents and user manuals: **https://manuals.plus/**