Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VGR V-367, V-365

VGR 3-in-1 Rechargeable Hair Trimmer and Shaver (Models V-367, V-365) User Manual

Model: V-367, V-365

1. Introduction

Thank you for choosing the VGR 3-in-1 Rechargeable Hair Trimmer and Shaver. This versatile grooming tool is designed for precision hair trimming, beard shaving, and eyebrow detailing. Please read this manual carefully before using the device to ensure safe and optimal performance. Keep this manual for future reference.

2. Important Safety Information

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- Always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use this appliance with a damaged or broken comb or blade, as injury may occur.
- Always attach plug to appliance first, then to outlet. To disconnect, turn all controls to "OFF" then remove plug from outlet.
- This appliance is intended for household use only.

3. Package Contents

Please check the package for the following items:

- VGR Main Trimmer Unit
- Precision Trimmer Head
- Foil Shaver Head
- Nose/Ear Trimmer Head
- USB Charging Cable
- Cleaning Brush
- User Manual



Image 1: The VGR 3-in-1 grooming kit showing the main unit with the foil shaver head attached, the precision trimmer head, and a small cleaning tool. The product box is visible in the background.

4. Product Overview

The VGR 3-in-1 grooming device features a sleek design with interchangeable heads for various grooming needs.

- **Main Unit:** Ergonomic handle with power button and LED display.
- **LED Display:** Shows current cutting height (if adjustable) and battery level.
- **Precision Trimmer Head:** For hair cutting, beard trimming, and detailing. Features ultra-sharp 0mm blades for close cuts.
- **Foil Shaver Head:** For smooth shaving of facial hair.
- **Nose/Ear Trimmer Head:** For safe and comfortable removal of unwanted nose and ear hair.



Image 2: The VGR main unit displayed with all three interchangeable heads: the foil shaver head, the precision trimmer head, and the nose/ear trimmer head, showcasing the versatility of the device.

5. Charging the Device

The VGR trimmer is equipped with a rechargeable battery and features convenient USB charging.

1. Ensure the device is turned off before charging.
2. Insert the small end of the USB charging cable into the charging port at the bottom of the trimmer.
3. Connect the other end of the USB cable to a USB power source (e.g., computer, power bank, or USB wall adapter).
4. The LED display will indicate the charging status.
5. Once fully charged, disconnect the USB cable. The device offers a long operating time on a single charge.

Note: *For optimal battery life, avoid overcharging and fully discharge the battery occasionally before recharging.*

6. Setup and Operation

6.1 Attaching/Detaching Trimmer Heads

1. To attach a head: Align the desired trimmer head with the main unit and gently push until it clicks into place.
2. To detach a head: Hold the main unit firmly and pull the trimmer head upwards or press the release button (if present) to remove it.

6.2 General Operation

1. Ensure the device is charged.
2. Attach the appropriate head for your grooming task.
3. Press the power button to turn the device ON. The LED display will illuminate.
4. After use, press the power button again to turn the device OFF.

6.3 Using the Precision Trimmer Head (Hair & Beard)

- For best results, use on clean, dry hair.
- Hold the trimmer at a slight angle against the skin.
- Move the trimmer slowly against the direction of hair growth for an even cut.
- For detailing and edging, use the blade edge carefully.

6.4 Using the Foil Shaver Head (Beard & Stubble)

- Ensure your skin is clean and dry.
- Hold the shaver flat against your skin.
- Move the shaver in short, circular motions or straight strokes against the direction of hair growth.
- Stretch your skin with your free hand to achieve a closer shave.

6.5 Using the Nose/Ear Trimmer Head

- Gently insert the trimmer tip into your nostril or ear canal.
- Move the trimmer in a circular motion to trim unwanted hair.
- Do not insert the trimmer too deeply to avoid injury.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your VGR trimmer.

1. **Turn Off and Unplug:** Always ensure the device is turned off and disconnected from the charger before cleaning.
2. **Remove Trimmer Head:** Detach the used trimmer head from the main unit.
3. **Clean Blades:** Use the provided cleaning brush to brush away any hair clippings from the blades and inside the trimmer head.
4. **Clean Main Unit:** Wipe the main unit with a soft, dry cloth. Do not immerse the main unit in water.
5. **Lubricate Blades (Optional):** Periodically, apply a small drop of clipper oil (not included) to the blades to maintain sharpness and smooth operation. Run the trimmer for a few seconds to distribute the oil.
6. **Storage:** Store the trimmer and its accessories in a dry place, away from direct sunlight and out of reach of children.

8. Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is low or depleted.	Charge the device fully.
Trimmer runs slowly or pulls hair.	Blades are clogged with hair or dull.	Clean the blades thoroughly. If blades are dull, consider replacement (if available) or contact support.
Device not charging.	USB cable or power source is faulty.	Try a different USB cable or power source. Ensure the cable is properly connected.
Excessive noise or vibration.	Trimmer head not properly attached or internal issue.	Ensure the trimmer head is securely attached. If the problem persists, contact customer support.

9. Specifications

Feature	Detail
Brand	VGR
Model	V-367, V-365
Power Source	Battery Powered (Rechargeable)
Blade Material	Stainless Steel
Body Material	Stainless Steel
Special Features	Rechargeable, Portable, LED Display, Low Noise (<60dB), Detachable Design
Charging Type	USB
Recommended Use	Beard, Hair Trimming
Target Audience	Men
Color	Black
Item Weight	300 Grams
Country of Origin	China

10. Warranty and Support

VGR products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included in your product packaging or visit the official VGR website. If you encounter any issues or have questions regarding your device, please contact VGR customer support through their official channels or the retailer from whom you purchased the product.
Please retain your proof of purchase for warranty claims.

© 2023 VGR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW259RJY

More documents and user manuals: **https://manuals.plus/**