Feikeer RMF-TX910U

Feikeer RMF-TX910U Backlit Voice Remote Control User Manual

For Sony Bravia TVs

Introduction

This manual provides detailed instructions for the Feikeer RMF-TX910U backlit voice remote control. Designed as a replacement for original Sony Bravia TV remotes, it offers enhanced features such as backlighting, voice control, and dedicated hotkeys for popular streaming services. Please read this manual carefully to ensure proper setup and operation.



Image: The Feikeer RMF-TX910U remote control, showcasing its design and backlit buttons.

Setup

1. Battery Installation

Open the battery compartment cover on the back of the remote control. Insert two AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment. Close the cover securely.

2. Pairing Instructions

For full functionality, including voice control, the remote must be paired with your Sony Bravia TV. Follow these steps:

1. Ensure your TV is powered on.
2. On your TV, navigate to the 'Settings' menu, then 'Remotes & Accessories' or 'Bluetooth Settings'.
3. Select 'Pair remote' or 'Add device'.
4. On the Feikeer RMF-TX910U remote, simultaneously press and hold the **Microphone button** and the **Volume Down button** for approximately 3 seconds.
5. The remote's indicator light may flash, and your TV should detect the remote. Select it from the list on your TV screen to complete pairing.



Image: Diagram illustrating how to press the Microphone and Volume Down buttons simultaneously for pairing.

Note: Some Sony TV models may require pairing through a specific 'Add a remote' program within the TV settings, rather than a general 'Add device' option.

Operating Instructions

Basic Functions

The remote provides standard TV control functions:

- **Power Button:** Turns the TV on or off.
- **Volume Up/Down:** Adjusts the TV volume.
- **Channel Up/Down:** Changes TV channels.
- **Navigation Pad (Up/Down/Left/Right/Enter):** Used to navigate menus and select options.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Accesses the TV's home screen or smart hub.
- **Mute Button:** Mutes or unmutes the TV audio.

Voice Control

After successful pairing, press the **Microphone button** to activate voice commands. Speak clearly into the remote to search for content, open applications, or control your TV. For example, you can say "Hey Google, find my remote!" or "Open Netflix and play Stranger Things!".



Image: The remote control being used for voice commands, with examples like searching for videos or opening streaming apps.

Backlight Function

The remote features an automatic backlight function. When ambient light is low, the buttons will illuminate, making it easier to operate the remote in dark environments. The backlight activates automatically when the remote is moved or picked up and dims after a period of inactivity.



Image: The remote control with its backlit buttons visible in a dimly lit room, enhancing usability.

Hotkeys

The remote includes dedicated hotkeys for quick access to popular streaming services. These buttons allow you to launch applications like BRAVIA CORE, Netflix, Disney+, Prime Video, YouTube, and Crunchyroll with a single press.



Image: The remote control with a close-up view of the dedicated hotkeys for various streaming platforms.

Buzzer (Anti-Loss) Function

If you misplace your remote, you can use the anti-loss function. By saying "Hey Google, find my remote!" to your TV (if supported), the remote will emit a buzzer sound, helping you locate it.



Image: A user interacting with their TV to activate the remote's buzzer function via voice command.

Compatibility

The Feikeer RMF-TX910U remote control is compatible with a wide range of Sony Smart TVs, including the following series and models:

- **4K Ultra HD LED Series:** KD55X77L, KD43X77L, KD50X77L, KD65X77L, KD75X77L, KD85X77L
- **BRAVIA XR Series:**
  - QD-OLED A95L Series: XR65A95L, XR55A95L, XR77A95L
  - Mini LED X95L X93L Series: XR85X95L, XR65X93L, XR75X93L, XR85X93L
  - OLED A80L Series: XR65A80L, XR55A80L, XR77A80L, XR83A80L
  - Full Array LED X90L Series: XR55X90L, XR65X90L, XR75X90L, XR85X90L, XR98X90L
  - OLED A75L Series: XR55A75L, XR65A75L



Image: A visual representation of the remote's compatibility with various Sony Bravia TV series and models.

Specifications

Feature	Detail
Model Number	RMF-TX910U
Brand	Feikeer
Special Features	Voice Control, Backlit Buttons, Brushed Metal Panel, Beep Locator Function
Color	Brushed metal panel
Max Number of Supported Devices	18 (compatible Sony TV models)
Item Weight	2.89 ounces
Package Dimensions	8.19 x 4.92 x 0.79 inches
Response Time	0.2 seconds
Transmission Distance	15 meters

Troubleshooting

If you encounter issues with your Feikeer RMF-TX910U remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Check battery levels and replace if necessary.
  - Ensure there are no obstructions between the remote and the TV's IR receiver.
  - Re-pair the remote with your TV following the 'Pairing Instructions' section.

- **Voice Control Not Working:**
  - Confirm the remote is successfully paired via Bluetooth. Voice functionality requires Bluetooth connection.
  - Ensure the TV's microphone settings are enabled.
  - Speak clearly and close to the remote's microphone.
- **Backlight Not Activating:**
  - The backlight activates in low light conditions. Test in a darker room.
  - Ensure batteries have sufficient power.
- **Poor Range or Responsiveness:**
  - Ensure a clear line of sight to the TV.
  - Replace batteries if they are low, as this can affect signal strength.
- **Buzzer Function Not Working:**
  - Verify that your TV supports the "Find My Remote" feature via Google Assistant.
  - Ensure the remote is paired and connected to the TV.

Warranty and Support

Feikeer provides a 1-year warranty for this product. If you encounter any issues or are not satisfied with your purchase, you may request a free replacement within the warranty period. For technical assistance or customer service inquiries, please contact Feikeer support. We aim to provide a satisfactory response within 12 hours.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question