Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WINNY POOL CLEANER WINNY HJ1102 Charger

WINNY POOL CLEANER 200 SE Charger Accessories User Manual

Model: WINNY HJ1102 Charger

Introduction

This user manual provides essential information for the safe and effective use of your WINNY POOL CLEANER 200 SE Charger Accessories. Please read this manual thoroughly before operating the charger and retain it for future reference. This charger is designed specifically for compatible WINNY robotic pool cleaners, ensuring optimal charging performance.

Safety Information

- Use only with compatible WINNY POOL CLEANER models as specified.
- Do not expose the charger or cables to water or excessive moisture. This product is for indoor use only.
- Ensure the power outlet voltage matches the charger's specifications.
- Do not attempt to disassemble, modify, or repair the charger. Refer all servicing to qualified personnel.
- Keep the charger and cables away from heat sources, sharp objects, and areas where they could be tripped over.
- Unplug the charger from the power outlet when not in use or before cleaning.
- If the charger or cable appears damaged, discontinue use immediately and replace it with an official WINNY POOL CLEANER accessory.

Package Contents

Please verify that all items are present in your package:

- 1 x WINNY POOL CLEANER 200 SE Charger (Wall Adapter)
- 2 x USB Cable (with 2-Pin Connector)
- 1 x User Manual (this document)





Image: The WINNY POOL CLEANER 200 SE Charger Accessories, including the wall adapter and the USB cable with its distinct 2-pin connector, designed for charging compatible WINNY robotic pool cleaners.

Setup Instructions

1. **Prepare the Charger:** Unpack the WINNY POOL CLEANER 200 SE Charger and one of the provided USB cables.
2. **Connect USB Cable to Adapter:** Insert the standard USB-A end of the charging cable into the USB port on the WINNY POOL CLEANER wall adapter. Ensure it is firmly seated.
3. **Connect to Pool Cleaner:** Locate the charging port on your WINNY robotic pool cleaner. Carefully align the 2-pin connector end of the USB cable with the charging port on the pool cleaner and insert it. The connector is designed to fit in only one orientation. Do not force it.
4. **Plug into Power Outlet:** Plug the WINNY POOL CLEANER wall adapter into a standard electrical wall outlet (AC 100-240V, 50/60Hz).
5. **Verify Connection:** Once connected, your pool cleaner should indicate that it is charging, typically via an LED indicator on the cleaner itself. Refer to your pool cleaner's manual for specific charging indicators.

Operating Instructions

The WINNY POOL CLEANER 200 SE Charger is designed for simple operation:

- **Charging Cycle:** Once connected as per the setup instructions, the charger will automatically begin charging your WINNY robotic pool cleaner. The charging time will vary depending on the battery level of your pool cleaner.
- **Charging Indicators:** Monitor the charging status directly on your WINNY robotic pool cleaner. The charger itself does not have indicator lights.
- **Full Charge:** Disconnect the charger once your pool cleaner's battery is fully charged to prolong battery life. Refer to your pool cleaner's manual for full charge indications.
- **Storage:** When not in use, unplug the charger from the wall outlet and store it in a dry, cool place.

Maintenance

Proper maintenance ensures the longevity and performance of your charger:

- **Cleaning:** Disconnect the charger from the power outlet and the pool cleaner before cleaning. Wipe the charger and cables with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Cable Care:** Avoid bending or kinking the USB cables excessively, especially near the connectors. This can damage the internal wires.
- **Storage:** Store the charger and cables in a clean, dry environment, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the charger and cables for any signs of damage, such as frayed wires, cracked casing, or bent pins. If damage is found, replace the accessory immediately.

Troubleshooting

If you encounter issues with your WINNY POOL CLEANER 200 SE Charger, refer to the following table:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Pool cleaner not charging.	Charger not plugged in. Cable not properly connected. Damaged charger or cable. Incompatible pool cleaner model.	Ensure charger is securely plugged into a live outlet. Check connections at both the adapter and the pool cleaner. Inspect charger and cable for damage; replace if necessary. Verify your pool cleaner model is compatible with this charger.
Charger feels hot during use.	Normal operation. Poor ventilation. Overload/Fault.	A slight warmth is normal. Ensure charger is in a well-ventilated area. If excessively hot or emitting smoke/smell, unplug immediately and discontinue use.
2-pin connector does not fit.	Incorrect orientation. Incompatible model.	Ensure the connector is aligned correctly with the port. Do not force it. Confirm your pool cleaner uses a 2-pin charging port compatible with this charger.

If the problem persists after attempting these solutions, please contact WINNY POOL CLEANER customer support.

Specifications

Model: WINNY HJ1102 Charger

Input: AC 100-240V, 50/60Hz

Output: USB (Specific voltage/amperage for 2-pin cable is determined by the pool cleaner's requirements, typically 29.4V for WINNY models)

Connector Type: 2-Pin (Proprietary for WINNY Pool Cleaners)

Included Components: 1 x Wall Adapter, 2 x USB Cables)

Dimensions: Approximately 3 x 1 x 4 inches (Charger Adapter)

Weight: Approximately 3.2 ounces

Color: Black

Connectivity Technology: USB

Compatible Devices: Specific WINNY Robotic Pool Cleaners (e.g., WINNY POOL CLEANER 200 SE)

Warranty and Support

WINNY POOL CLEANER products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or to purchase replacement parts, please visit the official WINNY POOL CLEANER website or contact their customer service department.
Online Support: Visit the WINNY POOL CLEANER Store on Amazon
Please have your product model number (WINNY HJ1102 Charger) and purchase information ready when contacting support.

© 2025 WINNY POOL CLEANER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW2T8MGK

More documents and user manuals: **https://manuals.plus/**