Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MM-DVX3-NP

ALLIMITY Replacement Remote Control User Manual

For JTC Smart 4K LED TVs

Introduction

This manual provides comprehensive instructions for the ALLIMITY replacement remote control, specifically designed for various JTC Smart 4K LED TV models. Please read this manual carefully before using the remote control to ensure proper operation and to maximize its lifespan.

Product Overview

The ALLIMITY replacement remote control offers full functionality, replicating all features of your original remote. It requires no programming or complex setup, making it ready to use right out of the box. Its ergonomic design ensures comfortable handling and stable performance.

Compatible TV Models:

- DVX3
- LE-215M1
- G001-4032C
- DLE-315M1
- DLE-315M1D
- DLE-315MIS-D
- DLE-395M1
- DLE-500M1




4
5
6
7
8
9
REPEAT
SLEEP
0
MENU
SOUREC
EXIT
INFO
OK
VOL
CH
P.MODE
S.MODE
P.SIZE
GUIDE
PVR LIST
DTV/RADIO
FAV
SUBTITLE
TS
STOP
REC
TEXT
GOTO

Image 1: Front view of the ALLIMITY replacement remote control. This image displays the full layout of buttons, including power, number keys, navigation, volume, channel, and media controls.



Image 2: Angled view of the ALLIMITY replacement remote control. This perspective highlights the ergonomic shape and button placement from a side-front angle.





Image 3: Dimensions of the ALLIMITY replacement remote control. This image shows the remote's length (18 cm / 7.09 in), width (5 cm / 1.97 in), and thickness (2 cm / 0.78 in), providing a clear understanding of its physical size.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included).

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, ensuring correct polarity (**+** and **-**).
3. Close the battery compartment cover securely.

Note: Ensure batteries are inserted correctly. Incorrect polarity can damage the remote control.

Operating Instructions

The ALLIMITY replacement remote control is designed to mimic the functions of your original JTC TV remote. Below are common button functions:

Key Functions:

- **POWER (Red Button):** Turns the TV on or off.
- **AUDIO:** Selects audio tracks or modes.
- **MUTE:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Directly selects channels or inputs numerical values.
- **REPEAT:** Repeats the current media playback.
- **SLEEP:** Sets the sleep timer.
- **MENU:** Accesses the TV's main menu.
- **SOURCE/REC:** Selects input sources (HDMI, AV, etc.) or initiates recording.
- **EXIT:** Exits the current menu or function.
- **INFO:** Displays information about the current program or input.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes channels.
- **P.MODE (Picture Mode):** Selects picture presets.
- **S.MODE (Sound Mode):** Selects sound presets.
- **P.SIZE (Picture Size):** Adjusts the aspect ratio.
- **GUIDE:** Accesses the Electronic Program Guide (EPG).
- **PVR LIST:** Accesses the Personal Video Recorder list.
- **DTV/RADIO:** Switches between digital TV and radio modes.
- **FAV (Favorites):** Accesses favorite channel lists.
- **SUBTITLE:** Toggles subtitles on or off.
- **TS (Time Shift):** Activates time shift function.
- **STOP:** Stops media playback.
- **REC (Record):** Starts recording.
- **TEXT:** Accesses teletext.
- **GOTO:** Jumps to a specific time in media playback.
- **Media Control Buttons (Rewind, Play/Pause, Fast Forward, Previous, Next):** Controls media playback.

Maintenance

To ensure optimal performance and longevity of your remote control:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote control in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact.

Troubleshooting

If your remote control is not functioning correctly, try the following:

- **No Response:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Make sure you are within the effective operating range (up to 10 meters).
- **Intermittent Response:**
  - This could indicate low battery power. Replace the batteries.
  - Ensure the remote's infrared emitter is clean and unobstructed.
- **Remote Controls Other Devices:**
  - This remote is specifically designed for the listed JTC TV models. If it affects other devices, ensure the TV is the only device in its line of sight or check for any universal remote settings on your TV (though this remote is not programmable).

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	MM-DVX3-NP
Connectivity Technology	Infrared
Special Feature	Ergonomic Design
Maximum Range	10 Meters
Item Weight	59 Grams
Compatible TV Models	DVX3, LE-215M1, G001-4032C, DLE-315M1, DLE-315M1D, DLE-315MIS-D, DLE-395M1, DLE-500M1

Warranty and Support

Information regarding product warranty and dedicated support channels is not provided in the product details. Please refer to your purchase documentation or contact your retailer for details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW5XS3SD

More documents and user manuals: **https://manuals.plus/**