Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OSOTEK H200 PRO

OSOTEK H200 Pro Flat Mop Vacuum Cleaner User Manual

Model: H200 PRO

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your OSOTEK H200 Pro Flat Mop Vacuum Cleaner. Please read this manual thoroughly before first use and retain it for future reference.



Image: The OSOTEK H200 Pro vacuum cleaner with its charging dock, showcasing its sleek design and components.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.

- Do not immerse the appliance in water or other liquids.
- Do not use outdoors or on wet surfaces.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug.
- Turn off all controls before unplugging.
- Exercise extreme care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the appliance.

Product Components

Familiarize yourself with the parts of your OSOTEK H200 Pro.

- Main Unit (Handle, Motor, Clean Water Tank, Dirty Water Tank)
- Brush Head Assembly (Roller Brush, Scraper)
- Charging Dock
- Power Adapter
- Cleaning Solution
- Cleaning Tool



Image: A family in a clean living space, illustrating the desired outcome of using the OSOTEK H200 Pro for a comfortable home environment.

Setup and First Use

Assembly

1. Insert the handle into the main unit until it clicks into place.
2. Ensure the clean water tank and dirty water tank are correctly installed.
3. Place the charging dock on a flat surface near a power outlet.

4. Connect the power adapter to the charging dock and plug it into the outlet.

Charging the Battery

Before first use, fully charge the appliance. The LED display will indicate charging status.

- Place the vacuum cleaner on the charging dock.
- The battery indicator on the LED display will show charging progress.
- A full charge typically takes approximately 4 hours.

Filling the Clean Water Tank

- Remove the clean water tank from the main unit.
- Open the tank cap and fill with clean tap water. For enhanced cleaning, add a small amount of OSOTEK cleaning solution (do not exceed the MAX line).
- Close the cap securely and reinsert the tank into the main unit.

Operating Instructions

Starting the Appliance

- Press the Power button to turn on the vacuum cleaner.
- The appliance will start in standard cleaning mode.
- To switch between cleaning modes (e.g., Standard, Max, Suction Only), press the Mode button.

Cleaning Process

- Hold the handle firmly and tilt the main unit back to engage the brush head.
- The self-propulsion feature will assist in moving the vacuum forward. Guide the unit slowly over the floor surface.
- For optimal cleaning, move the vacuum in overlapping passes.
- The 180° flat design allows for cleaning under low furniture.
- The dual-edge cleaning feature ensures thorough cleaning along baseboards and corners.



Image: The OSOTEK H200 Pro demonstrating its ability to clean effectively under low-clearance furniture.



Image: The OSOTEK H200 Pro cleaning close to a wall, highlighting its edge-cleaning capabilities.

Maintenance and Care

Self-Cleaning Cycle

After each use, it is recommended to run the self-cleaning cycle.

1. Place the vacuum cleaner on the charging dock.
2. Ensure the dirty water tank is not full and the clean water tank has sufficient water.
3. Press the Self-Clean button (refer to your device's specific button layout).
4. The appliance will perform an automatic cleaning of the roller brush and internal pathways.
5. Once the cycle is complete, empty the dirty water tank.

Emptying and Cleaning the Dirty Water Tank

- Remove the dirty water tank from the main unit.
- Carefully open the tank and dispose of the dirty water and debris.
- Rinse the tank thoroughly with clean water.
- Clean the filter located in the dirty water tank.
- Allow all parts to air dry completely before reassembling.

Roller Brush Maintenance

- Periodically remove the roller brush from the brush head assembly.
- Use the provided cleaning tool to remove any tangled hair or debris.
- Rinse the roller brush under running water.
- Allow the brush to air dry completely before reinserting.

Hot Air Drying (58°C)

The OSOTEK H200 Pro features a 58°C hot air drying function for the brush after self-cleaning, which helps prevent odors and bacterial growth.

- This function typically activates automatically after a self-cleaning cycle.
- Ensure the appliance is on the charging dock for this feature to operate.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Battery is depleted.	Charge the appliance fully.
Poor suction.	Dirty water tank is full or filter is clogged.	Empty and clean the dirty water tank and filter.
Water leakage.	Clean/dirty water tank not properly installed or cap is loose.	Ensure tanks are securely in place and caps are tightened.
Unpleasant odor.	Dirty water tank or roller brush needs cleaning.	Perform self-cleaning cycle, then thoroughly clean dirty water tank and roller brush. Ensure hot air drying is active.
Appliance not self-propelling.	Brush head may be obstructed or in incorrect mode.	Check for obstructions in the brush head. Ensure appliance is in a cleaning mode that supports self-propulsion.

Product Specifications

- **Model:** H200 PRO
- **Brand:** OSOTEK
- **Dimensions (L x W x H):** 26.8 x 23.3 x 109.9 cm (10.55 x 9.17 x 43.27 inches)
- **Weight:** 5.1 kg (11.24 lbs)
- **Clean Water Tank Capacity:** 750 ml
- **Power:** 200 Watts
- **Voltage:** 21.6 Volts
- **Noise Level:** 78 dB
- **Runtime:** Up to 40 minutes
- **Special Features:** 180° Flat Design, 58°C Hot Air Drying, Dual-Edge Cleaning, LED Display, Self-Propulsion, Self-Cleaning
- **Battery:** 1 Lithium-ion (included)

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official OSOTEK website. Keep your purchase receipt as proof of purchase.
Manufacturer: OSOTEK
Date of First Availability on Amazon.com.be: February 22, 2024
For further assistance, please contact OSOTEK customer service.

© 2024 OSOTEK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CW62L8JP

More documents and user manuals: **https://manuals.plus/**