RYOBI 5132006152

Ryobi Tri-Arc+™ 3-Tooth Blade Ø 30 cm User Manual

Model: 5132006152 (RAC165)
Brand: RYOBI

Product Overview

This manual provides essential information for the safe and effective use of your Ryobi Tri-Arc+™ 3-Tooth Blade. Designed for Ryobi battery-powered brushcutters, this blade is engineered for efficient cutting performance.



Image: The Ryobi Tri-Arc+ 3-tooth blade, featuring a central mounting hole and the Ryobi logo, designed for brushcutters.

Key features of this blade include:

- Optimized for Ryobi battery-powered brushcutters.
- Durable construction for demanding cutting tasks.
- Designed for efficient clearing of dense vegetation.

Safety Information

Always prioritize safety when handling and operating power tools and their accessories. Failure to follow safety instructions can result in serious injury.

- **Read the Brushcutter Manual:** Always refer to the instruction manual of your specific Ryobi brushcutter model for detailed safety guidelines and installation procedures.
- **Personal Protective Equipment (PPE):** Always wear appropriate PPE, including safety glasses, hearing protection, heavy-duty gloves, long pants, and sturdy footwear, when installing or operating the blade.
- **Disconnect Power:** Before installing, removing, or inspecting the blade, ensure the brushcutter's battery is removed or the power source is disconnected to prevent accidental startup.
- **Inspect Blade:** Before each use, inspect the blade for cracks, bends, or excessive wear. Do not use a damaged blade.
- **Secure Mounting:** Ensure the blade is correctly and securely mounted according to your brushcutter's instructions. A loose blade can be extremely dangerous.

- **Clear Work Area:** Keep bystanders, children, and pets away from the work area. Clear the area of debris that could be thrown by the blade.

Setup and Installation

Proper installation of the blade is critical for safe and effective operation. Refer to your brushcutter's manual for specific instructions and diagrams.

1. **Prepare the Brushcutter:** Ensure the brushcutter is turned off and the battery pack is removed. Place the brushcutter on a stable, flat surface.
2. **Remove Existing Attachment (if applicable):** If another cutting attachment is installed, follow your brushcutter's manual to safely remove it.
3. **Position the Blade:** Align the central hole of the Ryobi Tri-Arc+ blade with the mounting shaft on the brushcutter's gearhead. Ensure the blade is oriented correctly (cutting edges facing the direction of rotation, if specified by your brushcutter manual).
4. **Secure the Blade:** Place any necessary washers, nuts, or retaining plates as instructed by your brushcutter's manual. Tighten the fastening nut securely using the appropriate wrench. Some models may require a locking pin to hold the shaft while tightening.
5. **Verify Installation:** Gently rotate the blade by hand to ensure it is seated correctly and spins freely without wobbling. Double-check that all fasteners are tight.



Image: A Ryobi brushcutter with the blade installed, actively cutting through dense undergrowth, demonstrating its use in a natural environment.

Operating Instructions

Once the blade is securely installed, follow these general operating guidelines. Always refer to your brushcutter's specific operating instructions.

- **Pre-Operation Check:** Before starting, ensure the blade is secure, the guard is in place, and the work area is clear.

- **Starting the Brushcutter:** Follow the manufacturer's instructions for starting your specific brushcutter model.
- **Cutting Technique:** Use a sweeping motion to cut vegetation. Avoid forcing the blade through thick material. Allow the blade to reach full speed before engaging with vegetation.
- **Maintain Control:** Always maintain a firm grip on the brushcutter handles and keep your balance.
- **Avoid Obstacles:** Be aware of hidden obstacles such as rocks, metal objects, or stumps that could damage the blade or cause kickback.
- **Overheating:** If the blade or brushcutter shows signs of overheating (e.g., unusual noise, smoke), stop immediately and allow it to cool.



Image: A person wearing safety gear, including a harness, operating a Ryobi battery-powered brushcutter in a grassy field, demonstrating proper posture and use.

Maintenance

Regular maintenance ensures the longevity and performance of your blade.

- **Cleaning:** After each use, remove the blade (following safety precautions) and clean off any accumulated grass, dirt, or sap. Use a stiff brush and mild detergent if necessary. Dry thoroughly to prevent rust.
- **Inspection:** Regularly inspect the blade for signs of wear, cracks, nicks, or deformation. Pay close attention to the cutting edges and the area around the mounting hole.
- **Sharpening:** While this blade is designed for durability, its cutting edges may dull over time. If sharpening is required, it should be done by a qualified professional or with appropriate tools and knowledge to maintain blade balance. An unbalanced blade can cause excessive vibration and damage to the brushcutter.
- **Replacement:** Replace the blade if it is severely damaged, bent, or excessively worn. Using a damaged blade can be dangerous and may harm your brushcutter.
- **Storage:** Store the clean, dry blade in a safe place, away from moisture and out of reach of children. Consider applying a light coat of oil to prevent rust if storing for extended periods.

Troubleshooting

This section addresses common issues related to blade performance.

Problem	Possible Cause	Solution
Excessive Vibration	Blade is loose, bent, or unbalanced.	Ensure blade is securely tightened. Inspect blade for damage; replace if bent or cracked. If dull, consider professional sharpening or replacement to restore balance.
Poor Cutting Performance	Blade is dull or worn.	Inspect blade for sharpness and wear. Sharpen or replace the blade as needed.
Blade Not Spinning Freely	Debris caught around the blade or mounting area.	Disconnect power and carefully remove any debris obstructing the blade's rotation.

Specifications

Manufacturer: RYOBI

Model Number: 5132006152 (RAC165)

Product Dimensions (L x W x H): 23.8 x 26 x 1.3 cm

Weight: 560 grams

Color: Metal Grey

Quantity: 1 blade

Power Source Type: Crank (refers to manual operation for installation/maintenance, not power source for brushcutter)

Batteries Required: No (for the blade itself)

ASIN: B0CW6DZWWY

Warranty and Support

RYOBI products are designed for durability and performance. For information regarding the warranty of your Ryobi tools and batteries, please refer to the official Ryobi warranty policy.
Generally, Ryobi tools and batteries are guaranteed for a total period of 24 months, with an additional one-year warranty extension offered if the consumer registers their product within 30 days of the purchase date. The registration confirmation and the original invoice stating the purchase date will serve as proof of warranty extension.
For technical support, spare parts, or warranty claims, please contact Ryobi customer service or visit the official Ryobi website. Keep your purchase receipt as proof of purchase.
You can find more information and contact details on the official Ryobi website:www.ryobi.eu

© 2024 RYOBI. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question