Fresh FDD-B315BS

Fresh Silver 12 cu ft Refrigerator FDD-B315BS User Manual

Model: FDD-B315BS

1. Introduction

Thank you for choosing the Fresh Silver 12 cu ft Refrigerator, model FDD-B315BS. This manual provides essential information for the safe and efficient use, installation, and maintenance of your appliance. Please read it thoroughly before operating the refrigerator and keep it for future reference.

1.1 Safety Information

- Ensure the refrigerator is placed on a stable, level surface.
- Do not block ventilation openings in the appliance enclosure or in the built-in structure.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Always unplug the appliance before cleaning or performing maintenance.
- Keep children away from packaging materials to prevent suffocation.

2. Product Overview

The Fresh Silver 12 cu ft Refrigerator FDD-B315BS is a freestanding, frost-free appliance designed for efficient food storage. It features a sleek silver finish and an electronic lock for added security.



Image 1: Front view of the Fresh Silver 12 cu ft Refrigerator FDD-B315BS. This image shows the refrigerator's exterior, highlighting its silver color and door design.

2.1 Main Components

- Refrigerator Compartment
- Adjustable Shelves
- Door Bins
- Temperature Control Dial/Panel
- Electronic Lock Mechanism

3. Setup

3.1 Unpacking

1. Carefully remove all packaging materials, including foam and adhesive tape.
2. Inspect the refrigerator for any shipping damage. Report any damage to your retailer immediately.
3. Remove any protective films from the surfaces.

3.2 Placement

- Place the refrigerator on a firm, level floor that can support its weight when fully loaded.
- Allow adequate space around the appliance for proper ventilation (at least 10 cm at the back and sides, and 30 cm at the top).
- Avoid direct sunlight or heat sources (e.g., stoves, radiators) as these will increase energy consumption.
- Ensure the ambient temperature is within the recommended operating range for the appliance.

3.3 Leveling

Adjust the leveling feet at the bottom front of the refrigerator to ensure it is stable and level. A level appliance operates more efficiently and prevents door alignment issues.

3.4 Electrical Connection

- Connect the refrigerator to a dedicated, properly grounded electrical outlet.
- Do not use extension cords or adapter plugs.
- Ensure the voltage and frequency match the ratings on the appliance's data plate.

3.5 First Use

After installation, wait at least 2-4 hours before plugging in the refrigerator to allow the refrigerant to settle. Once plugged in, set the temperature control to a medium setting and allow the appliance to cool for several hours before loading food.

4. Operating

4.1 Temperature Control

The refrigerator features adjustable temperature control. Locate the control dial or panel inside the refrigerator compartment. Turn the dial or press the buttons to adjust the cooling intensity. A higher number or colder setting typically means lower temperatures. Start with a medium setting and adjust as needed based on food load and ambient temperature.

4.2 Electronic Lock

Your refrigerator is equipped with an electronic lock. Refer to the specific instructions provided with your appliance for setting up and operating the electronic lock. Typically, this involves a keypad or a specific sequence of button presses to lock and unlock the door.

4.3 Food Storage Guidelines

- Store raw meat and poultry on the lowest shelf to prevent drips onto other foods.
- Keep dairy products, eggs, and cooked foods on middle shelves.
- Use door bins for condiments, drinks, and items with longer shelf lives.
- Do not overload the refrigerator, as this can impede air circulation and cooling efficiency.
- Ensure food is covered to prevent drying out and odor transfer.

5. Maintenance

5.1 Cleaning the Interior

1. Unplug the refrigerator before cleaning.
2. Remove all food items and removable parts (shelves, door bins).
3. Wash interior surfaces and removable parts with a solution of mild detergent and warm water. Rinse thoroughly and dry.
4. For stubborn stains, use a baking soda solution (2 tablespoons baking soda to 1 quart water).
5. Do not use abrasive cleaners, scouring pads, or harsh chemicals.

5.2 Cleaning the Exterior

Wipe the exterior surfaces with a soft cloth dampened with mild detergent and water. For the stainless steel door, use a specialized stainless steel cleaner and polish in the direction of the grain. Keep the door gasket clean to ensure a proper seal.

5.3 Frost-Free System

Your refrigerator features a frost-free system, which automatically prevents ice buildup. Therefore, manual defrosting is not required. Ensure the air vents inside the refrigerator are not blocked to allow the system to function effectively.

6. Troubleshooting

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate	No power; power cord unplugged; circuit breaker tripped.	Check power supply; ensure plug is secure; reset circuit breaker.
Temperature is not cold enough	Temperature control set too warm; door opened frequently; warm food added; poor ventilation.	Adjust temperature setting; minimize door openings; allow hot food to cool before storing; ensure proper clearance around appliance.

Problem	Possible Cause	Solution
Unusual noises	Appliance not level; objects vibrating against the unit; compressor noise (normal).	Level the appliance; remove any vibrating objects; normal compressor sounds are expected.
Door does not close properly	Door gasket dirty or damaged; appliance not level; food packages blocking door.	Clean or replace gasket; level the appliance; rearrange food items.

7. Specifications

Feature	Detail
Model Number	FDD-B315BS
Brand	Fresh
Configuration	Refrigerator without integrated freezer
Color	Silver
Installation Type	Freestanding
Defrost System Type	Frost-free
Finish Type	Glossy
Door Material Type	Stainless Steel
Cooling Method	Compressor
Number of Shelves	1
Adjustable Temperature Control	Yes
Compressor Type	Rotary Scroll
Convertible Freezer	No
Customizable	No
Electric	Yes
Lock Type	Electronic
Item Weight	38 kg
Energy Efficiency	Energy Star Compliant

Feature	Detail
Dimensions (D x W x H)	60 cm x 55 cm x 175 cm

8. Warranty and Support

This Fresh refrigerator comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. For technical support, service requests, or to purchase spare parts, please contact Fresh customer service through their official website or the contact information provided in your warranty documentation.

Always provide your model number (FDD-B315BS) and serial number when contacting support to ensure efficient service.

© 2026 Fresh Appliances. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question