## ZoneFly 1

# ZoneFly Pressure Release Valve User Manual

Model: 1

For Power Quick and Emeril Lagasse MultiCookers

## Introduction

Thank you for choosing the ZoneFly Pressure Release Valve. This component is designed to replace the original steam release handle on compatible pressure cookers, ensuring safe and efficient operation by controlling the 'Venting' and 'Sealing' functions.

This manual provides essential information for the proper installation, use, and maintenance of your new pressure release valve.




Image: The ZoneFly Pressure Release Valve, a black component, shown alongside a compatible multi-cooker, highlighting its purpose as a replacement part.

## Compatibility

This ZoneFly Pressure Release Valve is compatible with the following models:

- **Power Quick** 6 and 10 Quart 8-in-1 One-Touch MultiCooker Models Y6D-36 and Y10D-36
- **Emeril Lagasse** Pressure AirFryer Plus Models Y6D-AF-36 (6 qt) and Y8D-AF-36 (8 qt)

**Important: Please verify the size and shape of your existing valve against the product images before purchase to ensure proper fit.**




Image: The black pressure release valve positioned next to a Power Quick multi-cooker, illustrating its intended use and compatibility with the appliance.

## Product Features

- **High Quality Material:** Constructed from premium food-grade PP (Polypropylene) and ABS plastic, ensuring durability and high-temperature resistance.
- **Venting & Sealing Control:** Designed to effectively control the pressure release and sealing functions of your pressure cooker.
- **Easy Installation:** Simple to install and remove for cleaning and replacement.
- **Dishwasher Safe:** Allows for convenient and thorough cleaning.




Image: A detailed close-up of the black pressure release valve, emphasizing its smooth finish and robust construction, indicative of its high-quality material.

## Installation and Setup

Follow these steps to properly install the Pressure Release Valve:

1. **Remove Old Valve (if applicable):** Gently pull to remove the existing Pressure Release Valve from the lid of your pressure cooker.
2. **Inspect the Lid:** Ensure that the hole on the lid where the valve sits is clean and free from any food debris or blockages.
3. **Inspect New Valve:** Check the clip on the underside of the new Pressure Release Valve. It should not be damaged or severely bent.
4. **Insert New Valve:** Press the new Pressure Release Valve firmly into the hole on the lid until it clicks securely into place.

**Caution: Do not attempt to assemble or disassemble the Pressure Release Valve when the Power Quick Pot is in**

**use or under pressure.**




Image: A hand demonstrating the simple process of inserting the black pressure release valve into the designated opening on the lid of a pressure cooker.




Image: A visual guide illustrating the removal of the pressure release valve from the cooker lid (Fig. ix) and a view of the valve's underside clip (Fig. x), crucial for proper installation.

## Operating the Valve

The Pressure Release Valve controls the 'Venting' and 'Sealing' functions of your pressure cooker. Refer to your pressure cooker's main instruction manual for specific cooking procedures and pressure release methods.

- **Sealing Position:** Rotate the valve to the 'Sealing' position (usually indicated by a closed symbol) to allow pressure to build inside the cooker during cooking.
- **Venting Position:** Rotate the valve to the 'Venting' position (usually indicated by an open or steam symbol) to release steam and depressurize the cooker after cooking.

**Warning: Always ensure the valve is in the correct position before and after cooking. Never force the valve or attempt to open the lid while the cooker is pressurized.**

## Maintenance and Cleaning

Regular cleaning of the Pressure Release Valve is essential for optimal performance and hygiene.

- **Removal:** Gently pull the valve upwards to remove it from the cooker lid.
- **Cleaning:** The valve is dishwasher safe. Alternatively, wash it by hand with warm, soapy water. Ensure all food particles are removed from the valve's openings and internal components.
- **Rinsing:** Rinse thoroughly under running water.
- **Drying:** Allow the valve to air dry completely before re-installing it onto the cooker lid.




Image: A hand holding the black pressure release valve under running water from a faucet, demonstrating its ease of cleaning and dishwasher-safe feature.

## Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Valve does not fit correctly. | Incorrect model compatibility; bent clip on valve. | Verify your cooker model against the compatibility list. Inspect the valve's underside clip for damage; if bent, it may not insert correctly. |
| Steam leaks from around the valve. | Valve not fully seated; debris blocking seal; valve damaged. | Ensure the valve is pressed firmly into place. Remove and clean the valve and the lid's opening thoroughly. Inspect for cracks or damage; replace if necessary. |
| Valve is difficult to rotate. | Food residue buildup. | Remove the valve and clean it thoroughly, paying attention to any grooves or moving parts. |

## Specifications

- **Brand:** ZoneFly
- **Model Number:** 1
- **Material:** Food grade PP + ABS Plastic
- **Color:** Black
- **Product Dimensions:** Approximately 1"D x 1"W x 2"H
- **Item Weight:** 2.89 ounces
- **Dishwasher Safe:** Yes

## Support

For further assistance, questions, or concerns regarding your ZoneFly Pressure Release Valve, please contact the manufacturer or refer to the product listing on Amazon.com for seller contact information.

Visit the ZoneFly Store on Amazon: ZoneFly Store

© 2025 ZoneFly. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**