EUARY AFTO2301DT

EUARY AFTO2301DT Large Capacity Air Fryer Oven User Manual

Model: AFTO2301DT

Introduction

Thank you for choosing the EUARY AFTO2301DT Large Capacity Air Fryer Oven. This appliance is designed to provide versatile cooking options, combining the functions of an air fryer, oven, toaster, dehydrator, and rotisserie. With its 24-liter capacity and 1800W power, it offers efficient and healthy cooking for a variety of meals. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.



Image: The EUARY AFTO2301DT Air Fryer Oven showcasing its large interior with various cooked dishes, including a whole chicken, pastries, and a steak.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow for proper ventilation.

Product Overview

Components and Accessories

Your EUARY Air Fryer Oven comes with several accessories to enhance your cooking experience. Please identify each component:



Image: An exploded view of the EUARY Air Fryer Oven showing the main unit and its various accessories, each numbered for identification.

1. **Small Mesh Basket:** Ideal for air frying smaller items like fries or chicken wings.
2. **Small Oil Tray:** Collects drips and can be used for baking smaller items.

3. **Small Rack:** For general baking or to elevate food.
4. **Big Mesh Basket:** For larger batches of air-fried foods.
5. **Big Oil Tray:** For larger baking needs or collecting drips from larger items.
6. **Big Rack:** For larger baking or roasting.
7. **Clip:** For safely handling hot accessories.
8. **Grilled Chicken on a Spit (Rotisserie Spit):** For roasting whole chickens or other large cuts of meat.

Control Panel

The intuitive control panel allows you to select cooking functions, adjust time and temperature, and utilize special features like Dual Cook and Sync Finish.



Image: The digital control panel of the air fryer oven, displaying various cooking presets and control buttons.



Image: A detailed diagram of the control panel, with each button and display area clearly labeled for easy understanding.

- **A: Menu/Preset Icons:** PRE-HEAT, AIR FRY, BAGEL, CHICKEN, BROIL, PIZZA, ROAST, ROTISS, DEHYD, COOKIES, VEGETABLES, WARM, BAKE, FERMENT, REHEAT.
- **B: Zone 1 Controls:** Adjust time and temperature for the left cooking zone.
- **C: Start/Pause Button:** To start or pause the cooking process.
- **D: Light Button:** To turn the interior light on/off.
- **E: Temperature +/- Buttons:** To increase or decrease the cooking temperature.
- **F: Sync Finish Button:** Synchronizes the finish time for both cooking zones.
- **G: Time/Temperature Display:** Shows current time and temperature settings.
- **H: Dual Cook Button:** Applies the same cooking settings to both zones.
- **I: Time +/- Buttons:** To increase or decrease the cooking time.
- **J: Rotisserie Button:** Activates the rotisserie function.
- **K: Power On/Off Button:** To turn the appliance on or off.
- **L: Zone 2 Controls:** Adjust time and temperature for the right cooking zone.

Setup

1. **Unpacking:** Carefully remove all packaging materials, stickers, and labels from the appliance and its accessories.
2. **Initial Cleaning:** Wash all removable parts (baskets, trays, racks, rotisserie spit) in warm, soapy water. Wipe the interior and exterior of the main unit with a damp cloth. Dry all parts thoroughly before reassembly.
3. **Placement:** Place the air fryer oven on a stable, level, heat-resistant surface. Ensure there is at least 10-15 cm (4-6 inches) of clear space around the back and sides of the appliance for proper air circulation. Do not place it directly under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **First Use (Burn-in):** It is recommended to run the appliance empty for about 10-15 minutes at 180°C (350°F) to burn off any manufacturing residues. A slight odor or smoke may be present during this initial use; this is normal. Ensure good ventilation during this process.

Operating Instructions

General Operation

- **Power On/Off:** Press the Power button (K) to turn the appliance on or off.
- **Selecting a Preset:** Once powered on, touch one of the preset icons (A) to select a cooking function. The default time and temperature for that function will appear on the display (G).

- **Adjusting Time and Temperature:** Use the Temperature +/- buttons (E) and Time +/- buttons (I) to adjust the settings as needed for your recipe.
- **Starting/Pausing:** Press the Start/Pause button (C) to begin cooking. Press it again to pause the cooking cycle.
- **Interior Light:** Press the Light button (D) to illuminate the interior and check on your food.

Using Dual Zones and Special Functions

The EUARY AFTO2301DT features a unique divider board, allowing you to cook two different dishes simultaneously with independent settings.



Image: The interior of the air fryer oven, highlighting the removable divider board that separates the cooking cavity into two independent zones.

- **Dual Cook:**
    a. Place the divider board in the center slot.
    b. Load food into both zones.

c. Select your desired preset or manually set time/temperature for Zone 1 using controls (B, E, I).
d. Press the Dual Cook button (H). The settings from Zone 1 will be copied to Zone 2.
e. Press Start/Pause (C) to begin cooking.

- **Sync Finish:**

a. Place the divider board in the center slot.
b. Load food into both zones.
c. Set desired cooking time and temperature for Zone 1 (B, E, I).
d. Set desired cooking time and temperature for Zone 2 (L, E, I).
e. Press the Sync Finish button (F). The oven will automatically adjust the start time for the zone with the shorter cooking duration so both zones finish simultaneously.
f. Press Start/Pause (C) to begin cooking.

- **Rotisserie Function:**

a. Assemble the rotisserie spit with your food (e.g., a whole chicken).
b. Insert the rotisserie spit into the designated slots inside the oven.
c. Select the "ROTISS" preset or set manual time/temperature.
d. Press the Rotisserie button (J) to activate the rotation.
e. Press Start/Pause (C) to begin cooking.



Image: A collage demonstrating the versatility of the air fryer oven, showing it in use for air frying, roasting, baking, and rotisserie cooking.



Image: An internal view of the air fryer oven illustrating the hot air circulation technology, which ensures even cooking and crispiness with less fat.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your EUARY Air Fryer Oven.

1. **Before Cleaning:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Removable Parts:** The mesh baskets, oil trays, racks, and rotisserie spit are dishwasher safe. Alternatively, they can be washed by hand in warm, soapy water using a non-abrasive sponge. Rinse thoroughly and dry completely.
3. **Interior Cleaning:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn food residue, a paste of baking soda and water can be used, then wiped clean. Avoid abrasive cleaners or metal scouring pads.
4. **Exterior Cleaning:** Wipe the exterior of the appliance with a damp cloth. Do not use harsh chemicals or abrasive materials.

5. **Control Panel:** Wipe the control panel gently with a soft, damp cloth. Do not use excessive water.
6. **Storage:** Ensure all parts are clean and dry before storing the appliance. Store it in a cool, dry place.



Image: A hand wiping down a non-stick tray, demonstrating the ease of cleaning for the appliance's accessories.

Troubleshooting

If you encounter any issues with your air fryer oven, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance not switched on.	Ensure the power cord is securely plugged into a working outlet. Press the Power button (K).
Food is not cooked evenly.	Overcrowding the basket; incorrect temperature/time; food not shaken/flipped.	Do not overcrowd the basket; cook in smaller batches. Adjust temperature and time. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty food being cooked.	Clean the appliance and accessories thoroughly after each use. For fatty foods, ensure the oil tray is in place to catch drips.
Food is not crispy.	Too much moisture in food; not enough oil (for air frying); overcrowding.	Pat food dry before cooking. Lightly spray or toss food with oil for crispier results. Avoid overcrowding.
Loud rattling noise during operation.	Loose accessories; rotisserie spit not properly secured.	Ensure all racks, trays, and the rotisserie spit are correctly positioned and secured.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Brand: EUARY

Model Number: AFTO2301DT

Color: Black

Product Dimensions (L x W x H): 35 x 34 x 34 cm

Capacity: 24 Liters

Power: 1800 Watts

Voltage: 230 Volts (AC)

Item Weight: 15.1 Kilograms

Non-stick Coating: Yes

Dishwasher Safe Parts: Yes

UPC: 784868154562

Warranty and Support

This product comes with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or contact EUARY customer support. If you have any questions, require technical assistance, or need to report an issue, please contact our customer service team through the retailer's platform or the official EUARY website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question