bubbacare T1

bubbacare Portable Mini Washing Machine (Model T1) User Manual

Model: T1 | Brand: bubbacare

Introduction

This manual provides essential instructions for the safe and efficient operation of your bubbacare Portable Mini Washing Machine, Model T1. Designed for convenience and portability, this compact washing device is ideal for washing small, lightweight items such as socks, underwear, and baby clothes. Please read this manual thoroughly before use and retain it for future reference.



Image: The bubbacare Portable Mini Washing Machine in operation, demonstrating its compact design and washing action.

Important Safety Information

- Keep the device away from children. This product is not a toy.

- Do not touch the rotary fan (turbine) when the machine is operating.
- Prevent water from coming into contact with the USB cable or power connection.
- Always unplug the power cable after washing and before handling the unit.
- Only wash lightweight items. Do NOT wash large or heavy clothes such as T-shirts, sweaters, or coats. The maximum laundry capacity is 1KG (including water).
- Ensure the power adapter used is 5V~2A.

Package Contents

Verify that all items are present in the package:

- 1 x Mini Washing Machine (Ultrasonic Turbine)
- 1 x Portable Foldable Laundry Tub
- 1 x USB Cable
- 1 x Two-sided Suction Cup
- 1 x Operation Manual



Image: Contents of the bubbacare Portable Mini Washing Machine package.

Setup Instructions

Follow these steps to assemble your bubbacare Portable Mini Washing Machine:

1. **Attach the Suction Cup:** Stick the two-sided suction cup firmly onto the smooth side of the mini washing machine (turbine unit).
2. **Secure the Turbine:** Fix the washing machine (with the attached suction cup) to the bottom interior of the foldable bucket. Ensure it is securely attached.
3. **Expand the Bucket:** Hold up the foldable bucket to expand it to its full capacity.
4. **Fill with Water:** Fill the bucket with a suitable volume of water, ensuring it covers the clothes but does not exceed the maximum fill line.
5. **Connect Power:** Connect the USB cable to the washing machine and then to a 5V~2A USB power adapter (not included) or power bank.



Image: Step-by-step assembly guide for the bubbacare Portable Mini Washing Machine.

Operating Instructions

The bubbacare Portable Mini Washing Machine features intelligent washing modes for effective cleaning:

- **Smart Switching Mode:** The machine automatically switches between wave wheel (pulsator) and ultrasonic cleaning modes.
- **Smart Rotation:** The turbine rotates clockwise for 20 seconds, then switches to counter-clockwise for 20 seconds, ensuring thorough cleaning and preventing clothes from tangling.
- **Automatic Cycle:** The washing machine operates with a 2-minute ultrasonic cycle after 6 minutes of pulsator work.
- **Automatic Shut-down:** For safety and energy saving, the machine will automatically shut down after approximately 30-40 minutes of operation.

Washing Process:

1. Place small, lightweight items (e.g., underwear, socks, baby clothes, towels) into the foldable bucket. Ensure the total weight of clothes does not exceed 1KG.
2. Add an appropriate amount of water and a small quantity of laundry detergent.
3. Connect the USB power cable. The machine will begin its washing cycle automatically.
4. Once the cycle is complete or the machine automatically shuts down, unplug the USB cable.
5. Remove the washed items and rinse them manually if necessary.



Image: Key operating features of the bubbacare Portable Mini Washing Machine.



Image: Examples of suitable items for washing with the bubbacare Portable Mini Washing Machine.

Maintenance

To ensure the longevity and optimal performance of your washing machine:

- After each use, unplug the device and empty the water from the foldable bucket.

- Rinse the bucket and the turbine unit with clean water.
- Wipe all components dry with a soft cloth.
- Fold the bucket for compact storage once completely dry.
- Store the washing machine in a cool, dry place away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Machine does not start.	No power or loose USB connection.	Ensure USB cable is securely connected and power source (5V~2A) is active.
Washing performance is poor.	Overloaded with clothes or insufficient water.	Reduce the amount of laundry (max 1KG). Ensure adequate water level.
Machine stops unexpectedly.	Automatic shut-down feature activated.	This is normal operation after 30-40 minutes. Unplug and restart if needed for another cycle.
Clothes are tangling.	May occur with certain fabric types or if overloaded.	Ensure not to overload. The smart rotation feature is designed to minimize tangling.

Specifications

- **Model:** T1
- **Brand:** bubbacare
- **Capacity:** 5 Liters
- **Max Laundry Weight:** 1 KG (including water)
- **Power Input:** 5 Volts (DC) via USB
- **Recommended Adapter:** 5V~2A (not included)
- **Max Spin Speed:** 200 RPM
- **Operation Mode:** Fully Automatic (Pulsator & Ultrasonic)
- **Control Type:** Touch
- **Automatic Shut-off:** 30-40 minutes
- **Product Dimensions (Expanded):** Approximately 5"D x 4"W x 8"H (5 x 4 x 8 inches)
- **Product Dimensions (Folded):** Approximately 9.8" (diameter) x 2" (height) for bucket; 5.1" (diameter) x 2.2" (height) for turbine.
- **Item Weight:** 3.2 ounces (turbine unit)
- **Color:** White Gray



Image: Dimensions and typical usage environments for the bubbacare Portable Mini Washing Machine.

Warranty and Support

Warranty: bubbacare provides a lifetime product warranty for the Mini Washing Machine. Additionally, a 30-day refund service is available without any reason.

Customer Support: If you have any questions, concerns, or require assistance with your bubbacare Portable Mini Washing Machine, please do not hesitate to contact our customer support team. We are committed to providing prompt assistance and resolving any issues you may encounter.

Please refer to your purchase documentation or the seller's contact information for specific support channels.

© 2024 bubbacare. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question